

Operation Manual

Goodrive350 Series High-performance Multi-function Inverter



Preface

Thank you for choosing Goodrive350 series inverter.

Goodrive350 is a high-performance and multipurpose inverter aiming to integrate synchronous motor drive with asynchronous motor drive, and torque control, speed control with position control. It is armed with advanced vector control technology and the latest digital processor dedicated for motor control, thus enhancing product reliability and adaptability to the environment. Goodrive350 series inverter adopts customized and industrialized design to realize excellent control performance through optimized functions and flexible applications.

In order to meet diversified customer demands, Goodrive350 series inverter provides abundant extension cards including programmable extension card, PG card, communication card and I/O extension card to achieve various functions as needed.

The programmable extension card adopts the mainstream development environment for customers to carry out secondary development easily, fulfilling varied customized needs and reducing customer cost.

PG card supports a variety of encoders like incremental encoders and resolver-type encoders, in addition, it also supports pulse reference and frequency-division output. PG card adopts digital filter technology to improve EMC performance and to realize stable transmission of the encoder signal over a long distance. It is equipped with encoder offline detection function to contain the impact of system faults.

Goodrive350 series inverter supports multiple kinds of popular communication modes to realize complicated system solutions. It can be connected to the internet with optional wireless communication card, by which users can monitor the inverter state anywhere any time via mobile APP

Goodrive350 series inverter uses high power density design. Some power ranges carry built-in DC reactor and brake unit to save installation space. Through overall EMC design, it can satisfy the low noise and low electromagnetic interference requirements to cope with challenging grid, temperature, humidity and dust conditions, thus greatly improving product reliability.

This operation manual presents installation wiring, parameter setup, fault diagnosis and trouble shooting, and precautions related to daily maintenance. Read through this manual carefully before installation to ensure Goodrive350 series inverter is installed and operated in a proper manner to give full play to its excellent performance and powerful functions.

If the product is ultimately used for military affairs or manufacture of weapon, it will be listed on the export control formulated by Foreign Trade Law of the People's Republic of China. Rigorous review and necessary export formalities are needed when exported.

Our company reserves the right to update the information of our products.

Contents

Preface	i
Contents	ii
Chapter 1 Safety precautions	1
1.1 What this chapter contains	1
1.2 Safety definition	1
1.3 Warning symbols	1
1.4 Safety guidelines	
Chapter 2 Quick startup	5
2.1 What this chapter contains	5
2.2 Unpack inspection	5
2.3 Application confirmation	5
2.4 Environment confirmation	5
2.5 Installation confirmation	6
2.6 Basic commissioning	6
Chapter 3 Product overview	8
3.1 What this chapter contains	8
3.2 Basic principle	8
3.3 Product specification	10
3.4 Product nameplate	
3.5 Type designation key	12
3.6 Rated value	12
3.7 Structure diagram	
Chapter 4 Installation guide	16
4.1 What this chapter contains	16
4.2 Mechanical installation	16
4.3 Standard wiring of main circuit	
4.4 Standard wiring of control circuit	
4.5 Wiring protection	
Chapter 5 Basic operation instructions	
5.1 What this chapter contains	33
5.2 Keypad introduction	
5.3 Keypad display	
5.4 Keypad operation	38
5.5 Basic operation instruction	
Chapter 6 Function parameter list	
6.1 What this chapter contains	
6.2 Function parameter list	
Chapter 7 Troubleshooting	
7.1 What this chapter contains	
7.2 Indications of alarms and faults	232

Goodrive350 series high-performance multi-function inverter	Contents
7.3 Fault reset	232
7.4 Fault history	232
7.5 Inverter faults and solutions	232
7.6 Analysis on common faults	241
7.7 Countermeasures on common interference	248
Chapter 8 Maintenance and hardware fault diagnosis	252
8.1 What this chapter contains	252
8.2 Periodical inspection	252
8.3 Cooling fan	254
8.4 Capacitor	255
8.5 Power cable	257
Chapter 9 Communication protocol	258
9.1 What this chapter contains	258
9.2 Modbus protocol introduction	258
9.3 Application of Modbus	258
9.4 RTU command code and communication data	264
9.5 Common communication faults	279
Appendix A Extension cards	281
A.1 Model definition	281
A.2 Dimensions and installation	286
A.3 Wiring	289
A.4 IO extension card function description	289
A.5 PG extension card function description	291
A.6 Communication card function description	305
A.7 Programmable extension card function description	312
Appendix B Technical data	315
B.1 What this chapter contains	315
B.2 Derated application	315
B.3 Grid specifications	316
B.4 Motor connection data	316
B.5 Application standards	317
B.6 EMC regulations	317
Appendix C Dimension drawings	319
C.1 What this chapter contains	319
C.2 Keypad structure	319
C.3 Inverter structure	320
C.4 Dimensions of Inverters of AC 3PH 380V (-15%)-440V (+10%)	320
C.5 Dimensions of Inverters of AC 3PH 520V (-15%)-690V (+10%)	325
Appendix D Optional peripheral accessories	
D.1 What this chapter contains	329
D.2 Wiring of peripheral accessories	329

Goodrive350 series high-performance multi-function inverter	Contents
D.3 Power supply	331
D.4 Cables	331
D.5 Breaker and electromagnetic contactor	336
D.6 Reactors	338
D.7 Filters	341
D.8 Brake system	344
Appendix E STO function description	
E.1 STO function logic table	349
E.2 STO channel delay description	349
E.3 STO function installation checklist	350
Appendix F Acronyms and abbreviations	351
Appendix G Further information	352
G.1 Product and service queries	352
G.2 Feedback on INVT Inverter manuals	352
G.3 Documents on the Internet	352

Chapter 1 Safety precautions

1.1 What this chapter contains

Read this manual carefully and follow all safety precautions before moving, installing, operating and servicing the inverter. If these safety precautions are ignored, physical injury or death may occur, or damage may occur to the equipment.

If any physical injury or death or damage to the equipment occur due to neglect of the safety precautions in the manual, our company will not be responsible for any damages and we are not legally bound in any manner.

1.2 Safety definition

Danger: Serious physical injury or even death may occur if related requirements are not followed

Warning: Physical injury or damage to the equipment may occur if related requirements are not followed

Note: Procedures taken to ensure proper operation.

Qualified electricians: People working on the device should take part in professional electrical and safety training, receive the certification and be familiar with all steps and requirements of installing, commissioning, operating and maintaining the device to prevent any emergencies.

1.3 Warning symbols

Warnings caution you about conditions which can result in serious injury or death and/or damage to the equipment, and advice on how to avoid the danger. Following warning symbols are used in this manual.

Symbols	Name	Instruction	Abbreviation
A Danger	Danger	Serious physical injury or even death may occur if related requirements are not followed	<u>A</u>
Marning	Warning	Physical injury or damage to the equipment may occur if related requirements are not followed	\triangle
Forbid	Electrostatic discharge	Damage to the PCBA board may occur if related requirements are not followed	*
Mot Hot	Hot sides	The base of the inverter may become hot. Do not touch.	
<u></u>	Electric shock	As high voltage still presents in the bus capacitor after power off, wait for at least five minutes (or 15 min / 25 min, depending on the warning symbols on the machine) after power	<u>^</u> Ĉ 5 min

Symbols	Name	Instruction	Abbreviation
		off to prevent electric shock	
	Read manual	Read the operation manual before operating on the equipment	
Note	Note	Procedures taken to ensure proper operation	Note

1.4 Safety guidelines

Only trained and qualified electricians are allowed to carry out related operations.

Do not perform wiring, inspection or component replacement when power supply is applied. Ensure all the input power supplies are disconnected before wiring and inspection, and wait for at least the time designated on the inverter or until the DC bus voltage is less than 36V. The minimum waiting time is listed in the table below.



Inv	erter model	Minimum waiting time		
380V	1.5kW-110kW	5 min		
380V	132kW-315kW	15 min		
380V	Above 355kW	25 min		
660V	22kW-132kW	5 min		
660V	160kW-350kW	15 min		
660V	400kW-630kW	25 min		



Do not refit the inverter unless authorized; otherwise, fire, electric shock or other injuries may occur.



♦ The base of the radiator may become hot during running. Do not touch to avoid hurt.



The electrical parts and components inside the inverter are electrostatic. Take measures to prevent electrostatic discharge during related operation.

1.4.1 Delivery and installation

Install the inverter on fire-retardant material and keep the inverter away from combustible materials.



- Connect the optional brake parts (brake resistors, brake units or feedback units) according to the wiring diagram.
- Do not operate on a damaged or incomplete inverter.
- Do not touch the inverter with wet items or body parts; otherwise, electric shock may occur.

Note:

Select appropriate tools for delivery and installation to ensure a safe and proper running of the inverter and avoid physical injury or death. To ensure physical safety, the installation staff should take mechanical protective measures like wearing exposure shoes and working uniforms;

- ♦ Ensure to avoid physical shock or vibration during delivery and installation;
- Do not carry the inverter by its front cover only as the cover may fall off;
- Installation site should be away from children and other public places;
- The inverter cannot meet the requirements of low voltage protection in IEC61800-5-1 if the altitude of installation site is above 2000m;
- The inverter should be used in proper environment (see chapter 4.2.1 Installation environment for details);
- Prevent the screws, cables and other conductive parts from falling into the inverter;
- As leakage current of the inverter during running may exceed 3.5mA, ground properly and ensure the grounding resistance is less than 10Ω. The conductivity of PE grounding conductor is the same with that of the phase conductor (with the same cross sectional area).
- R, S and T are the power input terminals, and U, V and W are output motor terminals. Connect the input power cables and motor cables properly; otherwise, damage to the inverter may occur.

1.4.2 Commissioning and running

- Disconnect all power sources applied to the inverter before terminal wiring, and wait for at least the time designated on the inverter after disconnecting the power sources.
- High voltage presents inside the inverter during running. Do not carry out any operation on the inverter during running except for keypad setup. For products at voltage levels of 5 or 6, the control terminals form extra-low voltage circuits. Therefore, you need to prevent the control terminals from connecting to accessible terminals of other devices.
- The inverter may start up by itself when P01.21 (restart after power down) is set to 1. Do not get close to the inverter and motor.
- ♦ The inverter cannot be used as "Emergency-stop device".
 - The inverter cannot act as an emergency brake for the motor; it is a must to install mechanical brake device.



- During driving permanent magnet synchronous motor, besides above-mentioned items, the following work must be done before installation and maintenance.
 - Disconnect all the input power sources including main power and control power.
 - Ensure the permanent-magnet synchronous motor has been stopped, and the voltage on output end of the inverter is lower than 36V.
 - After the permanent-magnet synchronous motor is stopped, wait for at least the time designated on the inverter, and ensure the voltage between "+" and "-" is lower than 36V.
 - 4. During operation, it is a must to ensure the permanent-magnet synchronous motor cannot run again by the action of external load; it is recommended to install effective external brake device or disconnect the direct electrical connection between permanent-magnet synchronous

motor and the inverter.

- Do not switch on or switch off input power sources of the inverter frequently;
- ♦ For inverters that have been stored for a long time, set the capacitance and carry out inspection and pilot run on the inverter before use.
- Close the front cover before running; otherwise, electric shock may occur.

1.4.3 Maintenance and component replacement



- Only well-trained and qualified professionals are allowed to perform maintenance, inspection, and component replacement on the inverter.
- Disconnect all the power sources applied to the inverter before terminal wiring, and wait for at least the time designated on the inverter after disconnecting the power sources.
- Take measures to prevent screws, cables and other conductive matters from falling into the inverter during maintenance and component replacement.

Note:

- Use proper torque to tighten the screws.
- Keep the inverter and its parts and components away from combustible materials during maintenance and component replacement.
- Do not carry out insulation voltage-endurance test on the inverter, or measure the control circuits of the inverter with megameter.
- Take proper anti-static measures on the inverter and its internal parts during maintenance and component replacement.

1.4.4 What to do after Scrapping



The heavy metals inside the inverter should be treated as industrial effluent.



When the life cycle ends, the product should enter the recycling system. Dispose of it separately at an appropriate collection point instead of placing it in the normal waste stream.

Chapter 2 Quick startup

2.1 What this chapter contains

This chapter introduces the basic principles required during installation commissioning. Users can realize quick installation commissioning by following these principles.

2.2 Unpack inspection

Check as follows after receiving products.

- Check whether the packing box is damaged or dampened. If yes, contact local dealers or INVT offices.
- Check the model identifier on the exterior surface of the packing box is consistent with the purchased model. If no, contact local dealers or INVT offices.
- Check whether the interior surface of packing box is improper, for example, in wet condition, or whether the enclosure of the inverter is damaged or cracked. If yes, contact local dealers or INVT offices.
- 4. Check whether the nameplate of the inverter is consistent with the model identifier on the exterior surface of the packing box. If not, contact local dealers or INVT offices.
- Check whether the accessories (including user's manual, control keypad and extension card units) inside the packing box are complete. If not, contact local dealers or INVT offices.

2.3 Application confirmation

Check the following items before operating on the inverter.

- 1. Verify the load mechanical type to be driven by the inverter, and check whether overload occurred to the inverter during actual application, or whether the inverter power class needs to be enlarged?
- 2. Check whether the actual running current of load motor is less than rated inverter current.
- Check whether the control precision required by actual load is the same with the control precision provided by the inverter.
- 4. Check whether the grid voltage is consistent with rated inverter voltage.
- 5. Check whether the functions required need an optional extension card to be realized.

2.4 Environment confirmation

Check the following items before use.

- Check whether the ambient temperature of the inverter during actual application exceeds 40°C, if yes, derate 1% for every additional 1°C. In addition, do not use the inverter when the ambient temperature exceeds 50°C.
 - Note: For cabinet-type inverter, its ambient temperature is the air temperature inside the cabinet
- Check whether ambient temperature of the inverter during actual application is below -10°C, if yes, install heating facility.

Note: For cabinet-type inverter, its ambient temperature is the air temperature inside the

cabinet.

- Check whether the altitude of the application site exceeds 1000m, if yes, derate 1% for every additional 100 m.
- 4. Check whether the humidity of application site exceeds 90%, if yes, check whether condensation occurred, if condensation does exist, take additional protective measures.
- Check whether there is direct sunlight or animal intrusion in the application site, if yes, take additional protective measures.
- Check whether there is dust, explosive or combustible gases in the application site, if yes, take additional protective measures.

2.5 Installation confirmation

After the inverter is installed properly, check the installation condition of the inverter.

- Check whether the input power cable and current-carrying capacity of the motor cable fulfill actual load requirements.
- Check whether peripheral accessories (including input reactors, input filters, output reactors, output filters, DC reactors, brake units and brake resistors) of the inverter are of correct type and installed properly; check whether the installation cables fulfill requirements on current-carrying capacity.
- 3. Check whether the inverter is installed on fire-retardant materials; check whether the hot parts (reactors, brake resistors, etc.) are kept away from combustible materials.
- Check whether all the control cables are routed separately with power cables based on EMC requirement.
- Check whether all the grounding systems are grounded properly according to inverter requirements.
- Check whether installation spacing of the inverter complies with the requirements in operation manual.
- Check whether installation mode of the inverter complies with the requirements in operation manual. Vertical installation should be adopted whenever possible.
- 8. Check whether external connecting terminals of the inverter are firm and tight enough, and whether the moment is up to the requirement.
- Check whether there are redundant screws, cables or other conductive objects inside the inverter, if yes, take them out.

2.6 Basic commissioning

Carry out basic commissioning according to the following procedures before operating on the inverter.

- Select motor type, set motor parameters and select inverter control mode according to actual motor parameters.
- 2. Whether autotuning is needed? If possible, disconnect the motor load to carry out dynamic parameter autotuning; if the load cannot be disconnected, perform static autotuning.
- 3. Adjust the acceleration and deceleration time based on actual working conditions of the

load.

- 4. Jogging to carry out device commissioning. Check whether the motor running direction is consistent with the direction required, if no, it is recommended to change the motor running direction by exchanging the motor wiring of any two phases.
- 5. Set all the control parameters, and carry out actual operation.

Chapter 3 Product overview

3.1 What this chapter contains

This chapter mainly introduces the operation principles, product features, layouts, nameplates and model instructions.

3.2 Basic principle

Goodrive350 series inverter is used to control asynchronous AC induction motor and permanent-magnet synchronous motor. The figure below shows the main circuit diagram of the inverter. The rectifier converts 3PH AC voltage into DC voltage, and the capacitor bank of intermediate circuit stabilizes the DC voltage. The inverter converts DC voltage into the AC voltage used by AC motor. When the circuit voltage exceeds the maximum limit value, external brake resistor will be connected to intermediate DC circuit to consume the feedback energy.




Fig 3.1 380V (15kW and below) main circuit diagram




Fig 3.2 380V (18.5kW-110kW (inclusive)) main circuit diagram




Fig 3.3 380V (132kW and above) main circuit diagram




Fig 3.4 660V main circuit diagram

- 132kW and above inverters can be connected to external DC reactors. Before connection, it is
 required to take off the copper bar between P1 and (+). 132kW and above inverters can be
 connected to external brake unit. DC reactors and brake units are optional parts.
- 2. 18.5kW-110kW (inclusive) inverters are equipped with built-in DC reactor.
- 37kW and below models carry built-in brake units, 45kW-110kW (inclusive) supports built-in brake unit. The models that carry built-in brake unit can also be connected to external brake resistor. The brake resistor is optional part.
- 4. 660V inverters can be connected to external DC reactor. Before connection, it is required to take off the copper bar between P1 and (+). 660V inverters can be connected to external brake unit. DC reactors and brake units are optional parts.

3.3 Product specification

Func	tion description	Specification	
7 41110		AC 3PH 380V (-15%)–440V (+10%) rated voltage: 380V	
	Input voltage (V)	AC 3PH 520V (-15%)–690V (+10%) rated voltage: 660V	
Power input	Input current (A)	Refer to Rated value	
	Input frequency (Hz)	50Hz or 60Hz, allowable range: 47–63Hz	
	Output voltage (V)	0-input voltage	
Power	Output current (A)	Refer to Rated value	
output	Output power (kW)	Refer to Rated value	
	Output frequency (Hz)	0–400Hz	
	Control mode	SVPWM control, SVC, VC	
		Asynchronous motor, permanent-magnet synchronous	
	Motor type	motor	
	0	Asynchronous motor 1: 200 (SVC); Synchronous motor 1:	
	Speed regulation ratio	20 (SVC) , 1:1000 (VC)	
	Speed control precision	±0.2% (SVC), ±0.02% (VC)	
Technical	Speed fluctuation	± 0.3% (SVC)	
control	Torque response	<20ms SVC) , <10ms (VC)	
performance	Torque control precision	10% (SVC), 5% (VC)	
		Asynchronous motor: 0.25Hz/150% (SVC)	
	Starting torque	Synchronous motor: 2.5 Hz/150% (SVC)	
		0Hz/200% (VC)	
		150% of rated current: 1min;	
	Overload capacity	180% of rated current: 10s;	
		200% of rated current: 1s;	
		Digital, analog, pulse frequency, multi-step speed	
		running, simple PLC, PID, MODBUS communication,	
	Frequency setup mode	PROFIBUS communication, etc;	
		Realize switch-over between the set combination and the	
		set channel	
Running	Automatic voltage	Keep the output voltage constant when grid voltage	
control	regulation function	changes	
performance		Fault protection function	
portormando	Fault protection function	Provide over 30 kinds of fault protection functions:	
	. dan protostion ranous.	overcurrent, overvoltage, undervoltage,	
		over-temperature, phase loss and overload, etc	
	Speed tracking restart	Realize impact-free starting of the motor in rotating	
	function	Note: This function is available for 4kW and above	
	models		
Peripheral	Terminal analog input	No more than 20mV	

Func	tion description	Specification
interface	resolution	
	Terminal digital input resolution	No more than 2ms
	Analog input	2 inputs, AI1: 0-10V/0-20mA; AI2: -10-10V
	Analog output	1 output, AO1: 0–10V /0–20mA
	Digital input	Four regular inputs; max. frequency: 1kHz; internal impedance: $3.3k\Omega$ Two high-speed inputs; max. frequency: 50kHz; supports quadrature encoder input; with speed measurement function
	Digital output	One high-speed pulse output; max. frequency: 50kHz One Y terminal open collector output
	Relay output	Two programmable relay outputs RO1A NO, RO1B NC, RO1C common port RO2A NO, RO2B NC, RO2C common port Contact capacity: 3A/AC250V, 1A/DC30V
	Extension interface	Three extension interfaces: SLOT1, SLOT2, SLOT3 Expandable PG card, programmable extension card, communication card, I/O card, etc
	Installation mode	Support wall-mounting, floor-mounting and flange-mounting
	Temperature of running	-10-50°C, derating is required if the ambient temperature
	environment	exceeds 40°C
	Protection level	IP20
	Pollution level	Level 2
Others	Cooling mode	Air cooling
Ouicis	Brake unit	Built-in brake unit for 380V 37kW and below models; Optional built-in brake unit for 380V 45kW-110kW (inclusive) models; Optional external brake unit for 660V models;
380V models fulfill the requirement		380V models fulfill the requirements of IEC61800-3 C3 Optional external filter should meet the requirements of IEC61800-3 C2

3.4 Product nameplate




Fig 3.5 Product nameplate

Note:

- This is an example of the nameplate of standard Goodrive350 products. The CE/TUV/IP20
 marking on the top right will be marked according to actual certification conditions.
- 2. Scan the QR code on the bottom right to download mobile APP and operation manual.

3.5 Type designation key

The type designation key contains product information. Users can find the type designation key on the nameplate and simple nameplate of the inverter.




Fig 3.6 Type designation key

Field	Sign	Description	Contents
Abbreviation of product series	1)	Abbreviation of product series	GD350: Goodrive350 high-performance multi-function inverter
Rated power	2	Power range + load type	5R5-5.5kW G—Constant torque load
Voltage level	3	Voltage level	4: AC 3PH 380V (-15%)–440V (+10%) Rated voltage: 380V 6: AC 3PH 520V (-15%)–690V (+10%) Rated voltage: 660V

Note:

Built-in brake unit is included in standard configuration of 380V 37kW and below models; Brake unit is not included in standard configuration of 380V 45–110kW models (optional built-in brake unit is available, suffix "-B" indicates optional built-in brake unit, eg GD350-045G-4-B)

3.6 Rated value

3.6.1 AC 3PH 380V(-15%)-440V(+10%) rated value

Product model	Output power (kW)	Input current (A)	Output current (A)
GD350-1R5G-4	1.5	5.0	3.7

Product model	Output power (kW)	Input current (A)	Output current (A)
GD350-2R2G-4	2.2	5.8	5
GD350-004G-4	4	13.5	9.5
GD350-5R5G-4	5.5	19.5	14
GD350-7R5G-4	7.5	25	18.5
GD350-011G-4	11	32	25
GD350-015G-4	15	40	32
GD350-018G-4	18.5	47	38
GD350-022G-4	22	51	45
GD350-030G-4	30	70	60
GD350-037G-4	37	80	75
GD350-045G-4	45	98	92
GD350-055G-4	55	128	115
GD350-075G-4	75	139	150
GD350-090G-4	90	168	180
GD350-110G-4	110	201	215
GD350-132G-4	132	265	260
GD350-160G-4	160	310	305
GD350-185G-4	185	345	340
GD350-200G-4	200	385	380
GD350-220G-4	220	430	425
GD350-250G-4	250	460	480
GD350-280G-4	280	500	530
GD350-315G-4	315	580	600
GD350-355G-4	355	625	650
GD350-400G-4	400	715	720
GD350-450G-4	450	840	820
GD350-500G-4	500	890	860

- The input current of 1.5–500kW inverter is measured in cases where the input voltage is 380V without additional reactors;
- 2. The rated output current is the output current when the output voltage is 380V;
- Within allowable input voltage range, the output current/power cannot exceed rated output current/power.

3.6.2 AC 3PH 520V (-15%)-690V (+10%) rated value

Product model	Output power (kW)	Input current (A)	Output current (A)
GD350-022G-6	22	35	27
GD350-030G-6	30	40	34
GD350-037G-6	37	47	42

Product model	Output power (kW)	Input current (A)	Output current (A)
GD350-045G-6	45	52	54
GD350-055G-6	55	65	62
GD350-075G-6	75	85	86
GD350-090G-6	90	95	95
GD350-110G-6	110	118	131
GD350-132G-6	132	145	147
GD350-160G-6	160	165	163
GD350-185G-6	185	190	198
GD350-200G-6	200	210	216
GD350-220G-6	220	230	240
GD350-250G-6	250	255	274
GD350-280G-6	280	286	300
GD350-315G-6	315	334	328
GD350-355G-6	355	360	380
GD350-400G-6	400	411	426
GD350-450G-6	450	445	465
GD350-500G-6	500	518	540
GD350-560G-6	560	578	600
GD350-630G-6	630	655	680

- The input current of 22–350kW inverter is measured in cases where the input voltage is 660V without DC reactors and input/output reactors;
- The input current of 400–630kW inverter is measured in cases where the input voltage is 660V and there is input reactor;
- 3. Rated output current is the output current when the output voltage is 660V.
- Within allowable input voltage range, the output current/power cannot exceed rated output current/power.

3.7 Structure diagram

The inverter layout is shown in the figure below (take a 380V 30kW inverter as an example).





Fig 3.7 Structure diagram

No.	Name	Instruction
1	Upper cover	Protect internal components and parts
2	Keypad	See details at chapter 5.4 Keypad operation
3	Lower cover	Protect internal components and parts
4	Extension card	Optional, see details at Appendix A Extension cards
5	Baffle of control board	Protect the control board and install extension card
6	Cooling fan	See details at chapter 9 Maintenance and hardware fault diagnosis
7	Keypad interface	Connect the keypad
8	Nameplate	See details at chapter 3.4 Product nameplate
9	Control terminals	See details at chapter 4 Installation guide
10	Cover plate of heat emission hole	Optional. Cover plate can upgrade protection level, however, as it will also increase internal temperature, derated use is required.
11	Main circuit terminal	See details at chapter 4 Installation guide
12	POWER indicator	Power indicator
13	Label of GD350 product series	See details at Type designation key of this chapter

Chapter 4 Installation guide

4.1 What this chapter contains

This chapter introduces the mechanical and electrical installations of the inverter.





- Ensure the inverter power is disconnected before installation. If the inverter has been powered on, disconnect the inverter and wait for at least the time designated on the inverter, and ensure the POWER indicator is off. Users are recommended to use a multimeter to check and ensure the inverter DC bus voltage is below 36V.
- Installation must be designed and done according to applicable local laws and regulations. INVT does not assume any liability whatsoever for any installation which breaches local laws and regulations. If recommendations given by INVT are not followed, the inverter may experience problems that the warranty does not cover.

4.2 Mechanical installation

4.2.1 Installation environment

Installation environment is essential for the inverter to operate at its best in the long run. The installation environment of the inverter should meet the following requirements.

Environment	Condition
Installation	Indoors
site	Illuools
	→ -10—+50°C;
	♦ When the ambient temperature exceeds 40°C, derate 1% for every
	additional 1°C;
	♦ It is not recommended to use the inverter when the ambient temperature
	is above 50°C;
	♦ In order to improve reliability, do not use the inverter in cases where the
Ambient	temperature changes rapidly;
temperature	♦ When the inverter is used in a closed space eg control cabinet, use
	cooling fan or air conditioner to prevent internal temperature from
	exceeding the temperature required;
	♦ When the temperature is too low, if restart an inverter which has been
	idled for a long time, it is required to install external heating device before
	use to eliminate the freeze inside the inverter, failing to do so may cause
	damage to the inverter.
Humidity	♦ The relative humidity (RH) of the air is less than 90%;

Environment	Condition
	♦ Condensation is not allowed;
	♦ The max RH cannot exceed 60% in the environment where there are
	corrosive gases.
Storage	-30—+60°C
temperature	-50-100 0
	The installation site should meet the following requirements.
	Away from electromagnetic radiation sources;
	→ Away from oil mist, corrosive gases and combustible gases;
	♦ Ensure foreign object like metal powder, dust, oil and water will not fall
Running	into the inverter (do not install the inverter onto combustible object like
environment	wood);
	Away from radioactive substance and combustible objects;
	♦ Away from harmful gases and liquids;
	♦ Low salt content;
	♦ No direct sunlight
	♦ Below 1000m;
	♦ When the altitude exceeds 1000m, derate 1% for every additional 100m;
Altitude	♦ When the altitude exceeds 2000m, configure isolation transformer on the
	input end of the inverter. It is recommended to keep the altitude below
	5000m.
Vibration	The max. amplitude of vibration should not exceed 5.8m/s² (0.6g)
Installation direction	Install the inverter vertically to ensure good heat dissipation effect

- GD350 series inverter should be installed in a clean and well-ventilated environment based on the IP level.
- 2. The cooling air must be clean enough and free from corrosive gases and conductive dust.

4.2.2 Installation direction

The inverter can be installed on the wall or in a cabinet.

The inverter must be installed vertically. Check the installation position according to following requirements. See appendix C *Dimension drawings* for detailed outline dimensions.




Fig 4.1 Installation direction of the inverter

4.2.3 Installation mode

There are three kinds of installation modes based on different inverter dimensions.

- Wall-mounting: suitable for 380V 315kW and below inverters, and 660V 355kW and below inverters:
- Flange-mounting: suitable for 380V 200kW and below inverters, and 660V 220kW and below inverters:
- 3. Floor-mounting: suitable for 380V 220-500kW inverters, and 660V 250-630kW inverters.





Fig 4.2 Installation mode

- (1) Mark the position of the installation hole. See appendix for the position of installation hole;
- (2) Mount the screws or bolts onto the designated position;
- (3) Put the inverter on the wall;
- (4) Tighten the fixing screws on the wall.

Note:

- Flange-mounting plate is a must for 380V 1.5–75kW inverters that adopt flange-mounting mode; while 380V 90–200kW and 660V 22–220kW models need no flange-mounting plate.
- Optional installation base is available for 380V 220–315kW and 660V 250–355kW inverters.
 The base can hold an input AC reactor (or DC reactor) and an output AC reactor.

4.2.4 Single-unit installation







Fig 4.3 Single-unit installation

Note: The min. dimension of B and C is 100mm.

4.2.5 Multiple-unit installation






Fig 4.4 Parallel installation

Note:

- When users install inverters in different sizes, align the top of each inverter before installation for the convenience of future maintenance.
- 2. The min. dimension of B, D and C is 100mm.

4.2.6 Vertical installation




Fig 4.5 Vertical installation

Note: During vertical installation, users must install windshield, otherwise, the inverter will experience mutual interference, and the heat dissipation effect will be degraded.

4.2.7 Tilted installation




Fig 4.6 Tilted installation

Note: During tilted installation, it is a must to ensure the air inlet duct and air outlet duct are separated from each other to avoid mutual interference.

4.3 Standard wiring of main circuit

4.3.1 Wiring diagram of main circuit

4.3.1.1 AC 3PH 380V(-15%)-440V(+10%) main circuit wiring diagram




Fig 4.7 Main circuit wiring diagram for AC 3PH 380V(-15%)-440V(+10%)

Note:

- The fuse, DC reactor, brake unit, brake resistor, input reactor, input filter, output reactor and output filter are optional parts. See Appendix D Optional peripheral accessories for details.
- 2. P1 and (+) have been short connected by default for 380V 132kW and above inverters. If users need to connect to external DC reactor, take off the short-contact tag of P1 and (+).
- When connecting the brake resistor, take off the yellow warning sign marked with PB, (+) and (-)
 on the terminal block before connecting the brake resistor wire, otherwise, poor contact may
 occur.
- 4. Built-in brake unit is optional for 380V 45kW-110kW models.

4.3.1.2 AC 3PH 520V(-15%)-690V(+10%) main circuit wiring diagram





Fig 4.8 660V main circuit wiring diagram

Note:

- The fuse, DC reactor, brake resistor, input reactor, input filter, output reactor and output filter are optional parts. See Appendix D Optional peripheral accessories for details.
- 2. P1 and (+) have been short connected by default. If users need to connect to external DC reactor, take off the short-contact tag of P1 and (+).
- When connecting the brake resistor, take off the yellow warning sign marked with (+) and (-) on the terminal block before connecting the brake resistor wire, otherwise, poor contact may occur.

4.3.2 Main circuit terminal diagram






Fig 4.10 3PH 380V 30-37kW




Fig 4.11 3PH 380V 45-110kW




Fig 4.12 660V 22-45kW




Fig 4.13 660V 55-132kW




Fig 4.14 380V 132-200kW and 660V 160-220kW




Fig 4.15 380V 220-315kW and 660V 250-355kW




Fig 4.16 380V 355-500kW and 660V 400-630kW

		Terminal name		
Terminal sign	380V 37kW and	380V 45-110kW	380V 132kW and above	Function description
	below	(inclusive)	660V	
R, S, T	Ms	Main circuit naver input		3PH AC input terminal, connect
11, 0, 1	IVIE	Main circuit power input		to the grid
U, V, W		Inverter output		3PH AC output terminal,
U, V, VV				connect to the motor
P1	Null	Null	DC reactor terminal 1	P1 and (+) connect to external
()	Brake resistor	Brake unit	DC reactor terminal 2,	DC reactor terminal
(+)	terminal 1	terminal 1	Brake unit terminal 1	(+) and (-) connect to external
(-)	/	Brake unit terminal 2		brake unit terminal
	Dualis assistan		NIII	PB and (+) connect to external
PB	Brake resistor		Null	brake resistor terminal

		Terminal name		
Terminal sign	380V 37kW and below	380V 45-110kW (inclusive)	380V 132kW and above 660V	Function description
	terminal 2			
PE	Grounding	g resistor is le	ss than 10 ohm	Grounding terminal for safe protection; each machine must carry two PE terminals and proper grounding is required

- Do not use asymmetrical motor cable. If there is a symmetrical grounding conductor in the motor cable besides the conductive shielded layer, ground the grounding conductor on the inverter end and motor end.
- 2. Brake resistor, brake unit and DC reactor are optional parts.
- 3. Route the motor cable, input power cable and control cables separately.
- 4. "Null" means this terminal is not for external connection.

4.3.3 Wiring process of the main circuit terminals

- Connect the grounding line of the input power cable to the grounding terminal (PE) of the inverter, and connect the 3PH input cable to R, S and T terminals and tighten up.
- 2. Connect the grounding line of the motor cable to the grounding terminal of the inverter, and connect 3PH motor cable to U, V and W terminals and tighten up.
- 3. Connect the brake resistor which carries cables to the designated position.
- 4. Fix all the cables outside the inverter mechanically if allowed.




Fig 4.17 Screw installation diagram

4.4 Standard wiring of control circuit

4.4.1 Wiring diagram of basic control circuit




Fig 4.18 Wiring diagram of control circuit

Terminal name	Instruction		
+10V	The inverter provides +10.5V power		
Al1	Input range: Al1 voltage/current can choose 0–10/ 0–20mA;		
Al2	 Al2: -10V—+10V voltage; Input impedance: 20kΩ during voltage input; 250Ω during current input; Al1 voltage or current input is set by P05.50; Resolution ratio: When 10V corresponds to 50Hz, the min. resolution ratio is 5mV; 25°C, When input above 5V or 10mA, the error is ±0.5% 		
GND	+10.5V reference zero potential		

Terminal name	Instruction		
	1. Output range: 0–10V voltage or 0–20mA current		
AO1	Voltage or current output is set by toggle switch SW2;		
	3. 25°C, when input above 5V or 10mA, the error is ±0.5%.		
RO1A	RO1 relay output; RO1A is NO, RO1B is NC, RO1C is common port		
RO1B	Contact capacity: 3A/AC250V, 1A/DC30V		
RO1C			
RO2A	RO2 relay output; RO2A is NO, RO2B is NC, RO2C is common port		
RO2B	Contact capacity: 3A/AC250V, 1A/DC30V		
RO2C	Contact capacity. Critical contact		
	1. Switch capacity: 200mA/30V;		
HDO	2. Range of output frequency: 0–50kHz		
	3. Duty ratio: 50%		
COM	Common port of +24V		
CME	Common port of open collector output; short connected to COM by default		
Y1	1. Switch capacity: 200mA/30V;		
'''	2. Range of output frequency: 0–1kHz		
485+	485 communication port, 485 differential signal port and standard 4	185	
485-	communication interface should use twisted shielded pair; the 120ohm terminal		
PE	matching resistor of 485 communication is connected by toggle switch SW3. Grounding terminal		
- '-	Provide input digital working power from external to internal;		
PW	Voltage range: 12–24V		
24V	The inverter provides user power; the maximum output current is 200mA		
СОМ	Common port of +24V		
S1	Digital input 1 1. Internal impedance: 3.3kΩ		
S2	Digital input 2 2. Accept 12–30V voltage input		
S3	Digital input 3 3. This terminal is bi-directional input terminal and suppo	orts	
	NPN/PNP connection modes		
0.4	4. Max. input frequency: 1kHz		
S4	Digital input 4 5. All are programmable digital input terminals, users can set t	the	
	terminal function via function codes		
HDIA	Besides S1–S4 functions, it can also act as high frequency pulse input channel		
	Max. input frequency: 50kHz;		
HDIB	Duty ratio: 30%–70%;		
	Supports quadrature encoder input; equipped with speed-measurement function		
+24V—H1	STO input 1 1. Safe torque off (STO) redundant input, connect to external N	NC	
+24V—H2	STO input 2 contact, STO acts when the contact opens, and the inver	ter	
727V—112	stops output;		

Terminal name	Instruction
	2. Safety input signal wires use shielded wire whose length is
	within 25m;
	3. H1 and H2 terminals are short connected to +24V by default;
	it is required to remove the short-contact tag on the terminal before
	using STO function.

4.4.2 Input/output signal connection diagram

Set NPN /PNP mode and internal/external power via U-type short-contact tag. NPN internal mode is adopted by default.




Fig 4.19 Position of U-type short-contact tag

Note: As shown in Fig 4.19, the USB port can be used to upgrade the software, and the keypad port can be used to connect an external keypad. The external keypad cannot be used when the keypad of the inverter is used.

If input signal comes from NPN transistors, set the U-type short-contact tag between +24V and PW based on the power used according to the figure below.




Fig 4.20 NPN mode

If input signal comes from PNP transistor, set the U-type short-contact tag based on the power used

according to the figure below.




Fig 4.21 PNP mode

4.5 Wiring protection

4.5.1 Protect the inverter and input power cable in short-circuit

Protect the inverter and input power cable during short-circuit to avoid thermal overload.

Carry out protective measures according to the following requirements.




Fig 4.22 Fuse configuration

Note: Select the fuse according to operation manual. During short-circuit, the fuse will protect input power cables to avoid damage to the inverter; when internal short-circuit occurred to the inverter, it can protect neighboring equipment from being damaged.

4.5.2 Protect the motor and motor cable in short circuit

If the motor cable is selected based on rated inverter current, the inverter will be able to protect the motor cable and motor during short circuit without other protective devices.



If the inverter is connected to multiple motors, it is a must to use a separated thermal overload switch or breaker to protect the cable and motor, which may require the fuse to cut off the short circuit current.

4.5.3 Protect motor and prevent thermal overload

According to the requirements, the motor must be protected to prevent thermal overload. Once overload is detected, users must cut off the current. The inverter is equipped with motor thermal overload protection function, which will block output and cut off the current (if necessary) to protect

the motor.

4.5.4 Bypass connection

In some critical occasions, industrial frequency conversion circuit is necessary to ensure proper operation of the system when inverter fault occurs.

In some special cases, eg, only soft startup is needed, it will converts to power-frequency operation directly after soft startup, corresponding bypass link is also needed.



♦ Do not connect any power source to inverter output terminals U, V and W. The voltage applied to motor cable may cause permanent damage to the inverter.

If frequent switch-over is needed, users can use the switch which carries mechanical interlock or a contactor to ensure motor terminals will not be connected to input power cables and inverter output ends simultaneously.

Chapter 5 Basic operation instructions

5.1 What this chapter contains

This chapter tells users how to use the inverter keypad and the commissioning procedures for common functions of the inverter.

5.2 Keypad introduction

LCD keypad is included in the standard configuration of GD350 series inverter. Users can control the inverter start/stop, read state data and set parameters via keypad.



Fig 5.1 Keypad diagram

Note:

- LCD keypad is armed with real-time clock, which can run properly after power off when installed with batteries. The clock battery (type: CR2032) should be purchased by the user separately;
- 2. LCD keypad support parameter-copy;
- 3. When extending the keypad cable to install the keypad, M3 screws can be used to fix the keypad onto the door plate, or optional keypad installation bracket can be used. If you need install the keypad on another position rather than on the inverter, use a keypad extension cable with a standard RJ45 crystal head.

4.	No.	Name		Instruction				
					Running indicator; LED off – the inverter is stopped;			
	1	State Indicator	(1)	RUN	LED off – the inverter is stopped, LED blinking – the inverter is in parameter autotune LED on – the inverter is running			

4. No.	Name			Ins	truction
		2)	TRIP QUICK/JOG		Fault indicator; LED on – in fault state LED off – in normal state LED blinking – in pre-alarm state
		(3)			Short-cut key indicator, which displays different state under different functions, see definition of QUICK/JOG key for details
		(4)			The function of function key varies with
		(5)		Function key	the menu; The function of function key is displayed
		(6)	•		in the footer
2	Button area	(7)	QUICK	Short-cut key	Re-definable. It is defined as JOG function by default, namely jogging. The function of short-cut key can be set by the ones of P07.12, as shown below. 0: No function; 1: Jogging (linkage indicator (3); logic: NO); 2: Reserved; 3: FWD/REV switch-over (linkage indicator (3); logic: NC); 4: Clear UP/DOWN setting (linkage indicator (3) logic: NC); 5: Coast to stop (linkage indicator (3); logic: NC); 6: Switching running command reference mode in order (linkage indicator (3); logic: NC); 7: Reserved; Note: After restoring to default values, the default function of short-cut key (7) is 1.
		(8)	Enter	Confirmation key	The function of confirmation key varies with menus, eg confirming parameter setup, confirming parameter selection, entering the next menu, etc.

4. No.	Name			Ins	truction
		(9)	RUN 🔷	Running key	Under keypad operation mode, the running key is used for running operation or autotuning operation.
		(10)	STOP RST	Stop/ Reset key	During running state, press the Stop/Reset key can stop running or autotuning; this key is limited by P07.04. During fault alarm state, all the control modes can be reset by this key.
		(11)	^ >	Direction key UP: DOWN: LEFT: RIGHT:	UP: The function of UP key varies with interfaces, eg shifting up the displayed item, shifting up the selected item, changing digits, etc; DOWN: The function of DOWN key varies with interfaces, eg shifting down the displayed item, shifting down the selected item, changing digits, etc; LEFT: The function of LEFT key varies with interfaces, eg switch over the monitoring interface, eg shifting the cursor leftward, exiting current menu and returning to previous menu, etc; RIGHT: The function of RIGHT key varies with interfaces, eg switch over the monitoring interface, shifting the cursor rightward, enter the next menu etc.
3	Display area	(12)	LCD	Display screen	240×160 dot-matrix LCD; display three monitoring parameters or six sub-menu items simultaneously
		(13)	RJ45 interface	RJ45 interface	RJ45 interface is used to connect to the inverter.
4	Others	(14)	Battery cover	Clock battery cover	Remove this cover when replacing or installing clock battery, and close the cover after battery is installed
		(15)	USB terminal	mini USB terminal	Mini USB terminal is used to connect to the USB flash drive through an adapter.

The LCD has different display areas, which displays different contents under different interfaces. The figure below is the main interface of stop state.




Fig 5.2 Main interface of LCD

Area	Name	Displayed contents
Header A	Real-time display area	Display the real-time; clock battery is not included; the time needs to be reset when powering on the inverter
Header B	Inverter running state display area	Display the running state of the inverter: 1. Display motor rotating direction: "Forward" — Run forward during operation; Reverse — Run reversely during operation; "Forbid" — Reverse running is forbidden; 2. Display inverter running command channel: "Local" — Keypad; "Terminal" — Terminal; "Remote" - Communication 3. Display current running state of the inverter: "Ready" — The inverter is in stop state (no fault); "Run" — The inverter is in running state; "Jog" — The inverter is in jogging state; "Pre-alarm" — the inverter is under pre-alarm state during running; "Fault" — Inverter fault occurred.
Header C	Inverter station no. and model display area	 Display inverter station no.: 01–99, applied in multi-drive applications (reserved function); Inverter model display: "GD350" – current inverter is GD350 series inverter
Display D	The parameter name and function code monitored by the inverter	Display the parameter name and corresponding function code monitored by the inverter; three monitoring parameters can be displayed simultaneously. The monitoring parameter list can be edited by the user
Display E	Parameter value monitored by the inverter	Display the parameter value monitoring by the inverter, the monitoring value will be refreshed in real time
Footer F	Corresponding menu of function key (4), (5) and (6)	Corresponding menu of function key (4), (5) and (6). The corresponding menu of function key (4), (5) and (6) varies with interfaces, and the contents displayed in this area is also different

5.3 Keypad display

The display state of GD350 series keypad is divided into stop parameter display state, running

parameter display stateand fault alarm display state.

5.3.1 Stop parameter display state

When the inverter is in stop state, the keypad displays stop state parameters, and this interface is the main interface during power-up by default. Under stop state, parameters in various states can be displayed. Press or to shift the displayed parameter up or down.




Fig 5.3 Stop parameter display state

Press or to switch between different display styles, including list display style and progress bar display style.




Fig 5.4 Stop parameter display state

The stop display parameter list is defined by the user, and each state variable function code can be added to the stop display parameter list as needed. The state variable which has been added to the stop display parameter list can also be deleted or shifted.

5.3.2 Running parameter display state

After receiving valid running command, the inverter will enter running state, and the keypad displays running state parameter with RUN indicator on the keypad turning on. Under running state, multiple kinds of state parameters can be displayed. Press or to shift up or down.




Fig 5.5 Running parameter display state

Press or to switch between different display styles, including list display style and progress

bar display style.




Fig 5.6 Running parameter display state

Under running state, multiple kinds of state parameters can be displayed. The running display parameter list is defined by the user, and each state variable function code can be added to the running display parameter list as needed. The state variable which has been added to the running display parameter list can also be deleted or shifted.

5.3.3 Fault alarm display state

The inverter enters fault alarm display state once fault signal is detected, and the keypad displays fault code and fault information with TRIP indicator on the keypad turning on. Fault reset operation can be carried out via STOP/RST key, control terminal or communication command.

The fault code will be kept displaying until fault is removed.




Fig 5.7 Fault alarm display state

5.4 Keypad operation

Various operations can be performed on the inverter, including entering/exiting menu, parameter selection, list modification and parameter addition.

5.4.1 Enter/exit menu

Regarding the monitoring menu, the operation relation between enter and exit is shown below.



Fig 5.8 Enter/exit menu diagram 1

Regarding the system menu, the operation relation between enter and exit is shown below.




Fig 5.9 Enter/exit menu diagram 2

The keypad menu setup is shown as below.

First-level	Second-level	Third-level	Fourth-level			
Common	/	1	P00.10:	Set	frequency	via

First-level	Second-level	Third-level	Fourth-level
parameter			keypad
setup			P00.00: Speed control mode
			Pxx.xx : Common parameter
			setup xx
	Quick setup		
	for function	/	Pxx.xx
	code		
		P00: Basic function group	P00.xx
		P07: HMI group	P07.xx
		P08: Enhance function	P08.xx
	Basic	group	1 00.22
	parameter	P11: Protection parameter	P11.xx
	group setup	group	111.22
		P14: Serial communication	P14.xx
		function group	117.22
		P99: Factory function group	P99.xx
		P02: Motor 1 parameter	P02.xx
	Motor parameter group setup	group	1 02.33
		P12: Motor 2 parameter	P12.xx
		group	1 12.00
		P20: Motor 1 encoder group	P20.xx
		P24: Motor 2 encoder group	P24.xx
Parameter		P01: Start/stop control	P01.xx
setup		group	1 01.30
		P03: Motor 1 vector control	P03.xx
		group	1 00.33
		P04: V/F control group	P04.xx
		P09: PID control group	P09.xx
	Control	P10: Simple PLC and	
	parameter	multi-step speed control	P10.xx
	group setup	group	
	g. oup cotup	P13: Synchronous motor	P13.xx
		control parameter group	
		P21: Position control group	P21.xx
		P22: Spindle positioning	P22.xx
		group	
		P23: Motor 2 vector control	P23.xx
		group	
	Terminal	P05: Input terminal group	P05.xx

First-level	Second-level	Third-level	Fourth-level	
	function	P06: Output terminal group	P06.xx	
	group setup	P98: AIAO calibration	DOG	
		function group	P98.xx	
		P15: Communication		
		extension card 1 function	P15.xx	
		group		
		P16: Communication		
		extension card 2 function	P16.xx	
	Optional card	group		
	function	P25: Extension I/O card	P25.xx	
	group setup	input function group	1 23.22	
		P26: Extension I/O card	P26.xx	
		output function group	1 20.24	
		P27: PLC function group	P27.xx	
		P28: Master/slave function	P28.xx	
		group	1 20.22	
		P90: Customized function	P90.xx	
		group 1	1 30.22	
	Default function group setup	P91: Customized function	P91.xx	
		group 2		
		P92: Customized function	P92.xx	
		group 3		
		P93: Customized function	P93.xx	
		group 4		
		P07: HMI group	P07.xx	
		P17: State-check function	P17.xx	
	State	group		
	monitoring	P18: Closed-loop vector	P18.xx	
	3	state check function group	-	
		P19: Extension card state	P19.xx	
State		check function group	-	
monitoring/fault			P07.27: Type of present fault	
record			P07.28: Type of the last fault	
			P07.29: Type of the last but one	
	Fault record	/	fault	
			P07.30: Type of the last but two	
			fault	
			P07.31: Type of the last but three	
			fault	

First-level	Second-level	Third-level	Fourth-level
			P07.32: Type of the last but four
			fault
			P07.33: Running frequency of
			present fault
			P07.34: Ramps frequency of
	Fault state	/	present fault
			P07.xx: xx state of the last but xx
			fault
	Clear fault		
	history	/	Ensure to clear fault history?
			Pxx.xx has modified parameter 1
	Modified	,	Pxx.xx has modified parameter 2
	parameter	/	Pxx.xx has modified parameter
			xx
			Complete parameter rotary
	/		autotuning
Motor			Complete parameter static
parameter		/	autotuning
autotuning			Partial parameter static
			autotuning
			Upload local function parameter
			to keypad
			Download complete keypad
			function parameter
		Operate the storage area 1:	Download key function
		BACKUP01	parameters which are not in
Parameter			motor group
backup/restore	/		Download keypad function
default value	,		parameters which are in motor
			group
		Operate the storage area 2:	
		BACKUP012	
		Operate the storage area 3:	
		BACKUP03	
		Restore function parameter	Ensure to restore function
		to default value	parameters to default value?
			Language selection
System setup	/	/	Time/date
			Backlight brightness regulation

First-level	Second-level	Third-level	Fourth-level	
			Backlight time adjustment	
		Power-on guiding enable		
			Power-on guiding settings	
			Keyboard burning selection	
			Fault time enable	
			Control board burning selection	

5.4.2 List edit

The monitoring items displayed in the parameter list of stop state can be added by users as needed (through the menu of the function code in state check group), and the list can also be edited by users eg "shift up", "shift down" and "delete from the list". The edit function is shown in the interface below.



Fig 5.10 List edit diagram 1

Press key to enter edit interface, select the operation needed, and press key, key or key to confirm the edit operation and return to the previous menu (parameter list), the returned list is the list edited. If key or key is pressed in edit interface withouth selecting edit operation, it will return to the previous menu (parameter list remain unchanged).

Note: For the parameter objects in the list header, shift-up operation will be invalid, and the same principle can be applied to the parameter objects in the list footer; after deleting a certain parameter, the parameter objects under it will be shifted up automatically.

The monitoring items displayed in the parameter list of running state can be added by users as needed (through the menu of the function code in state check group), and the list can also be edited by users eg "shift up", "shift down" and "delete from the list". The edit function is shown in the interface below.




Fig 5.11 List edit diagram 2

The parameter list of common parameter setup can be added, deleted or adjusted by users as needed, including delete, shift-up and shift-down; the addition function can be set in a certain function code of a function group. The edit function is shown in the figure below.



Fig 5.12 List edit diagram 3

5.4.3 Add parameters to the parameter list displayed in stop/running state

In the fourth-level menu of "State monitoring", the parameters in the list can be added to the "parameter displayed in stop state" list or "parameter displayed in running state" list as shown below.




Fig 5.13 Add parameter diagram 1

Press key to enter parameter addition interface, select the operation needed, and press key, key or key to confirm the addition operation. If this parameter is not included in

the "parameter displayed in stop state" list or "parameter displayed in running state" list, the parameter added will be at the end of the list; if the parameter is already in the "parameter displayed in stop state" list or "parameter displayed in running state" list, the addition operation will be invalid. If

key or key is pressed without selecting addition peration in "Addition" interface, it will return to monitoring parameter list menu.

Part of the monitoring parameters in P07 HMI group can be added to the "parameter displayed in stop state" list or "parameter displayed in running state" list; All the parameters in P17, P18 and P19 group can be added to the "parameter displayed in stop state" list or "parameter displayed in running state" list.

Up to 16 monitoring parameters can be added to the "parameter displayed in stop state" list; and up to 32 monitoring parameters can be added to the "parameter displayed in running state" list.

5.4.4 Add parameter to common parameter setup list

In fourth-level menu of "parameter setup" menu, the parameter in the list can be added to the "common parameter setup" list as shown below.




Fig 5.14 Add parameter diagram 2

Add key to enter addition interface, and press key, key or key to confirm the addition operation. If this parameter is not included in the original "common parameter setup" list, the newly-added parameter will be at the end of the list; if this parameter is already in the "common parameter setup" list, the addition operation will be invalid. If key or key is pressed without selecting addition operation, it will return to parameter setup list menu.

All the function code groups under parameter setup sub-menu can be added to "common parameter setup" list. Up to 64 function codes can be added to the "common parameter setup" list.

5.4.5 Parameter selection edit interface

In the fourth-level menu of "parameter setup" menu, press key, key or key to enter parameter selection edit interface. After entering edit interface, current value will be highlighted. Press key and key to edit current parameter value, and the corresponding parameter item of current value will be highlighted automatically. After parameter selection is done, press key or key to save the selected parameter and return to the previous menu. In parameter selection edit interface, press key to maintain the parameter value and return to the previous menu.



Fig 5.15 Parameter selection edit interface


In parameter selection edit interface, the "authority" on the top right indicates whether this parameter is editable or not.

- " \lambda " indicates the set value of this parameter can be modified under current state.
- "x" indicates the set value of this parameter cannot be modified under current state.
- "Current value" indicates the value of current option.

"Default value" indicates the default value of this parameter.

5.4.6 Parameter setup edit interface

In the fourth-level menu in "parameter setup" menu, press



parameter setup edit interface. After entering edit interface, set the parameter from low bit to high bit, and the bit under setting will be highlighted. Press key or key to increase or decrease the parameter value (this operation is valid until the parameter value exceeds the max. value or min.

value); press or to shift the edit bit. After parameters are set, press

key or

to save the set parameters and return to the previous parameter. In parameter setup edit interface,

press to maintain the original parameter value and return to the previous menu.



Fig 5.16 Parameter setup edit interface

In parameter selection edit interface, the "authority" on the top right indicates whether this parameter can be modified or not.

" \(\sigma \)" indicates the set value of this parameter can be modified under current state.

"x" indicates the set value of this parameter cannot be modified under current state.

"Current value" indicates the value saved last time.

"Default value" indicates the default value of this parameter.

5.4.7 State monitoring interface

In the fourth-level menu of "state monitoring/fault record" menu, press



key to enter state monitoring interface. After entering state monitoring interface, the current parameter value will be displayed in real time, this value is the actually detected value which cannot be modified.




Fig 5.17 State monitoring interface

5.4.8 Motor parameter autotuning

In "Motor parameter autotuning" menu, press key, key or key to enter motor parameter autotuning selection interface, however, before entering motor parameter autotuning interface, users must set the motor nameplate parameters correctly. After entering the interface, select motor autotuning type to carry out motor parameter autotuning. In motor parameter autotuning



Fig 5.18 Parameter autotuning operation diagram

After selecting motor autotuning type, enter motor parameter autotuning interface, and press RUN key to start motor parameter autotuning. After autotuning is done, a prompt will pop out indicating autotuning is succeeded, and then it will return to the main interface of stop. During autotuning, users can press STOP/RST key to terminate autotuning; if any fault occur during autotuning, the keypad will pop out a fault interface.





Fig 5.19 Parameter autotuning finished

5.4.9 Parameter backup

In "parameter backup" menu, press key, key or key to enter function parameter backup setting interface and function parameter restoration setup interface to upload/download inverter parameters, or restore inverter parameters to default value. The keypad has three different storage areas for parameter backup, and each storage area can save the parameters of one inverter, namely it can save parameters of three inverter in total.



Fig 5.20 Parameter backup operation diagram

5.4.10 System setup

In "System setup" menu, press key, key or key to enter system setup interface to set keypad language, time/date, backlight brightness, backlight time and restore parameters.

Note: Clock battery is not included, and the keypad time/date needs to be reset after power off. If time-keeping after power off is needed, users should purchase the clock batteries separately.




Fig 5.21 System setup diagram

5.4.11 Power-on guiding settings

The keyboard supports the power-on guiding function, mainly for the first power-on situation, guiding the user to enter the setting menu, and gradually implementing basic functions such as basic parameter setting, direction judgment, mode setting and autotuning. The power-on guiding enable menu guides the user to enable power-on to boot each time. Power-on guiding setup menu guides the user to set step by step according to the functions.

The power-on guide is shown as below.

First	First-level		Second-level		Third-level		/el
Language	0: Simplified Chinese	0: Power- on each guiding time	Whether to enter the power-on	0:Yes	Whether to test	Yes	
	1: English	enable	1: Power on only once	guiding settings?	1:No	rotation direction?	No
					0: Set via keypad	Press the JOG button first. It is	Yes
				P00.06 A frequency command	1: Set via AI1	currently forward, Is it consistent with the expectations?	No
				selection A frequency command selection	2: Set via Al2	P02.00 Type of	0: Asynch ronous motor
					3: Set via Al3	motor 1	1: Synchr onous motor

First-le	evel	Secon	d-level	Thir	d-level	Fourth-level	
			4 10101		4: Set via high-speed pulse HDIA	P02.01 Rated power of asynchronous motor 1	
					5: Set via simple PLC program	P02.02 Rated frequency of asynchronous motor 1	
					6: Set via multi-step speed running	P02.03 Rated speed of asynchronous motor 1	
					7: Set via PID control	P02.04 Rated voltage of asynchronous motor 1	
					8: Set via MODBUS communicatio	P02.05 Rated current of asynchronous motor 1	
					ANopen/Devic eNET	P02.15 Rated	
						P02.16 Rated frequency of synchronous motor 1	
					11: Set via high-speed pulse HDIB	P02.17 Number of pole pairs of synchronous motor 1	
					12: Set via pulse string AB	P02.18 Rated voltage of synchronous motor 1	
				40	13: Set via EtherCat/Profi	P02.19 Rated current of	

First-level	Second-level	Thir	d-level	Fourth-lev	el
			netcommunica		
			tion	motor 1	
			14: Set via	Whether to	
			PLC card	conduct	Yes
		1	15: Reserved	autotuning?	No
				Motor	
				parameter	
		P00.01	0: Keypad	autotuning	
		Running		interface	
		command	1: Terminal		
		channel	2:		
			Communicatio		
			n		
			0: MODBUS		
		P00.02	1: PROFIBUS/		
		Communic	CANopen/Devi		
		ation	cenet		
		running	2: Ethernet		
		command	3:		
		channel	EtherCat/Profi		
		Communic	net		
		ation	4: PLC		
		running	programmable		
		command	card		
		channel	5: Bluetooth		
			card		
		P08.37	0: Disable		
		Enable/disa	energy-consu		
		ble energy-	mption		
		consumptio	1: Enable		
		n brake	energy-consu		
			mption		
		P00.00	0: SVC 0		
		Speed	1: SVC 1		
		control	2: VF control		
		mode	3: VC		
		P01.08	0: Decelerate		
		Stop mode	to stop		
			1: Coast to		

First-level		Secor	nd-level	Thir	d-level	Fourth-lev	rel .
					stop		
				P00.11			
				Acceleratio			
				n time			
				P00.12			
				Deceleratio			
				n time			

5.5 Basic operation instruction

5.5.1 What this section contains


This section introduces the function modules inside the inverter



- ♦ Ensure all the terminals are fixed and tightened firmly.
- Ensure the motor matches with the inverter power.

5.5.2 Common commissioning procedures

The common operation procedures are shown below (take motor 1 as an example).



Note: If fault occurred, rule out the fault cause according to "fault tracking".

The running command channel can be set by terminal commands besides P00.01 and P00.02.

Current running command channel	function (36)	Multi-function terminal function (37) Command switches to terminal	Multi-function terminal function (38) Command switches to communication
Keypad	/	Terminal	Communication
Terminal	Keypad	/	Communication
Communication	Keypad	Terminal	/

Note: "/" means this multi-function terminal is valid under current reference channel.

Related parameter list:

Function code	Name	Detailed parameter description	Default value
P00.00	Speed control mode	0:SVC 0 1:SVC 1 2:SVPWM 3:VC Note: If 0, 1 or 3 is selected, it is required to carry out motor parameter autotuning	2
P00.01	Running command	first. 0: Keypad 1: Terminal	0
	channel	2: Communication 0:MODBUS	-
P00.02	Communication running command channel	1:PROFIBUS/CANopen/Devicenet 2:Ethernet 3:EtherCat/Profinet 4:PLC programmable card 5:Bluetooth card	0
P00.15	Motor parameter autotuning	O: No operation 1: Rotary autotuning; carry out comprehensive motor parameter autotuning; rotary autotuning is used in cases where high control precision is required; 2: Static autotuning 1 (comprehensive autotuning); static autotuning 1 is used in cases where the motor cannot be disconnected from load; 3: Static autotuning 2 (partial autotuning); when current motor is motor 1, only P02.06,	0

Function	Name	Detailed parameter description	Default
code	Name	Detailed parameter description	value
		P02.07 and P02.08 will be autotuned; when	
		current motor is motor 2, only P12.06,	
		P12.07 and P12.08 will be autotuned.	
		0: No operation	
		1: Restore to default value	
		2: Clear fault history	
	Function parameter	Note: After the selected function	
P00.18	restoration	operations are done, this function code	0
	restoration	will be restored to 0 automatically.	
		Restoration to default value will clear the	
		user password, this function should be	
		used with caution.	
D02.00	Time of motor 4	0: Asynchronous motor	0
P02.00	Type of motor 1	1: Synchronous motor	0
D00.04	Rated power of	0.4.0000.01.W	Depend
P02.01	asynchronous motor 1	0.1–3000.0kW	on model
D.O. O.O.	Rated frequency of		50.00 11
P02.02	asynchronous motor 1	0.01Hz–P00.03 (Max. output frequency)	50.00Hz
500.00	Rated speed of	4.00000	Depend
P02.03	asynchronous motor 1	1–36000rpm	on model
	Rated voltage of	0–1200V	Depend
P02.04	asynchronous motor 1		on model
	Rated current of		Depend
P02.05	asynchronous motor 1	0.8–6000.0A	on model
	Rated power of		Depend
P02.15	synchronous motor 1	0.1–3000.0kW	on model
	Rated frequency of		
P02.16	synchronous motor 1	0.01Hz-P00.03 (Max. output frequency)	50.00Hz
	Number of pole pairs of		
P02.17	synchronous motor 1	1–50	2
	Rated voltage of		Depend
P02.18	synchronous motor 1	0–1200V	on model
	Rated current of		Depend
P02.19	synchronous motor 1	0.8–6000.0A	on model
	Function of multi-function	36: Command switches to keypad	
P05.01-	digital input terminal	37: Command switches to terminal	,
P05.06	(S1–S4, HDIA, HDIB)	38: Command switches to communication	,
P07.01	Reserved variables	/	/
F 07.01	IVESELACA AUTUMIES	<i>'</i>	/


Function code	Name	Detailed parameter description	Default value
P07.02	QUICK/JOG key function	Range: 0x00–0x27 Ones: QUICK/JOG key function selection 0: No function 1: Jogging 2: Reserved 3: Switching between forward/reverse rotation 4: Clear UP/DOWN setting 5: Coast to stop 6: Switch running command reference mode by sequence 7: Reserved Tens: Reserved	0x01

5.5.3 Vector control

Asynchronous motors are featured with high order, non-linear, strong coupling and multi-variables, which makes it very difficult to control asynchronous motors during actual application. The vector control theory aims to solve this problem through measuring and controlling the stator current vector of asynchronous motor, and decomposing the stator current vector into exciting current (current component which generates internal magnet field) and torque current (current component which generates torque) based on field orientation principle, and then controlling the amplitude value and phase position of these two components (namely, control the stator current vector of motor) to realize decoupling control of exciting current and torque current, thus achieving high-performance speed regulation of asynchronous motor.

GD350 series inverter carries built-in speed sensor-less vector control algorithm, which can be used to drive the asynchronous motor and permanent-magnet synchronous motor simultaneously. As the core algorithm of vector control is based on accurate motor parameter model, the accuracy of motor parameters will impact the control performance of vector control. It is recommended to input accurate motor parameters and carry out motor parameter autotuning before vector operation.

As vector control algorithm is complicated, users should be cautious of regulation on dedicated function parameters of vector control.



Function code	Name	Detailed parameter description	Default value
		0:SVC 0 1:SVC 1	
		2:SVPWM	
P00.00	Speed control mode	3:VC	2
		Note: If 0, 1 or 3 is selected, it is	
		required to carry out motor parameter	
		autotuning first.	
		0: No operation	
		1: Rotary autotuning; carry out	
		comprehensive motor parameter	
		autotuning; rotary autotuning is used in	
		cases where high control precision is	
		required;	
P00.15	Motor parameter	2: Static autotuning 1 (comprehensive	0
100.13	autotuning	autotuning); static autotuning 1 is used in	U
		cases where the motor cannot be	
		disconnected from load;	
		3: Static autotuning 2 (partial autotuning);	
		when current motor is motor 1, only	
		P02.06, P02.07 and P02.08 will be	
		autotuned; when current motor is motor 2,	

Function			Default
code	Name	Detailed parameter description	value
		only P12.06, P12.07 and P12.08 will be	
		autotuned.	
P02.00	Type of motor 1	0: Asynchronous motor	0
F 02.00	Type of filotor 1	1: Synchronous motor	0
P03.00	Speed loop proportional gain 1	0–200.0	20.0
P03.01	Speed loop integral time 1	0.000-10.000s	0.200s
P03.02	Switching low point frequency	0.00Hz-P03.05	5.00Hz
P03.03	Speed loop proportional gain 2	0–200.0	20.0
P03.04	Speed loop integral time 2	0.000-10.000s	0.200s
P03.05	Switching high point frequency	P03.02–P00.03 (Max. output frequency)	10.00Hz
P03.06	Speed loop output filter	0-8 (corresponds to 0-28/10ms)	0
P03.07	Electromotion slip compensation coefficient of vector control	50%–200%	100%
P03.08	Brake slip compensation coefficient of vector control	50%–200%	100%
P03.09	Current loop proportional coefficient P	0–65535	1000
P03.10	Current loop integral coefficient I	0–65535	1000
P03.11	Torque setup mode selection	1: Set via keypad (P03.12) 2: Set via Al1 (100% corresponds to three times of rated motor current) 3: Set via Al2 (the same as above) 4: Set via Al3 (the same as above) 5: Set via pulse frequency HDIA (the same as above) 6: Set via multi-step torque (the same as above) 7: Set via MODBUS communication (the same as above) 8: Set via PROFIBUS/CANopen/DeviceNet communication (the same as above) 9: Set via Ethernet communication (the	1

Function code	Name	Detailed parameter description	Default value
P03.12 P03.13	Torque set by keypad Torque reference filter time Source of upper limit frequency setup of forward rotation in torque control	same as above) 10: Set via pulse frequency HDIB (the same as above) 11: Set via EtherCat/Profinet communication 12: Set via PLC Note: Set mode 2–12, 100% corresponds to three times of rated motor current. -300.0%–300.0% (rated motor current) 0.000–10.000s 0: Keypad (P03.16) 1: Al1 (100% corresponds to max. frequency) 2: Al2 (the same as above) 3: Al3 (the same as above) 4: Pulse frequency HDIA (the same as above) 5: Multi-step (the same as above) 6: MODBUS communication (the same as above) 7: PROFIBUS /CANopen/ DeviceNet communication (the same as above) 8: Ethernet communication (the same as above) 9: Pulse frequency HDIB (the same as above) 10: EtherCat/Profinet communication 11: PLC 12: Reserved	50.0% 0.010s
		Note: Source 1-11, 100% relative to the max. frequency	
P03.15	Source of upper limit frequency setup of reverse rotation in torque control	0: Keypad (P03.17) 1–11: the same as P03.14	0
P03.16	Keypad limit value of upper limit frequency of forward rotation in torque control	Value range: 0.00 Hz–P00.03 (Max. output	50.00Hz
P03.17	Keypad limit value of upper limit frequency of reverse	frequency)	50.00Hz

Function code	Name	Detailed parameter description	Default value
	rotation in torque control		
P03.18	Source of upper limit setup of the torque when motoring	0: Keypad (P03.20) 1: Al1 (100% relative to three times of motor current) 2: Al2 (the same as above) 3: Al3 (the same as above) 4: Pulse frequency HDIA (the same as above) 5: MODBUS communication (the same as above) 6: PROFIBUS/CANopen/DeviceNet communication (the same as above) 7: Ethernet communication (the same as above) 8: Pulse frequency HDIB (the same as above) 9: EtherCat/Profinet communication 10: PLC 11: Reserved Note: Source 1–10, 100% relative to three times of motor current.	0
P03.19	Source of upper limit setup of brake torque	0: Keypad (P03.21) 1–10: the same as P03.18	0
P03.20	Set upper limit of the torque when motoring via keypad	0.0–300.0% (rated motor current)	180.0%
P03.21	Set upper limit of brake torque via keypad	0.0-300.0 % (rated motor current)	180.0%
P03.22	Flux-weakening coefficient in constant power area	0.1–2.0	0.3
P03.23	Min. flux-weakening point in constant power area	10%–100%	20%
P03.24	Max. voltage limit	0.0–120.0%	100.0%
P03.25	Pre-exciting time	0.000-10.000s	0.300s
P03.32	Torque control enable	0:Disable 1:Enable	0
P03.35	Control optimization setting	Ones place: Reserved 0: Reserved 1: Reserved	0x0000

Function code	Name	Detailed parameter description	Default value
		Tens place: Reserved	
		0: Reserved	
		1: Reserved	
		Hundreds place: ASR integral separation	
		enabling	
		0: Disabled	
		1: Enabled	
		Thousands place: Reserved	
		0: Reserved	
		1: Reserved	
		Range: 0x0000-0x1111	
P03.36	ASR differential gain	0.00-10.00s	0.00s
P03.37	High-frequency ACR	In the closed-loop vector control mode	1000
F03.31	proportional coefficient	(P00.00=3), when the frequency is lower	1000
P03.38	High-frequency ACR	than the ACR high-frequency switching	1000
F 03.30	integral coefficient	threshold (P03.39), the ACR PI parameters	1000
		are P03.09 and P03.10; and when the	
		frequency is higher than the ACR	
		high-frequency switching threshold	
P03.39	ACR high-frequency	(P03.39), the ACR PI parameters are	
	switching threshold	P03.37 and P03.38.	100.0%
	switching threshold	Setting range of P03.37: 0–20000	
		Setting range of P03.38: 0–20000	
		Setting range of P03.39: 0.0-100.0% (in	
		relative to the maximum frequency)	
P17.32	Flux linkage	0.0–200.0%	0.0%

5.5.4 SVPWM control mode


GD350 inverter also carries built-in SVPWM control function. SVPWM mode can be used in cases where mediocre control precision is enough. In cases where an inverter needs to drive multiple motors, it is also recommended to adopt SVPWM control mode.

GD350 inverter provides multiple kinds of V/F curve modes to meet different field needs. Users can select corresponding V/F curve or set the V/F curve as needed.


Suggestions:

- 1. For the load featuring constant moment, eg, conveyor belt which runs in straight line, as the moment should be constant during the whole running process, it is recommended to adopt straight-type V/F curve.
- 2. For the load featuring decreasing moment, eg, fan and water pump, as the relation

between its actual torque and speed is squared or cubed, it is recommended to adopt the V/F curve corresponds to power 1.3, 1.7 or 2.0.



GD350 inverter also provides multi-point V/F curve. Users can alter the V/F curve outputted by inverter through setting the voltage and frequency of the three points in the middle. The whole curve consists of five points starting from (0Hz, 0V) and ending in (fundamental motor frequency, rated motor voltage). During setup, it is required that $0 \le f1 \le f2 \le f3 \le f$ undamental motor frequency, and $0 \le V1 \le V2 \le V3 \le f$ are donor voltage




GD350 inverter provides dedicated function codes for SVPWM control mode. Users can improve the performance of SVPWM through settings.

Torque boost

Torque boost function can effectively compensate for the low-speed torque performance during SVPWM control. Automatic torque boost has been set by default to enable the inverter to adjust the torque boost value based on actual load conditions.

Note:

- (1) Torque boost is effective only under torque boost cut-off frequency;
- (2) If the torque boost is too large, low-frequency vibration or overcurrent may occur to the motor, if such situation occurs, lower the torque boost value.



2. Energy-saving run

During actual running, the inverter can search for the max. efficiency point to keep running in the most efficient state to save energy.

Note:

- (1) This function is generally used in light load or no-load cases.
- (2) This function does for fit in cases where load transient is required.

3. V/F slip compensation gain

SVPWM control belongs to open-loop mode, which will cause motor speed to fluctuate when motor load transients. In cases where strict speed requirement is needed, users can set the slip compensation gain to compensate for the speed variation caused by load fluctuation through internal output adjustment of inverter.

The set range of slip compensation gain is 0–200%, in which 100% corresponds to rated slip frequency.

Note: Rated slip frequency= (rated synchronous speed of motor-rated speed of motor) × number of motor pole pairs/60

4. Oscillation control


Motor oscillation often occurs in SVPWM control in large-power drive applications. To solve this problem, GD350 series inverter sets two function codes to control the oscillation factor, and users can set the corresponding function code based on the occurrence frequency of oscillation.

Note: The larger the set value, the better the control effect, however, if the set value is too large, it may easily lead to too large inverter output current.

5. Asynchonous motor IF control

Generally, the IF control mode is valid for asynchronous motors. It can be used for a synchronous motor only when the frequency of the synchronous motor is extremely low. Therefore, the IF control described in this manual is only involved with asynchronous motors. IF control is implemented by performing closed-loop control on the total output current of the inverter. The output voltage adapts to the current reference, and open-loop control is separately performed over the frequency of the voltage and current.

Customized V/F curve (V/F separation) function:



When selecting customized V/F curve function, users can set the reference channels and acceleration/deceleration time of voltage and frequency respectively, which will form a real-time V/F curve through combination.

Note: This kind of V/F curve separation can be applied in various frequency-conversion power sources, however, users should be cautious of parameter setup as improper setup may damage the machine.

Function code	Name	Detailed parameter description	Default value
5525		0:SVC 0 1:SVC 1	74.40
P00.00	Speed control mode	2:SVPWM 3:VC	2
		Note: If 0, 1 or 3 is selected, it is required to carry out motor parameter autotuning first.	
P00.03	Max. output frequency	P00.04–400.00Hz	50.00Hz
P00.04	Upper limit of running frequency	P00.05–P00.03	50.00Hz
P00.05	Lower limit of running frequency	0.00Hz-P00.04	0.00Hz
P00.11	Acceleration time 1	0.0–3600.0s	Depend on model
P00.12	Deceleration time 1	0.0–3600.0s	Depend on model
P02.00	Type of motor 1	0: Asynchronous motor 1: Synchronous motor	0
P02.02	Rated power of asynchronous motor 1	0.01Hz-P00.03 (Max. output frequency)	50.00Hz
P02.04	Rated voltage of asynchronous motor 1	0–1200V	Depend on model
		0: Straight-type V/F curve 1: Multi-point V/F curve	
P04.00	V/F curve setting of motor 1	2: Torque-down V/F curve (power 1.3) 3: Torque-down V/F curve (power 1.7) 4: Torque-down V/F curve (power 2.0) 5: Customized V/F (V/F separation)	0
P04.01	Torque boost of motor	0.0%: (automatic) 0.1%–10.0%	0.0%
P04.02	Motor 1 torque boost cut-off	0.0%–50.0% (rated frequency of motor 1)	20.0%
P04.03	V/F frequency point 1	0.00Hz–P04.05	0.00Hz

Function code	Name	Detailed parameter description	Default value
	of motor 1		
P04.04	V/F voltage point 1 of motor 1	0.0%–110.0%	0.0%
P04.05	V/F frequency point 2 of motor 1	P04.03– P04.07	0.00Hz
P04.06	V/F voltage point 2 of motor 1	0.0%–110.0%	0.0%
P04.07	V/F frequency point 3 of motor 1	P04.05– P02.02 or P04.05– P02.16	0.00Hz
P04.08	V/F voltage point 3 of motor 1	0.0%–110.0%	0.0%
P04.09	V/F slip compensation gain of motor 1	0.0–200.0%	100.0%
P04.10	Low-frequency oscillation control factor of motor 1	0–100	10
P04.11	High-frequency oscillation control factor of motor 1	0–100	10
P04.12	Oscillation control threshold of motor 1	0.00Hz-P00.03 (Max. output frequency)	30.00Hz
P04.13	V/F curve setup of motor 2	0: Straight V/F curve; 1: Multi-point V/F curve 2: Torque-down V/F curve (1.3 th order) 3: Torque-down V/F curve (1.7 th order) 4: Torque-down V/F curve (2.0 th order) 5: Customize V/F (V/F separation)	0
P04.14	Torque boost of motor 2	0.0%: (automatic) 0.1%–10.0%	0.0%
P04.15	Motor 2 torque boost cut-off	0.0%–50.0% (rated frequency of motor 1)	20.0%
P04.16	V/F frequency point 1 of motor 2	0.00Hz–P04.18	0.00Hz
P04.17	V/F voltage point 1 of motor 2	0.0%–110.0%	0.0%
P04.18	V/F frequency point 2 of motor 2	P04.16– P04.20	0.00Hz
P04.19	V/F voltage point 2 of	0.0%–110.0%	0.0%

Function code	Name	Detailed parameter description	Default value
	motor 2		
P04.20	V/F frequency point 3 of motor 2	P04.18– P02.02 or P04.18– P02.16	0.00Hz
P04.21	V/F voltage point 3 of motor 2	0.0%–110.0%	0.0%
P04.22	V/F slip compensation gain of motor 2	0.0–200.0%	100.0%
P04.23	Low-frequency oscillation control factor of motor 2	0–100	10
P04.24	High-frequency oscillation control factor of motor 2	0–100	10
P04.25	Oscillation control threshold of motor 2	0.00Hz-P00.03 (Max. output frequency)	30.00Hz
P04.26	Energy-saving run	0: No 1: Automatic energy-saving run	0
P04.27	Channel of voltage setup	0: Keypad; output voltage is determined by P04.28 1: Al1 2: Al2 3: Al3 4: HDIA 5: Multi-step 6: PID 7: MODBUS communication 8: PROFIBUS/CANopen communication 9: Ethernet communication 10: HDIB 11: EtherCat/Profinet communication 12: PLC card 13: Reserved	0
P04.28	Set voltage value via keypad	0.0%–100.0% (rated motor voltage)	100.0%
P04.29	Voltage increase time	0.0–3600.0s	5.0s
P04.30	Voltage decrease time	0.0–3600.0s	5.0s
P04.31	Output max. voltage	P04.32–100.0% (rated motor voltage)	100.0%
P04.32	Output min. voltage	0.0%-P04.31 (rated motor voltage)	0.0%


Function code	Name	Detailed parameter description	Default value
	Flux-weakening coefficient in the constant power zone	1.00–1.30	1.00
P04.34	Input current 1 in synchronous motor VF control	When the synchronous motor VF control mode is enabled, this parameter is used to set the reactive current of the motor when the output frequency is lower than the frequency set in P04.36. Setting range: -100.0%—+100.0% (of the rated current of the motor)	20.0%
P04.35	Input current 2 in synchronous motor VF control	When the synchronous motor VF control mode is enabled, this parameter is used to set the reactive current of the motor when the output frequency is higher than the frequency set in P04.36. Setting range: -100.0%—+100.0% (of the rated current of the motor)	10.0%
P04.36	Frequency threshold for input current switching in synchronous motor VF control	When the synchronous motor VF control mode is enabled, this parameter is used to set the frequency threshold for the switching between input current 1 and input current 2. Setting range: 0.00 Hz–P00.03 (Max. output frequency)	50.00Hz
P04.37	Reactive current closed-loop proportional coefficient in synchronous motor VF control	When the synchronous motor VF control mode is enabled, this parameter is used to set the proportional coefficient of the reactive current closed-loop control. Setting range: 0–3000	50
P04.38	Reactive current closed-loop integral time in synchronous motor VF control	When the synchronous motor VF control mode is enabled, this parameter is used to set the integral coefficient of the reactive current closed-loop control. Setting range: 0–3000	30
P04.39	Reactive current closed-loop output limit in synchronous motor VF control	When the synchronous motor VF control mode is enabled, this parameter is used to set the output limit of the reactive current closed-loop control. A greater value indicates a higher reactive	8000

Function code	Name	Detailed parameter description	Default value
		closed-loop compensation voltage and higher output power of the motor. In general, you do not need to modify this parameter. Setting range: 0–16000	
P04.40	Enable/disable IF mode for asynchronous motor 1	0: Disabled 1: Enabled	0
P04.41	Current setting in IF mode for asynchronous motor 1	When IF control is adopted for asynchronous motor 1, this parameter is used to set the output current. The value is a percentage in relative to the rated current of the motor. Setting range: 0.0–200.0%	120.0%
P04.42	Proportional coefficient in IF mode for asynchronous motor 1	When IF control is adopted for asynchronous motor 1, this parameter is used to set the proportional coefficient of the output current closed-loop control. Setting range: 0–5000	650
P04.43	Integral coefficient in IF mode for asynchronous motor 1	When IF control is adopted for asynchronous motor 1, this parameter is used to set the integral coefficient of the output current closed-loop control. Setting range: 0–5000	350
P04.44	Frequency threshold for switching off IF mode for asynchronous motor 1	When IF control is adopted for asynchronous motor 1, this parameter is used to set the frequency threshold for switching off the output current closed-loop control. When the frequency is lower than the value of this parameter, the current closed-loop control in the IF control mode is enabled; and when the frequency is higher than that, the current closed-loop control in the IF control mode is disabled. Setting range: 0.00–20.00 Hz	10.00Hz
P04.45	Enable/disable IF mode for asynchronous motor 2	0: Disabled 1: Enabled	0
P04.46	Current setting in IF mode for asynchronous motor 2	When IF control is adopted for asynchronous motor 2, this parameter is used to set the output current. The value is a percentage in relative to the rated current of the motor. Setting range: 0.0–200.0%	120.0%
P04.47	Proportional	When IF control is adopted for asynchronous motor	650

Function code	Name	Detailed parameter description	Default value
	coefficient in IF mode for asynchronous motor 2	2, this parameter is used to set the proportional coefficient of the output current closed-loop control. Setting range: 0–5000	
P04.48	Integral coefficient in IF mode for asynchronous motor 2	When IF control is adopted for asynchronous motor 2, this parameter is used to set the inetgral coefficient of the output current closed-loop control. Setting range: 0–5000	350
P04.49	for switching off IF mode for	When IF control is adopted for asynchronous motor 2, this parameter is used to set the frequency threshold for switching off the output current closed-loop control. When the frequency is lower than the value of this parameter, the current closed-loop control in the IF control mode is enabled; and when the frequency is higher than that, the current closed-loop control in the IF control mode is disabled. Setting range: 0.00–20.00 Hz	10.00Hz

5.5.5 Torque control

GD350 inverter supports torque control and speed control. Speed control mode aims to stabilize the speed to keep the set speed consistent with the actual running speed, meanwhile, the max. load-carrying capacity is restricted by torque limit. Torque control mode aims to stabilize the torque to keep the set torque consistent with the actual output torque, meanwhile, the output frequency is restricted by upper/lower limit.



Function code	Name	Detailed parameter description	Default value
P00.00	Speed control mode	0:SVC 0 1:SVC 1 2:SVPWM 3:VC Note: If 0, 1 or 3 is selected, it is required to carry out motor parameter autotuning first.	2
P03.32	Torque control enable	0:Disable 1:Enable	0
P03.11	Torque setup mode selection	1:Enable 0: Set via keypad (P03.12) 1: Set via keypad (P03.12) 2: Set via Al1 (100% corresponds to three times of rated motor current) 3: Set via Al2 (the same as above) 4: Set via Al3 (the same as above) 5: Set via pulse frequency HDIA (the same as above) 6: Set via multi-step torque (the same as above) 7: Set via MODBUS communication (the same as above)	
P03.12	Torque set by keypad	-300.0%–300.0% (rated motor current)	50.0%
P03.13	Torque reference filter time	0.000-10.000s	0.010s
P03.14	Source of upper limit frequency setup of forward rotation in torque control	0: Keypad (P03.16) 1: Al1 (100% corresponds to max. frequency) 2: Al2 (the same as above) 3: Al3 (the same as above) 4: Pulse frequency HDIA (the same as above) 5: Multi-step (the same as above)	0

Function code	Name	Detailed parameter description	Default value
Code		6: MODBUS communication (the same as above) 7: PROFIBUS /CANopen/ DeviceNet communication (the same as above) 8: Ethernet communication (the same as above) 9: Pulse frequency HDIB (the same as above) 10: EtherCat/Profinet communication 11: PLC 12: Reserved Note: Source 1-11, 100% relative to the max.	value
P03.15	Source of upper limit frequency setup of reverse rotation in torque control	frequency 0: Keypad (P03.17) 1: Al1 (100% corresponds to max. frequency) 2: Al2 (the same as above) 3: Al3 (the same as above) 4: Pulse frequency HDIA (the same as above) 5: Multi-step (the same as above) 6: MODBUS communication (the same as above) 7: PROFIBUS /CANopen/ DeviceNet communication (the same as above) 8: Ethernet communication (the same as above) 9: Pulse frequency HDIB (the same as above) 10: EtherCat/Profinet communication 11: PLC 12: Reserved Note: Source 1-11, 100% relative to the max. frequency	0
P03.16	Keypad limit value of upper limit frequency of forward rotation in torque control	0.00Hz-P00.03 (Max. output frequency)	50.00 Hz
P03.17	Keypad limit value of upper limit frequency of reverse rotation in torque control	0.00Hz–P00.03 (Max. output frequency)	50.00 Hz
P03.18	Source of upper	0: Keypad (P03.20)	0


Function	Name	Detailed parameter description	Default
code			value
	limit setup of the	1: Al1 (100% relative to three times of motor	
	torque during	current)	
	motoring	2: Al2 (the same as above)	
		3: Al3 (the same as above)	
		4: Pulse frequency HDIA (the same as above)	
		5: MODBUS communication (the same as	
		above)	
		6: PROFIBUS/CANopen/DeviceNet	
		communication (the same as above)	
		7: Ethernet communication (the same as above)	
		8: Pulse frequency HDIB (the same as above)	
		9: EtherCat/Profinet communication	
		10: PLC	
		11: Reserved	
		Note: Source 1–10, 100% relative to three times	
		of motor current.	
		0: Keypad (P03.21)	
		1: Al1 (100% relative to three times of motor	
		current)	
		2: Al2 (the same as above)	
		3: Al3 (the same as above)	
		4: Pulse frequency HDIA (the same as above)	
		5: MODBUS communication (the same as	
	Source of upper	above)	
P03.19	limit setup of brake	6: PROFIBUS/CANopen/DeviceNet	0
	torque	communication (the same as above)	
		7: Ethernet communication (the same as above)	
		8: Pulse frequency HDIB (the same as above)	
		9: EtherCat/Profinet communication	
		10: PLC	
		11: Reserved	
		Note: Source 1–10, 100% relative to three times	
		of motor current.	
P03.20	Set upper limit of		
	the torque when	0.0-300.0% (rated motor current)	180.0%
. 55.25	motoring via	The second (tales meter sunsting)	
	keypad		
P03.21	Set upper limit of	0.0-300.0% (rated motor current)	180.0%
FU3.21	brake torque via	ord occurs, (rated motor editority	100.070

Function code	Name	Detailed parameter description	Default value
	keypad		
P17.09	Motor output torque	-250.0–250.0%	0.0%
P17.15	Torque reference value	-300.0–300.0% (rated motor current)	0.0%

5.5.6 Motor parameter




Check the safety conditions surrounding the motor and load machineries before autotuning as physical injury may occur due to sudden start of motor during autotuning.






If the motor has been connected to load, do not carry out rotary autotuning; otherwise, misact or damage may occur to the inverter. If rotary autotuning is carried out on a motor which has been connected to load, wrong motor parameters and motor misacts may occur. Disconnect the load to carry out autotuning if necessary.

GD350 inverter can drive asynchronous motors and synchronous motors, and it supports two sets of motor parameters, which can be switched over by multi-function digital input terminals or communication modes.



The control performance of the inverter is based on accurate motor model, therefore, users need to carry out motor parameter autotuning before running the motor for the first time (take motor 1 as an example)



Note:

- 1. Motor parameters must be set correctly according to motor nameplate;
- If rotary autotuning is selected during motor autotuning, it is a must to disconnect the motor from load to put the motor in static and no-load state, failed to do so may lead to inaccurate autotuned results. At this time, the asynchronous motor can autotune P02.06–P02.10, and synchronous motor can autotune P02.20–P02.23
- 3. If static autotuning is selected during motor autotuning, there is no need to disconnect the motor

from load, as only part of the motor parameters have been autotuned, the control performance may be impacted, under such situation, the asynchronous motor can autotune P02.06–P02.10, while synchronous motor can autotune P02.20–P02.22, P02.23 (counter-emf constant of synchronous motor 1) can be obtained via calculation.

4. Motor autotuning can be carried out on current motor only, if users need to perform autotuning on the other motor, switch over the motor through selecting the switch-over channel of motor 1 and motor 2 by setting the ones of P08.31.

Function code	Name	Detailed parameter description	Default value
		0: Keypad	
P00.01	Running command channel	1: Terminal	0
		2: Communication	
		0: No operation	
		1: Rotary autotuning; carry out	
		comprehensive motor parameter	
		autotuning; rotary autotuning is used in	
		cases where high control precision is	
		required;	
		2: Static autotuning 1 (comprehensive	
P00.15	Matar navamatar autatunina	autotuning); static autotuning 1 is used in	0
P00.15	Motor parameter autotuning	cases where the motor cannot be	0
		disconnected from load;	
		3: Static autotuning 2 (partial	
		autotuning); when current motor is motor	
		1, only P02.06, P02.07 and P02.08 will	
		be autotuned; when current motor is	
		motor 2, only P12.06, P12.07 and P12.08	
		will be autotuned.	
P02.00	Type of motor 1	0: Asynchronous motor	0
P02.00	Type of motor 1	1: Synchronous motor	U
P02.01	Rated power of	0.1. 2000 01/1/	Depend
P02.01	asynchronous motor 1	0.1–3000.0kW	on model
D00.00	Rated frequency of	0.041 = D00.02 (May autout fraguesia)	50 00LI=
P02.02	asynchronous motor 1	0.01Hz–P00.03 (Max. output frequency)	50.00Hz
D00.05	Rated speed of	4. 20000	Depend
P02.03	asynchronous motor 1	1–36000rpm	on model
P02.04	Rated voltage of	0. 42001/	Depend
	asynchronous motor 1	0–1200V	on model
P02.05	Rated current of	0.8–6000.0A	Depend

Function code	Name	Detailed parameter description	Default value
code	asynchronous motor 1		on model
	Stator resistance of		Depend
P02.06	asynchronous motor 1	$0.001-65.535\Omega$	on model
	Rotor resistance of		Depend
P02.07	asynchronous motor 1	0.001–65.535Ω	on model
	Leakage inductance of		Depend
P02.08	asynchronous motor 1	0.1–6553.5mH	on model
	Mutual inductance of		Depend
P02.09	asynchronous motor 1	0.1–6553.5mH	on model
	No-load current of		Depend
P02.10	asynchronous motor 1	0.1–6553.5A	on model
D00.45	Rated power of synchronous		Depend
P02.15	motor 1	0.1–3000.0kW	on model
P02.16	Rated frequency of	0.01Hz-P00.03 (Max. output frequency)	50.00Hz
1 02.10	synchronous motor 1	0.01112=1 00.03 (Max. Output frequency)	50.00HZ
P02.17	Number of pole pairs of	1–50	2
1 02.17	synchronous motor 1		
P02.18	Rated voltage of	0–1200V	Depend
	synchronous motor 1		on model
P02.19	Rated current of	0.8–6000.0A	Depend
	synchronous motor 1		on model
P02.20	Stator resistance of	0.001–65.535Ω	Depend
	synchronous motor 1		on model
P02.21	Direct-axis inductance of	0.01–655.35mH	Depend
	synchronous motor 1		on model
P02.22	Quadrature-axis inductance	0.01–655.35mH	Depend
	of synchronous motor 1		on model
P02.23	Counter-emf constant of	0–10000	300
	synchronous motor 1		
P05.01-	Function of multi-function digital input terminal (S1–S4,	35: Motor 1 switches to motor 2	/
P05.06	HDIA,HDIB)	33. Motor 1 Switches to motor 2	/
	(טוטויג,ווטווי)	0x00-0x14	
		Ones: Switch-over channel	
	Switching between motor 1	0: Switch over by terminal	
P08.31	and motor 2	1: Switch over by MODBUS	00
	and motor 2	communication	
		2: Switch over by PROFIBUS / CANopen	

Function	Name	Detailed parameter description	Default
code		·	value
		/Devicenet	
		3: Switch over by Ethernet	
		communication	
		4: Switch over by EtherCat/Profinet	
		communication	
		Tens: Motor switch-over during running	
		0: Disable switch-over during running	
		1: Enable switch-over during running	
P12.00	Type of motor 2	0: Asynchronous motor	0
1 12.00	Type of motor 2	1: Synchronous motor	U
P12.01	Rated power of	0.1–3000.0kW	Depend
P12.01	asynchronous motor 2	0.1–3000.0kvv	on model
D40.00	Rated frequency of	0.0411= D00.03 (May, autout fraguesia)	50 00LI=
P12.02	asynchronous motor 2	0.01Hz–P00.03 (Max. output frequency)	50.00Hz
D40.00	Rated speed of	4 00000	
P12.03	asynchronous motor 2	1–36000rpm	
	Rated voltage of		
P12.04	asynchronous motor 2	0–1200V	
	Rated current of	0.8–6000.0A	
P12.05	asynchronous motor 2		
	Stator resistance of		
P12.06	asynchronous motor 2	0.001–65.535Ω	
	Rotor resistance of		Depend
P12.07	asynchronous motor 2	0.001–65.535Ω	on model
	Leakage inductance of		
P12.08	asynchronous motor 2	0.1–6553.5mH	
	Mutual inductance of		
P12.09	asynchronous motor 2	0.1–6553.5mH	
	No-load current of		
P12.10	asynchronous motor 2	0.1–6553.5A	
	,		
P12.15	Rated power of synchronous motor 2	0.1–3000.0kW	
P12.16	Rated frequency of	0.01Hz-P00.03 (Max. output frequency)	50.00Hz
	synchronous motor 2		
P12.17	Number of pole pairs of	1–50	2
	synchronous motor 2		.
P12.18	Rated voltage of	0–1200V	Depend
1 12.10	synchronous motor 2	0-1200 V	on model

Function code	Name	Detailed parameter description	Default value
P12.19	Rated current of	0.8-6000.0A	Depend
	synchronous motor 2		on model
P12.20	Stator resistance of	0.001–65.535Ω	Depend
F 12.20	synchronous motor 2	0.001-05.55522	on model
P12.21	Direct-axis inductance of	0.01–655.35mH	Depend
F 12.21	synchronous motor 2		on model
P12.22	Quadrature-axis inductance	0.01-655.35mH	Depend
P12.22	of synchronous motor 2		on model
P12.23	Counter-emf constant of	0–10000	300
F 12.23	synchronous motor 2	0-10000	300

5.5.7 Start/stop control


The start/stop control of the inverter is divided into three states: start after running command at power-up; start after restart-at-power-cut function is effective; start after automatic fault reset. Descriptions for these three start/stop control states are presented below.

There are three start modes for the inverter, which are start at starting frequency, start after DC brake, and start after speed-tracking. Users can select the proper start mode based on field conditions.


For large-inertia load, especially in cases where reversal may occur, users can choose to start after DC brake or start after speed-racking.

Note: It is recommended to drive synchronous motors in direct start mode.


1. Logic diagram for running command after power-up



2. Logic diagram for restart after power-cut



3. Logic diagram for restart after automatic fault reset



Function code	Name	Detailed parameter description	Default value
		0: Keypad	
P00.01	Running command channel	1: Terminal	0
		2: Communication	
P00.11	Appalaration time 1	0.0.2600.00	Depend
P00.11	Acceleration time 1	0.0–3600.0s	on model
D00.40	Deceleration time 1	0.0–3600.0s	Depend
P00.12			on model
	Running mode of start	0: Direct start	
P01.00		1: Start after DC brake	0
P01.00		2: Start after speed-track 1	
		3: Start after speed-track 2	
P01.01	Starting frequency of direct start	0.00-50.00Hz	0.50Hz
P01.02	Hold time of starting	0.0-50.0s	0.0s

Function code	Name	Detailed parameter description	Default value
	frequency		
P01.03	DC brake current before start	0.0–100.0%	0.0%
P01.04	DC brake time before start	0.00-50.00s	0.00s
P01.05	Acceleration/deceleration mode	0: Straight line 1: S curve Note: If mode 1 is selected, it is required to set P01.07, P01.27 and P01.08 accordingly	0
P01.08	Stop mode	Decelerate to stop Coast to stop	0
P01.09	Starting frequency of DC brake after stop	0.00Hz–P00.03 (Max. output frequency)	0.00Hz
P01.10	Waiting time of DC brake after stop	0.00–50.00s	0.00s
P01.11	DC brake current of stop	0.0–100.0%	0.0%
P01.12	DC brake time of stop	0.00–50.00s	0.00s
P01.13	Deadzone time of forward/reverse rotation	0.0–3600.0s	0.0s
P01.14	Forward/reverse rotation switch-over mode	switch over after zero frequency switch over after starting frequency switch over after passing stop speed and delay	0
P01.15	Stop speed	0.00–100.00Hz	0.50 Hz
P01.16	Stop speed detection mode	O: Set value of speed (the only detection mode valid in SVPWM mode) 1: Detection value of speed	1
P01.18	Power-on terminal running protection selection	Terminal running command is invalid at power up Terminal running command is valid at power up	0
P01.19	Action selection when the running frequency is below lower limit (lower limit should be larger than 0)	O: Run at the lower limit frequency 1: Stop 2: Sleep	0
P01.20	Wake-up-from-sleep delay	0.0-3600.0s (valid when P01.19 is 2)	0.0s
P01.21	Restart after power cut	Restart is disabled Restart is enabled	0

Function code	Name	Detailed parameter description	Default value
P01.22	Waiting time of restart after power cut	0.0–3600.0s (valid when P01.21 is 1)	1.0s
P01.23	Start delay	0.0–60.0s	0.0s
P01.24	Stop speed delay	0.0–100.0s	0.0s
P01.25	Open-loop 0Hz output selection	O: No voltage output 1: With voltage output 2: Output as per DC brake current of stop	0
P01.26	Deceleration time of emergency-stop	0.0-60.0s	2.0s
P01.27	Time of starting section of deceleration S curve	0.0–50.0s	0.1s
P01.28	Time of ending section of deceleration S curve	0.0–50.0s	0.1s
P01.29	Short-circuit brake current	0.0-150.0% (rated inverter current)	0.0%
P01.30	Hold time of short-circuit brake at startup	0.00-50.00s	0.00s
P01.31	Hold time of short-circuit brake at stop	0.00-50.00s	0.00s
P05.01– P05.06	Digital input function selection	1: Forward running 2: Reverse running 4: Forward jogging 5: Reverse jogging 6: Coast to stop 7: Fault reset 8: Running pause 21: Acceleration/deceleration time selection 1 22: Acceleration/deceleration time selection 2 30: Acceleration/deceleration disabled	1
P08.06	Running frequency of jog	0.00Hz-P00.03 (Max. output frequency)	5.00Hz
P08.07	Acceleration time at jogging	0.0–3600.0s	Depend on model
P08.08	Deceleration time at jogging	0.0–3600.0s	Depend on model
P08.00	Acceleration time 2	0.0–3600.0s	Depend on model

Function code	Name	Detailed parameter description	Default value
P08.01	Declaration time 2	0.0–3600.0s	Depend
P06.01	Declaration time 2	0.0–3600.08	on model
P08.02	Acceleration time 3	0.0–3600.0s	Depend
F00.02	Acceleration time 3	0.0–3000.08	on model
P08.03	Declaration time 3	0.0–3600.0s	Depend
F00.03	Deciaration time 3	0.0–3000.08	on model
P08.04	Acceleration time 4	0.0–3600.0s	Depend
F00.04	Acceleration time 4	0.0–3000.08	on model
P08.05	Declaration time 4	0.0–3600.0s	Depend
F00.05	Deciaration time 4	0.0–3000.08	on model
		0.00-P00.03 (Max. output frequency)	
	Switching frequency of	0.00Hz: No switch over	
P08.19	acceleration/deceleration	If the running frequency is larger than	0
	time	P08.19, switch to acceleration	
		/deceleration time 2	
		0: Max. output frequency	
	Reference frequency of	1: Set frequency	
P08.21	acceleration/deceleration	2: 100Hz	0
	time	Note: Valid for straight-line	
		acceleration/deceleration only	
P08.28	Automatic fault reset times	0–10	0
P08.29	Automatic fault reset time interval	0.1–3600.0s	1.0s


5.5.8 Frequency setup

GD350 series inverter supports multiple kinds of frequency reference modes, which can be categorized into two types: main reference channel and auxiliary reference channel.

There are two main reference channels, namely frequency reference channel A and frequency reference channel B. These two channels support simple arithmetical operation between each other, and they can be switched dynamically by setting multi-function terminals.

There is one input mode for auxiliary reference channel, namely terminal UP/DOWN switch input. By setting function codes, users can enable the corresponding reference mode and the impact made on the inverter frequency reference by this reference mode.

The actual reference of inverter is comprised of the main reference channel and auxiliary reference channel.




GD350 inverter supports switch-over between different reference channels, and the rules for channel switch-over are shown below.

Present reference channel	Multi-function terminal function 13 Channel A switches to channel B	Multi-function terminal function 14 Combination setup switches to channel A	Multi-function terminal function 15 Combination setup switches to channel B
Α	В	/	/
В	А	/	/
A+B	/	А	В
A-B	1	А	В

Present reference channel	Multi-function terminal function 13 Channel A switches to channel B	Multi-function terminal function 14 Combination setup switches to channel A	Multi-function terminal function 15 Combination setup switches to channel B
Max (A, B)	/	А	В
Min (A, B)	/	A	В

Note: "/" indicates this multi-function terminal is invalid under present reference channel.

When setting the auxiliary frequency inside the inverter via multi-function terminal UP (10) and DOWN (11), users can increase/decrease the frequency quickly by setting P08.45 (UP terminal frequency incremental change rate) and P08.46 (DOWN terminal frequency decremental change rate).




Function code	Name	Detailed parameter description	Default value
P00.03	Max. output frequency	P00.04–400.00Hz	50.00Hz
P00.04	Upper limit of running frequency	P00.05-P00.03	50.00Hz
P00.05	Lower limit of running frequency	0.00Hz-P00.04	0.00Hz
P00.06	A frequency command	0: Set via keypad	0
	selection	1: Set via Al1 2: Set via Al2 3: Set via Al3	
P00.07	B frequency command selection	4: Set via high speed pulse HDIA 5: Set via simple PLC program 6: Set via multi-step speed running 7: Set via PID control 8: Set via MODBUS communication	15

Function code	Name	Detailed parameter description	Default value
		9: Set via PROFIBUS / CANopen /	
		DeviceNet communication	
		10: Set via Ethernet communication	
		11: Set via high speed pulse HDIB	
		12: Set via pulse string AB	
		13: Set via EtherCat/Profinet	
		communication	
		14: Set via PLC card	
		15: Reserved	
D00.00	Reference object of B	0: Max. output frequency	
P00.08	frequency command	1: A frequency command	0
		0: A	
		1: B	
P00.09	Combination mode of setup	2: (A+B)	0
	source	3: (A-B)	U
		4: Max (A, B)	
		5: Min (A, B)	
		10: Frequency increase (UP)	· · · · · · · · · · · · · · · · · · ·
		11: Frequency decrease (DOWN)	
		12: Clear frequency increase/decrease	
	Function of multi-function	setting	
P05.01-		13: Switch-over between setup A and	,
P05.06	digital input terminal (S1–S4,	setup B	/
	HDIA, HDIB)	14: Switch-over between combination	
		setup and setup A	
		15: Switch-over between combination	
		setup and setup B	
P08.42	Reserved variables	1	/
P08.43	Reserved variables	1	/
		0x000-0x221	
		Ones: Frequency enabling selection	
		0: UP/DOWN terminal setting is valid	
P08.44		1: UP/DOWN terminal setting is invalid	
	UP/DOWN terminal control	Tens: Frequency control selection	0x000
		0: Valid only when P00.06=0 or P00.07=0	
		1: Valid for all frequency modes	
		2: Invalid for multi-step speed when	
		multi-step speed takes priority	

Function code	Name	Detailed parameter description	Default value
		Hundreds: Action selection at stop	
		0: Valid	
		1: Valid during running, clear after stop	
		2: Valid during running, clear after	
		receiving stop command	
P08.45	UP terminal frequency	0.01–50.00 Hz/s	0.50 Hz/s
P08.45	incremental change rate		0.50 HZ/S
P08.46	DOWN terminal frequency	0.01–50.00 Hz/s	0.50 Hz/s
P08.46	decremental change rate	0.01-50.00 HZ/S	0.50 HZ/S
P17.00	Set frequency	0.00Hz-P00.03 (Max. output frequency)	0.00Hz
P17.02	Ramps reference frequency	0.00Hz-P00.03 (Max. output frequency)	0.00Hz
P17.14	Digital adjustment value	0.00Hz-P00.03	0.00Hz

5.5.9 Analog input

GD350 series inverter carries two analog input terminals (Al1 is 0–10V/0–20mA (voltage input or current input can be set by P05.50); Al2 is -10–10V) and two high-speed pulse input terminals. Each input can be filtered separately, and the corresponding reference curve can be set by adjusting the reference corresponds to the max. value and min. value.




Function	Name	Detailed parameter description	Default
code	Name	Detailed parameter description	value
		0x00–0x11	
		Ones: HDIA input type	
		0: HDIA is high-speed pulse input	
P05.00	HDI input type	1: HDIA is digital input	0x00
		Tens: HDIB input type	
		0: HDIB is high-speed pulse input	
		1: HDIB is digital input	
P05.24	Lower limit value of Al1	0.00V-P05.26	0.00V
P05.25	Corresponding setting of	-100.0%—100.0%	0.0%
1 00.20	lower limit of Al1	100.070	0.070
P05.26	Upper limit value of Al1	P05.24–10.00V	10.00V
P05.27	Corresponding setting of	-100.0%–100.0%	100.0%
	upper limit of AI1		
P05.28	Input filter time of AI1	0.000s-10.000s	0.100s
P05.29	Lower limit value of Al2	-10.00V–P05.31	-10.00V
P05.30	Corresponding setting of lower limit of Al2	-100.0%–100.0%	-100.0%
P05.31	Intermediate value 1 of Al2	P05.29–P05.33	0.00V
P05.32	Corresponding setting of	-100.0%–100.0%	0.0%
. 00.02	intermediate value 1 of Al2		0.070
P05.33	Intermediate value 2 of Al2	P05.31–P05.35	0.00V
P05.34	Corresponding setting of intermediate value 2 of Al2	-100.0%–100.0%	0.0%
P05.35	Upper limit value of Al2	P05.33-10.00V	10.00V
P05.36	Corresponding setting of upper limit of Al2	-100.0%—100.0%	100.0%
P05.37	Input filter time of AI2	0.000s-10.000s	0.100s
		0: Set input via frequency	
P05.38	HDIA high-speed pulse input	1: Reserved	0
	function	2: Input via encoder, used in	U
		combination with HDIB	
P05.39	Lower limit frequency of HDIA	0.000 KHz – P05.41	0.000KHz
P05.40	Corresponding setting of lower limit frequency of HDIA	-100.0%—100.0%	0.0%

Function code	Name	Detailed parameter description	Default value
P05.41	Upper limit frequency of HDIA	P05.39 –50.000KHz	50.000KHz
P05.42	Corresponding setting of upper limit frequency of HDIA	-100.0%—100.0%	100.0%
P05.43	HDIA frequency input filter time	0.000s-10.000s	0.030s
P05.44	HDIB high-speed pulse input function selection	O: Set input via frequency I: Reserved C: Input via encoder, used in combination with HDIA O: Set input via frequency O: Set input via frequency O: Set input via frequency O: Set input via frequency	0
P05.45	Lower limit frequency of HDIB	0.000 KHz – P05.47	0.000KHz
P05.46	Corresponding setting of lower limit frequency of HDIB	-100.0%–100.0%	0.0%
P05.47	Upper limit frequency of HDIB	P05.45 –50.000KHz	50.000KHz
P05.48	Corresponding setting of upper limit frequency of HDIB	-100.0%–100.0%	100.0%
P05.49	HDIB frequency input filter time	0.000s-10.000s	0.030s
P05.50	Al1 input signal type	0–10: Voltage type1: Current type	0

5.5.10 Analog output

GD350 series inverter carries one analog output terminal (0–10V/0–20mA) and one high-speed pulse output terminal. Analog output signals can be filtered separately, and the proportional relation can be adjusted by setting the max. value, min. value, and the percentage of their corresponding output. Analog output signal can output motor speed, output frequency, output current, motor torque and motor power at a certain proportion.



Instructions for output:

Set value	Function	Description
0	Running frequency	0-Max. output frequency
1	Set frequency	0-Max. output frequency
2	Ramps reference frequency	0-Max. output frequency
3	Running speed	0-Synchronous speed corresponding to Max. output frequency
4	Output current (relative to inverter)	0–Two times of rated current of inverter
5	Output current (relative to motor)	0-Two times of rated current of motor
6	Output voltage	0–1.5 times of rated voltage of inverter
7	Output power	0-Two times of rated power
8	Set torque value	0-Two times of rated current of motor
9	Output torque	0-Two times of rated current of motor
10	Al1 input value	0–10V/0–20mA
11	Al2 input value	-10V–10V
12	Al3 input value	0–10V/0–20mA
13	Input value of high-speed pulse HDIA	0.00–50.00kHz
14	Set value 1 of MODBUS communication	-1000–1000, 1000 corresponds to 100.0%
15	Set value 2 of MODBUS communication	-1000–1000, 1000 corresponds to 100.0%
16	Set value 1 of	-1000–1000, 1000 corresponds to 100.0%

Set value	Function	Description
	PROFIBUS\CANopen	
	communication	
	Set value 2 of	
17	PROFIBUS\CANopen	-1000–1000, 1000 corresponds to 100.0%
	communication	
18	Set value 1 of Ethernet	-1000–1000, 1000 corresponds to 100.0%
	communication	
19	Set value 2 of Ethernet	-1000–1000, 1000 corresponds to 100.0%
	communication	
20	Input value of high-speed pulse HDIB	0.00–50.00kHz
21	Reserved variable	
	Torque current (bipolar, 100%	0–Two times of rated current of motor
22	corresponds to 10V)	
23	Exciting current (100%	0-One times of rated current of motor
23	corresponds to 10V)	
24	Set frequency (bipolar)	0-Max. output frequency
25	Ramps reference frequency	0-Max. output frequency
23	(bipolar)	
26	Running speed (bipolar)	0-Max. output frequency
	Set value 2 of	-1000–1000, 1000 corresponds to
27	EtherCat/Profinet	100.0%
	communication	100.070
28	C_AO1 from PLC	1000 corresponds to 100.0%
29	C_AO2 from PLC	1000 corresponds to 100.0%
30	Running speed	0-Two times of rated synchronous speed of motor
31–47	Reserved variable	


Function code	Name	Detailed parameter description	Default value
		0: Open collector high-speed pulse	
P06.00	HDO output type	output	0
		1: Open collector output	
P06.14	AO1 output selection	0: Running frequency	0
P06.15	Reserved variable	1: Set frequency	0
500.40		2: Ramps reference frequency	
P06.16	HDO high-speed pulse output	3: Running speed	0

Function	Name	Detailed parameter description	Default
code	Name	Detailed parameter description	value
		4: Output current (relative to inverter)	
		5: Output current (relative to motor)	
		6: Output voltage	
		7: Output power	
		8: Set torque value	
		9: Output torque	
		10: Analog Al1 input value	
		11: Analog Al2input value	
		12: Analog Al3 input value	
		13: Input value of high-speed pulse	
		HDIA	
		14: Set value 1 of MODBUS	
		communication	
		15: Set value 2 of MODBUS	
		communication	
		16: Set value 1 of PROFIBUS\CANopen	
		communication	
		17: Set value 2 of PROFIBUS\CANopen	
		communication	
		18: Set value 1 of Ethernet	
		communication	
		19: Set value 2 of Ethernet	
		communication	
		20: Input value of high-speed pulse	
		HDIB	
		21: Set value 1 of EtherCat/Profinet	
		communication	
		22: Torque current (bipolar, 100%	
		corresponds to 10V)	
		23: Exciting current (100% corresponds	
		to 10V)	
		24: Set frequency (bipolar)	
		25: Ramps reference frequency	
		(bipolar)	
		26: Running speed (bipolar)	
		27: Set value 2 of EtherCat/Profinet	
		communication	
		28: C_AO1 from PLC (You need to set	
		P27.00 to 1.)	

Function code	Name	Detailed parameter description	Default value
		29: C_AO2 from PLC (You need to set	
		P27.00 to 1.)	
		30: Running speed	
		31–47: Reserved variable	
P06.17	Lower limit of AO1 output	-100.0%–P06.19	0.0%
P06.18	Corresponding AO1 output of lower limit	0.00V-10.00V	0.00V
P06.19	Upper limit of AO1 output	P06.17–100.0%	100.0%
P06.20	Corresponding AO1 output of upper limit	0.00V-10.00V	10.00V
P06.21	AO1 output filter time	0.000s-10.000s	0.000s
P06.22-	Decembed veriable	0.05525	0
P06.26	Reserved variable	0–65535	0
P06.27	Lower limit of HDO output	-100.0%–P06.29	0.0%
P06.28	Corresponding HDO output of lower limit	0.00-50.00kHz	0.0kHz
P06.29	Upper limit of HDO output	P06.27–100.0%	100.0%
P06.30	Corresponding HDO output of upper limit	0.00-50.00kHz	50.00kHz
P06.31	HDO output filter time	0.000s-10.000s	0.000s

5.5.11 Digital input

GD350 series inverter carries four programmable digital input terminals and two HDI input terminals. The function of all the digital input terminals can be programmed by function codes. HDI input terminal can be set to act as high-speed pulse input terminal or common digital input terminal; if it is set to act as high-speed pulse input terminal, users can also set HDIA or HDIB high-speed pulse input to serve as the frequency reference and encoder signal input.



This parameter is used to set the corresponding function of digital multi-function input terminals.

Note: Two different multi-function input terminals cannot be set to the same function.

Function	Description
No function	The inverter does not act even if there is signal input; users can set the unused terminals to "no function" to avoid misacts.
Forward running (FWD) Reverse running (REV)	Control the forward/reverse running of the inverter by external terminals.
3-wire control/Sin	Set the inverter running mode to 3-wire control mode by this terminal. See P05.13 for details.
Forward jogging	Frequency when jogging, see P08.06, P08.07 and
Reverse jogging	P08.08 for jogging acceleration/deceleration time.
Coast to stop	The inverter blocks output, and the stop process of motor is uncontrolled by the inverter. This mode is applied in cases of large-inertia load and free stop time; its definition is the same with P01.08, and it is mainly used in remote control.
Fault reset	External fault reset function, its function is the same with the STOP/RST key on the keypad. This function can be used in remote fault reset.
Running pause	The inverter decelerates to stop, however, all the running parameters are in memory state, eg PLC parameter, wobbling frequency, and PID parameter. After this signal disappears, the inverter will revert to the state before stop.
External fault input	When external fault signal is transmitted to the inverter, the inverter releases fault alarm and stops.
Frequency increase (UP)	Used to change the frequency-increase/decrease
Frequency decrease (DOWN)	command when the frequency is given by external terminals.
Clear frequency increase/decrease setting	LANGE TO THE TERMINAL STATES AND
	Forward running (FWD) Reverse running (REV) 3-wire control/Sin Forward jogging Reverse jogging Coast to stop Fault reset Running pause External fault input Frequency increase (UP) Frequency decrease (DOWN) Clear frequency

Set value	Function		Description						
		t	set by UP/DOWN, thus restoring the reference frequence to the frequency given by main reference frequence command channel.						
13	Switching between A setting and B setting		This function is used to switch between the frequency setting channels.						
14	Switching between combination setting and A setting	r	A frequency reference channel and B frequency reference channel can be switched by no. 13 function; the combination channel set by P00.09 and the A						
15	Switching between combination setting and B setting	f	frequency reference channel can be switched by no. 14 function; the combination channel set by P00.09 and the B frequency reference channel can be switched by no. 15 function.						
16	Multi-step speed terminal 1	1	6-step s	peeds	s car	n be set b	y combinin	g digita	l states of
17	Multi-step speed terminal 2		hese fou						
18	Multi-step speed terminal 3		Note: Mu s high bi		ep s	peea 1 is	low bit, mu	uti-ste	o speea 4
19	Multi-step speed terminal 4		Multi-s	tep	S	ulti-step peed 3 BIT2	Multi-step speed 2 BIT1	sp	lti-step eed 1
20	Multi-step speed pause	Pause multi-step speed selection function to keep the set value in present state.							
21	Acceleration/deceleration time selection 1					erminals ation time	to select	four g	groups of
			Terminal 1	Term 2		deceler	eration or ation time ection		sponding
	Acceleration/deceleration		OFF	OF	F		leration/ ation time 1	P00.11	I/P00.12
22	time selection 2		ON	OF	F		leration/ ation time 2	P08.00	D/P08.01
			OFF	OI	N		leration/ ation time 3	P08.02	2/P08.03
			ON	OI	N		leration/ ation time 4	P08.04	1/P08.05
23	Simple PLC stop reset	Restart simple PLC process and clear previous PLC state information.							
24	Simple PLC pause					-	PLC exec step. After		•

Set value	Function	Description
value		cancelled, simple PLC keeps running.
25	PID control pause	PID is ineffective temporarily, and the inverter maintains current frequency output.
26	Wobbling frequency pause (stop at current frequency)	The inverter pauses at current output. After this function is canceled, it continues wobbling-frequency operation at current frequency.
27	Wobbling frequency reset (revert to center frequency)	The set frequency of inverter reverts to center frequency.
28	Counter reset	Zero out the counter state.
29	Switching between speed control and torque control	The inverter switches from torque control mode to speed control mode, or vice versa.
30	Acceleration/deceleration disabled	Ensure the inverter will not be impacted by external signals (except for stop command), and maintains current output frequency.
31	Counter trigger	Enable pulse counting of the counter.
33	Clear frequency increase/decrease setting temporarily	When the terminal is closed, the frequency value set by UP/DOWN can be cleared to restore the reference frequency to the frequency given by frequency command channel; when terminal is disconnected, it will revert to the frequency value after frequency increase/decrease setting.
34	DC brake	The inverter starts DC brake immediately after the command becomes valid.
35	Switching between motor 1 and motor 2	When this terminal is valid, users can realize switch-over control of two motors.
36	Command switches to keypad	When this terminal is valid, the running command channel will switch to keypad compulsorily. If this function becomes invalid, the running command channel will revert to the original state.
37	Command switches to terminal	When this terminal is valid, the running command channel will switch to terminal compulsorily. If this function becomes invalid, the running command channel will revert to the original state.
38	Command switches to communication	When this terminal is valid, the running command channel will switch to communication compulsorily. If this function becomes invalid, the running command channel will revert to the original state.
39	Pre-exciting command	When this terminal is valid, motor pre-exciting will be

Set value	Function	Description
		started until this terminal becomes invalid.
40	Zero out power consumption quantity	After this command becomes valid, the power consumption quantity of the inverter will be zeroed out.
41	Maintain power consumption quantity	When this command is valid, current operation of the inverter will not impact the power consumption quantity.
42	Source of upper torque limit switches to keypad	When this command is valid, the upper limit of the torque will be set by keypad
56	Emergency stop	When this command is valid, the motor decelerate to emergency stop as per the time set by P01.26.
57	Motor over-temperature fault input	Motor stops at motor over-temperature fault input.
59	FVC switches to V/F control	When this terminal is valid in stop state, switch to SVPWM control.
60	Switch to FVC control	When this terminal is valid in stop state, switch to closed-loop vector control.
61	PID polarity switch-over	Switching the output polarity of PID, this terminal should be used in conjunction with P09.03
66	Zero out the counter	Zero out the position counting value
67	Pulse increase	When the terminal function is valid, the pulse input is increased according to the P21.27 pulse speed.
68	Enable pulse superimposition	When the pulse superimposition is enabled, pulse increase and pulse decrease are effective.
69	Pulse decrease	When the terminal function is valid, the pulse input is decreased according to the P21.27 pulse speed.
70	Electronic gear selection	When the terminal is valid, the proportional numerator is switched to the P21.30 numerator of the 2 nd command ratio.
71–79	Reserved variables	/

Function code	Name	Detailed parameter description	Default value
Pos 00		0x00–0x11	
	HDI input type	Ones: HDIA input type	
		0: HDIA is high-speed pulse input	0,,00
P05.00		1: HDIA is digital input	0x00
		Tens: HDIB input type	
		0: HDIB is high-speed pulse input	


Function			Default
code	Name	Detailed parameter description	value
		1: HDIB is digital input	
P05.01	Function of S1 terminal	0: No function	1
P05.02	Function of S2 terminal	1: Forward running	4
P05.03	Function of S3 terminal	2: Reverse running 3: 3-wire control/Sin	7
P05.04	Function of S4 terminal	4: Forward jogging	0
P05.05	Function of HDIA terminal	5: Reverse jogging	0
P05.06	Function of HDIB terminal	6: Coast to stop	0
		7: Fault reset	
		8: Running pause	
		9: External fault input	
		10: Frequency increase (UP)	
		11: Frequency decrease (DOWN)	
		12: Clear frequency	
		increase/decrease setting	
		13: Switch-over between setup A and	
		setup B	
		14: Switch-over between	
		combination setting and A setting	
		15: Switch-over between	
		combination setting and setup B	
		16: Multi-step speed terminal 1	
		17: Multi-step speed terminal 2	
P05.07	Reserved variables	18: Multi-step speed terminal 3	0
		19: Multi-step speed terminal 4	
		20: Multi-step speed pause	
		21: Acceleration/deceleration time	
		selection 1	
		22: Acceleration/deceleration time	
		selection 2	
		23: Simple PLC stop reset	
		24: Simple PLC pause	
		25: PID control pause	
		26: Wobbling frequency pause	
		27: Wobbling frequency reset	
		28: Counter reset	
		29: Switching between speed control	
		and torque control	
		30: Acceleration/deceleration	

Function code	Name	Detailed parameter description	Default value
		disabled	7 0.1.0.0
		31: Counter trigger	
		32: Reserved	
		33: Clear frequency	
		increase/decrease setting	
		temporarily	
		34: DC brake	
		35: Switching between motor 1 and	
		motor 2	
		36: Command switches to keypad	
		37: Command switches to terminal	
		38: Command switches to	
		communication	
		39: Pre-exciting command	
		40: Zero out power consumption	
		quantity	
		41: Maintain power consumption	
		quantity	
		42: Source of upper torque limit	
		switches to keypad	
		56: Emergency stop	
		57: Motor over-temperature fault	
		input	
		59: Switch to V/F control	
		60: Switch to FVC control	
		61: PID polarity switch-over	
		66: Zero out encoder counting	
		67: Pulse increase	
		68: Enable pulse superimposition	
		69: Pulse decrease	
		70: Electronic gear selection	
		71–79: Reserved	
P05.08	Polarity of input terminal	0x00-0x3F	0x00
P05.09	Digital filter time	0.000–1.000s	0.010s
		0x00-0x3F (0: disable, 1: enable)	
DOE 10	Virtual tarminal actting	BIT0: S1 virtual terminal	0x00
P05.10	Virtual terminal setting	BIT1: S2 virtual terminal	
		BIT2: S3 virtual terminal	

Function code	Name	Detailed parameter description	Default value
		BIT3: S4 virtual terminal	
		BIT4: HDIA virtual terminal	
		BIT8: HDIB virtual terminal	
		0: 2-wire control 1	
P05.11	2/3-wire control mode	1: 2-wire control 2	0
1 00.11	2/3-wire control mode	2: 3-wire control 1	O
		3: 3-wire control 2	
P05.12	S1 terminal switch-on delay	0.000–50.000s	0.000s
P05.13	S1 terminal switch-off delay	0.000–50.000s	0.000s
P05.14	S2 terminal switch-on delay	0.000-50.000s	0.000s
P05.15	S2 terminal switch-off delay	0.000-50.000s	0.000s
P05.16	S3 terminal switch-on delay	0.000–50.000s	0.000s
P05.17	S3 terminal switch-off delay	0.000-50.000s	0.000s
P05.18	S4 terminal switch-on delay	0.000-50.000s	0.000s
P05.19	S4 terminal switch-off delay	0.000–50.000s	0.000s
P05.20	HDIA terminal switch-on delay	0.000–50.000s	0.000s
P05.21	HDIA terminal switch-off delay	0.000-50.000s	0.000s
P05.22	HDIB terminal switch-on delay	0.000-50.000s	0.000s
P05.23	HDIB terminal switch-off delay	0.000-50.000s	0.000s
P07.39	Input terminal state of present fault	1	0
P17.12	Digital input terminal state	/	0

5.5.12 Digital output

GD350 series inverter carries two groups of relay output terminals, one open collector Y output terminal and one high-speed pulse output (HDO) terminal. The function of all the digital output terminals can be programmed by function codes, of which the high-speed pulse output terminal HDO can also be set to high-speed pulse output or digital output by function code.



The table below lists the options for the above four function parameters, and users are allowed to select the same output terminal functions repetitively.

Set value	Function	Description
0	Invalid	Output terminal has no function
1	In running	Output ON signal when there is frequency output during running
2	In forward running	Output ON signal when there is frequency output during forward running
3	In reverse running	Output ON signal when there is frequency output during reverse running
4	In jogging	Output ON signal when there is frequency output during jogging
5	Inverter fault	Output ON signal when inverter fault occurred
6	Frequency level detection FDT1	Refer to P08.32 and P08.33
7	Frequency level detection FDT2	Refer to P08.34 and P08.35
8	Frequency reached	Refer to P08.36
9	Running in zero speed	Output ON signal when the inverter output frequency and reference frequency are both zero.
10	Reach upper limit frequency	Output ON signal when the running frequency reaches upper limit frequency
11	Reach lower limit frequency	Output ON signal when the running frequency reached lower limit frequency
12	Ready to run	Main circuit and control circuit powers are established, the protection functions do not act; when the inverter is ready to run, output ON signal.
13	In pre-exciting	Output ON signal during pre-exciting of the inverter
14	Overload pre-alarm	Output ON signal after the pre-alarm time elapsed based

Set	Function	Description
value		
		on the pre-alarm threshold; see P11.08–P11.10 for
		details.
		Output ON signal after the pre-alarm time elapsed based
15	Underload pre-alarm	on the pre-alarm threshold; see P11.11–P11.12 for
		details.
16	Simple PLC state	Output signal when current stage of simple PLC is
	completed	completed
17	Simple PLC cycle	Output signal when a single cycle of simple PLC
	completed	operation is completed
	Virtual terminal output of	Output corresponding signal based on the set value of
23	MODBUS communication	MODBUS; output ON signal when it is set to 1, output
	Vinteral tames in all acctors to a	OFF signal when it is set to 0
24	Virtual terminal output of	Output corresponding signal based on the set value of
24	POROFIBUS\CANopen communication	PROFIBUS\CANopen; output ON signal when it is set to 1, output OFF signal when it is set to 0
	communication	<u> </u>
25	Virtual terminal output of	Output corresponding signal based on the set value of Ethernet; output ON signal when it is set to 1, output OFF
25	Ethernet communication	signal when it is set to 0.
	DC bus voltage	Output is valid when the bus voltage is above the
26	established	undervoltage threshold of the inverter
27	Z pulse output	Output is valid when the encoder Z pulse is arrived, and
	2 paioo oatpat	is invalid after 10 ms.
28	During pulse superposition	
	Daning pales superposition	input function is valid
29	STO action	Output when STO fault occurred
30	Positioning completed	Output is valid when position control positioning is
		completed
31	Spindle zeroing completed	Output is valid when spindle zeroing is completed
32	Spindle scale-division	Output is valid when spindle scale-division is completed
	completed	
33	In speed limit	Output is valid when the frequency is limited
34	Virtual terminal output of	The corresponding signal is output according to the set
	EtherCat/Profinet	value of Profinet communication. When it is set to 1, the
	communication	ON signal is output, and when it is set to 0, the OFF
		signal is output.
35	Reserved	
36	Speed/position control	Output is valid when the mode switch-over is completed
	switch-over completed	

Set value	Function	Description
37–40	Reserved	
41	C_Y1	C_Y1 from PLC (You need to set P27.00 to 1.)
42	C_Y2	C_Y2 from PLC (You need to set P27.00 to 1.)
43	C_HDO	C_HDO from PLC (You need to set P27.00 to 1.)
44	C_RO1	C_RO1 from PLC(You need to set P27.00 to 1.)
45	C_RO2	C_RO2 from PLC (You need to set P27.00 to 1.)
46	C_RO3	C_RO3 from PLC (You need to set P27.00 to 1.)
47	C_RO4	C_RO4 from PLC (You need to set P27.00 to 1.)
48–63	Reserved variables	1

Function code	Name	Detailed parameter description	Default value
P06.00	HDO output type	O: Open collector high-speed pulse output Copen collector output	0
P06.01	Y output selection	0: Invalid	0
P06.02	HDO output selection	1: In running	0
P06.03	Relay RO1 output selection	2: In forward running 3: In reverse running	1
P06.04	Relay RO2 output selection	4: In jogging 5: Inverter fault 6: Frequency level detection FDT1 7: Frequency level detection FDT2 8: Frequency reached 9: Running in zero speed 10: Reach upper limit frequency 11: Reach lower limit frequency 12: Ready to run 13: In pre-exciting 14: Overload pre-alarm 15: Underload pre-alarm 16: Simple PLC stage completed 17: Simple PLC cycle completed 18: Reach set counting value 19: Reach designated counting value 20: External fault is valid 21: Reserved 22: Reach running time 23: Virtual terminal output of MODBUS	5

Function code	Name	Detailed parameter description	Default value
		communication	
		24: Virtual terminal output of	
		POROFIBUS/CANopen communication	
		25: Virtual terminal output of Ethernet	
		communication	
		26: DC bus voltage established	
		27: Z pulse output	
		28: During pulse superposition	
		29: STO action	
		30: Positioning completed	
		31: Spindle zeroing completed	
		32: Spindle scale-division completed	
		33: In speed limit	
		34: Virtual terminal output of	
		EtherCat/Profinet communication	
		35: Reserved	
		36: Speed/position control switch-over	
		completed	
		37–40: Reserved	
		41: C_Y1 from PLC (You need to set P27.00	
		to 1.)	
		42: C_Y2 from PLC (You need to set P27.00	
		to 1.)	
		43: C_HDO from PLC (You need to set	
		P27.00 to 1.)	
		44: C_RO1 from PLC (You need to set	
		P27.00 to 1.)	
		45: C_RO2 from PLC (You need to set	
		P27.00 to 1.)	
		46: C_RO3 from PLC (You need to set	
		P27.00 to 1.)	
		47: C_RO4 from PLC (You need to set	
		P27.00 to 1.)	
		48–63: Reserved	
P06.05	Output terminal polarity selection	0x00-0x0F	0x00
P06.06	Y switch-on delay	0.000-50.000s	0.000s
P06.07	Y switch-off delay	0.000–50.000s	0.000s


Function code	Name	Detailed parameter description	Default value
P06.08	HDO switch-on delay	0.000-50.000s (valid only when P06.00=1)	0.000s
P06.09	HDO switch-off delay	0.000–50.000s (valid only when P06.00=1)	0.000s
P06.10	Relay RO1 switch-on delay	0.000–50.000s	0.000s
P06.11	Relay RO1 switch-off delay	0.000-50.000s	0.000s
P06.12	Relay RO2 switch-on delay	0.000-50.000s	0.000s
P06.13	Relay RO2 switch-off delay	0.000-50.000s	0.000s
P07.40	Output terminal state of present fault	1	0
P17.13	Digital output terminal state	1	0

5.5.13 Simple PLC

Simple PLC is a multi-step speed generator, and the inverter can change the running frequency and direction automatically based on the running time to fulfill process requirements. Previously, such function was realized with external PLC, while now, the inverter itself can achieve this function.

GD350 series inverter can realize 16-step speeds control, and provide four groups of acceleration/deceleration time for users to choose from.

After the set PLC completes one cycle (or one section), one ON signal can be output by the multi-function relay.




Function code	Name	Detailed parameter description	Default value
P10.00	Simple PLC mode	O: Stop after running once 1: Keep running in the final value after running once 2: Cyclic running	0
P10.01	Simple PLC memory selection	No memory after power down Memory after power down	0
P10.02	Multi-step speed 0	-100.0–100.0%	0.0%
P10.03	Running time of 0 th step	0.0–6553.5s (min)	0.0s
P10.04	Multi-step speed 1	-100.0–100.0%	0.0%
P10.05	Running time of 1 st step	0.0–6553.5s (min)	0.0s
P10.06	Multi-step speed 2	-100.0–100.0%	0.0%
P10.07	Running time of 2 nd step	0.0–6553.5s (min)	0.0s
P10.08	Multi-step speed 3	-100.0–100.0%	0.0%
P10.09	Running time of 3 rd step	0.0–6553.5s (min)	0.0s
P10.10	Multi-step speed 4	-100.0–100.0%	0.0%
P10.11	Running time of 4 th step	0.0–6553.5s (min)	0.0s
P10.12	Multi-step speed 5	-100.0–100.0%	0.0%
P10.13	Running time of 5 th step	0.0–6553.5s (min)	0.0s
P10.14	Multi-step speed 6	-100.0–100.0%	0.0%
P10.15	Running time of 6 th step	0.0-6553.5s (min)	0.0s
P10.16	Multi-step speed 7	-100.0–100.0%	0.0%
P10.17	Running time of 7 th step	0.0–6553.5s (min)	0.0s
P10.18	Multi-step speed 8	-100.0–100.0%	0.0%
P10.19	Running time of 8 th step	0.0–6553.5s (min)	0.0s
P10.20	Multi-step speed 9	-100.0–100.0%	0.0%
P10.21	Running time of 9 th step	0.0–6553.5s (min)	0.0s
P10.22	Multi-step speed 10	-100.0–100.0%	0.0%
P10.23	Running time of 10 th step	0.0-6553.5s (min)	0.0s
P10.24	Multi-step speed 11	-100.0–100.0%	0.0%
P10.25	Running time of 11 th step	0.0-6553.5s (min)	0.0s
P10.26	Multi-step speed 12	-100.0–100.0%	0.0%
P10.27	Running time of 12 th step	0.0-6553.5s (min)	0.0s

Function code	Name	Detailed parameter description	Default value
P10.28	Multi-step speed 13	-100.0–100.0%	0.0%
P10.29	Running time of 13 th step	0.0–6553.5s (min)	0.0s
P10.30	Multi-step speed 14	-100.0–100.0%	0.0%
P10.31	Running time of 14 th step	0.0–6553.5s (min)	0.0s
P10.32	Multi-step speed 15	-100.0–100.0%	0.0%
P10.33	Running time of 15 th step	0.0–6553.5s (min)	0.0s
P10.36	PLC restart mode	Restart from the first section Continue running at the frequency when interruption occurred	0
P10.34	Acceleration/deceleration time of 0–7 stage of simple PLC	0x0000-0XFFFF	0000
P10.35	Acceleration/deceleration time of 8–15 stage of simple PLC	0x0000-0XFFFF	0000
P05.01– P05.09	Digital input function	23: Simple PLC stop reset 24: Simple PLC pause 25: PID control pause	
P06.01- P06.04	Digital output function	16: Simple PLC stage reached17: Simple PLC cycle reached	
P17.00	Set frequency	0.00Hz-P00.03 (Max. output frequency)	0.00Hz
P17.27	Simple PLC and current stage number of multi-step speed	0–15	0

5.5.14 Multi-step speed running

Set the parameters used in multi-step speed running. GD350 inverter can set 16-step speeds, which are selectable by multi-step speed terminals 1–4, corresponding to multi-step speed 0 to multi-step speed 15.




Functio n code	Name	Detailed parameter description	Default value
P10.02	Multi-step speed 0	-100.0–100.0%	0.0%
P10.03	Running time of 0 th step	0.0-6553.5s (min)	0.0s
P10.04	Multi-step speed 1	-100.0–100.0%	0.0%
P10.05	Running time of 1 st step	0.0–6553.5s (min)	0.0s
P10.06	Multi-step speed 2	-100.0–100.0%	0.0%
P10.07	Running time of 2 nd step	0.0–6553.5s (min)	0.0s
P10.08	Multi-step speed 3	-100.0–100.0%	0.0%
P10.09	Running time of 3 rd step	0.0–6553.5s (min)	0.0s
P10.10	Multi-step speed 4	-100.0–100.0%	0.0%
P10.11	Running time of 4 th step	0.0–6553.5s (min)	0.0s
P10.12	Multi-step speed 5	-100.0–100.0%	0.0%
P10.13	Running time of 5 th step	0.0-6553.5s (min)	0.0s
P10.14	Multi-step speed 6	-100.0–100.0%	0.0%
P10.15	Running time of 6 th step	0.0–6553.5s (min)	0.0s
P10.16	Multi-step speed 7	-100.0–100.0%	0.0%

Functio n code	Name	Detailed parameter description	Default value
P10.17	Running time of 7 th step	0.0–6553.5s (min)	0.0s
P10.18	Multi-step speed 8	-100.0–100.0%	0.0%
P10.19	Running time of 8 th step	0.0–6553.5s (min)	0.0s
P10.20	Multi-step speed 9	-100.0–100.0%	0.0%
P10.21	Running time of 9 th step	0.0–6553.5s (min)	0.0s
P10.22	Multi-step speed 10	-100.0–100.0%	0.0%
P10.23	Running time of 10 th step	0.0–6553.5s (min)	0.0s
P10.24	Multi-step speed 11	-100.0–100.0%	0.0%
P10.25	Running time of 11 th step	0.0–6553.5s (min)	0.0s
P10.26	Multi-step speed 12	-100.0–100.0%	0.0%
P10.27	Running time of 12 th step	0.0–6553.5s (min)	0.0s
P10.28	Multi-step speed 13	-100.0–100.0%	0.0%
P10.29	Running time of 13 th step	0.0-6553.5s (min)	0.0s
P10.30	Multi-step speed 14	-100.0–100.0%	0.0%
P10.31	Running time of 14 th step	0.0-6553.5s (min)	0.0s
P10.32	Multi-step speed 15	-100.0–100.0%	0.0%
P10.33	Running time of 15 th step	0.0-6553.5s (min)	0.0s
P10.34	Acceleration/decoration time selection of 0–7 section of simple PLC	0x0000-0XFFFF	0000
P10.35	Acceleration/decoration time selection of 8–15 section of simple PLC	0x0000-0XFFFF	0000
P05.01– P05.09	Digital input function selection	16: Multi-step speed terminal 1 17: Multi-step speed terminal 2 18: Multi-step speed terminal 3 19: Multi-step speed terminal 4 20: Multi-step speed pause	/
P17.27	Simple PLC and current steps of multi-step speed	0–15	0

5.5.15 PID control

PID control, a common mode for process control, is mainly used to adjust the inverter output frequency or output voltage through performing scale-division, integral and differential operations on the difference between feedback signal of controlled variables and signal of the target, thus forming a negative feedback system to keep the controlled variables above the target. It is suitable for flow control, pressure control, temperature control, etc. Diagram of basic principles for output frequency regulation is shown in the figure below.



Introduction to the working principles and control methods for PID control

Proportional control (Kp): When the feedback deviates from the reference, the output will be proportional to the deviation, if such deviation is constant, the regulating variable will also be constant. Proportional control can respond to feedback changes rapidly, however, it cannot eliminate the error by itself. The larger the proportional gain, the faster the regulating speed, but too large gain will result in oscillation. To solve this problem, first, set the integral time to a large value and the derivative time to 0, and run the system by proportional control, and then change the reference to observe the deviation between feedback signal and the reference (static difference), if the static difference is (eg, increase the reference, and the feedback variable is always less than the reference after system stabilizes), continue increasing the proportional gain, otherwise, decrease the proportional gain; repeat such process until the static error becomes small.

Integral time (Ti): When feedback deviates from reference, the output regulating variable accumulates continuously, if the deviation persists, the regulating variable will increase continuously until deviation disappears. Integral regulator can be used to eliminate static difference; however, too large regulation may lead to repetitive overshoot, which will cause system instability and oscillation. The feature of oscillation caused by strong integral effect is that the feedback signal fluctuates up and down based on the reference variable, and fluctuation range increases gradually until oscillation occurred. Integral time parameter is generally regulated gradually from large to small until the stabilized system speed fulfills the requirement.

Derivative time (Td): When the deviation between feedback and reference changes, output the regulating variable which is proportional to the deviation variation rate, and this regulating variable is only related to the direction and magnitude of the deviation variation rather than the direction and magnitude of the deviation itself. Differential control is used to control the feedback signal variation based on the variation trend. Differential regulator should be used with caution as it may easily enlarge the system interferences, especially those with high variation frequency.

When frequency command selection (P00.06, P00.07) is 7, or channel of voltage setup (P04.27) is 6,

the running mode of inverter is process PID control.

5.5.15.1 General procedures for PID parameter setup

a. Determining proportional gain P

When determining proportional gain P, first, remove the integral term and derivative term of PID by making Ti=0 and Td=0 (see PID parameter setup for details), thus turning PID into pure proportional control. Set the input to 60%–70% of the max. allowable value, and increase proportional gain P gradually from 0 until system oscillation occurred, and then in turn, decrease proportional gain P gradually from current value until system oscillation disappears, record the proportional gain P at this point and set the proportional gain P of PID to 60%–70% of current value. This is whole commissioning process of proportional gain P.

b. Determine integral time Ti

After proportional gain P is determined, set the initial value of a larger integral time Ti, and decrease Ti gradually until system oscillation occurred, and then in turn, increase Ti until system oscillation disappears, record the Ti at this point, and set the integral time constant Ti of PID to 150%–180% of current value. This is the commissioning process of integral time constant Ti.

c. Determining derivative time Td

The derivative time Td is generally set to 0.


If users need to set Td to another value, set in the same way with P and Ti, namely set Td to 30% of the value when there is no oscillation.

d. Empty system load, perform load-carrying joint debugging, and then fine-tune PID parameter until fulfilling the requirement.


5.5.15.2 How to fine-tune PID

After setting the parameters controlled by PID, users can fine-tune these parameters by the following means.


Control overmodulation: When overmodulation occurred, shorten the derivative time (Td) and prolong integral time (Ti).




Stabilize the feedback value as fast as possible: when overmodulation occurred, shorten integral time (Ti) and prolong derivative time (Td) to stabilize control as fast as possible.



Control long-term vibration: If the cycle of periodic vibration is longer than the set value of integral time (Ti), it indicates the integral action is too strong, prolong the integral time (Ti) to control vibration.



Control short-term vibration: If the vibration cycle is short is almost the same with the set value of derivative time (Td), it indicates derivative action is too strong, shorten the derivative time (Td) to control vibration. When derivative time (Td) is set to 0.00 (namely no derivative control), and there is no way to control vibration, decrease the proportional gain.




Function code	Name	Detailed parameter description	Default value
P09.00	PID reference source	0: Keypad (P09.01) 1: Al1 2: Al2 3: Al3 4: High-speed pulse HDIA 5: Multi-step	0
		6: MODBUS communication 7: PROFIBUS/CANopen/DeviceNet communication 8: Ethernet communication 9: High-speed pulse HDIB	

Function code	Name	Detailed parameter description	Default value
		10: EtherCat/Profinet communication	
		11: Programmable extension card	
	Due not DID veference of	12: Reserved	
P09.01	Pre-set PID reference of keypad	-100.0%—100.0%	0.0%
		0: Al1	
		1: Al2	
		2: Al3	
		High-speed pulse HDIA High-speed pulse HDIA High-speed pulse HDIA	
		5: PROFIBUS/CANopen/DeviceNet	
P09.02	PID feedback source	communication	0
		6: Ethernet communication	
		7: High-speed pulse HDIB	
		8: EtherCat/Profinet communication	
		9: Programmable extension card	
		10: Reserved	
P09.03	PID output characteristics	0: PID output is positive characteristic	0
P09.03	PID output characteristics	1: PID output is negative characteristic	0
P09.04	Proportional gain (Kp)	0.00–100.00	1.80
P09.05	Integral time (Ti)	0.01–10.00s	0.90s
P09.06	Derivative time (Td)	0.00–10.00s	0.00s
P09.07	Sampling cycle (T)	0.000–10.000s	0.100s
P09.08	Limit of PID control deviation	0.0–100.0%	0.0%
D00.00	Upper limit value of PID	P09.10-100.0% (max. frequency or	400.00/
P09.09	output	voltage)	100.0%
P09.10	Lower limit value of PID	-100.0%-P09.09 (max. frequency or	0.0%
F09.10	output	voltage)	0.0%
P09.11	Feedback offline detection	0.0–100.0%	0.0%
	value		0.070
P09.12	Feedback offline detection time	0.0–3600.0s	1.0s
		0x0000-0x1111	
		Ones:	
P09.13	PID control selection	0: Continue integral control after the	0x0001
		frequency reaches upper/lower limit	
		1: Stop integral control after the	

Function code	Name	Detailed parameter description	Default value
		frequency reaches upper/lower limit	
		Tens:	
		0: The same with the main reference	
		direction	
		1: Contrary to the main reference	
		direction	
		Hundreds:	
		0: Limit as per the max. frequency	
		1: Limit as per A frequency	
		Thousands:	
		0: A+B frequency, acceleration	
		/deceleration of main reference A	
		frequency source buffering is invalid	
		1: A+B frequency, acceleration/	
		deceleration of main reference A	
		frequency source buffering is valid,	
		acceleration/deceleration is determined	
		by P08.04 (acceleration time 4).	
P17.00	Set frequency	0.00Hz-P00.03 (Max. output frequency)	0.00Hz
P17.23	PID reference value	-100.0–100.0%	0.0%
P17.24	PID feedback value	-100.0–100.0%	0.0%

5.5.16 Run at wobbling frequency

Wobbling frequency is mainly applied in cases where transverse movement and winding functions are needed like textile and chemical fiber industries. The typical working process is shown as below.



Function code	Name	Detailed parameter description	Default value
P00.03	Max. output frequency	P00.03–400.00Hz	50.00Hz
P00.03	A frequency command selection	0: Set via keypad 1: Set via Al1 2: Set via Al2 3: Set via Al3 4: Set via high speed pulse HDIA 5: Set via simple PLC program 6: Set via multi-step speed running 7: Set via PID control 8: Set via MODBUS communication 9: Set via PROFIBUS / CANopen / DeviceNet communication 10: Set via Ethernet communication 11: Set via high speed pulse HDIB 12: Set via pulse string AB 13: Set via EtherCat/Profinet	0
P00.11	Acceleration time 1	communication 14: Set via PLC card 0.0–3600.0s	Depend on model
P00.12	Deceleration time 1	0.0–3600.0s	Depend on model
P05.01– P05.09	Digital input function selection	26: Wobbling frequency pause (stop at current frequency) 27: Wobbling frequency reset (revert to center frequency)	/
P08.15	Amplitude of wobbling frequency	0.0–100.0% (relative to set frequency)	0.0%
P08.16	Amplitude of jump frequency	0.0–50.0% (relative to amplitude of wobbling frequency)	0.0%
P08.17	Wobbling frequency rise time	0.1–3600.0s	5.0s
P08.18	Wobbling frequency fall time	0.1–3600.0s	5.0s

5.5.17 Local encoder input

GD350 series inverter supports pulse count function by inputting the count pulse from HDI high-speed pulse port. When the actual count value is no less than the set value, digital output terminal will output count-value-reached pulse signal, and the corresponding count value will be zeroed out.

Function code	Name	Detailed parameter description	Default value
P05.00	HDI input type	0x00–0x11 Ones: HDIA input type 0: HDIA is high-speed pulse input 1: HDIA is digital input Tens: HDIB input type 0: HDIB is high-speed pulse input	0x00
P05.38	HDIA high-speed pulse input function	1: HDIB is digital input 0: Set input via frequency 1: Reserved 2: Input via encoder, used in combination with HDIB	0
P05.44	HDIB high-speed pulse input function selection	O: Set input via frequency 1: Reserved 2: Input via encoder, used in combination with HDIA	0
P20.15	Speed measurement mode	0: PG card 1: local; realized by HDIA and HDIB; supports incremental 24V encoder only	0
P18.00	Actual frequency of encoder	-999.9–3276.7Hz	0.0Hz

5.5.18 Commissioning procedures for position control and spindle positioning function

- 1. Commissioning procedures for closed-loop vector control of asynchronous motor
- Step 1: Restore to default value via keypad
- Step 2: Set P00.03, P00.04 and P02 group motor nameplate parameters
- Step 3: Motor parameter autotuning

Carry out rotary parameter autotuning or static parameter autotuning via keypad, if the motor can be disconnected from load, then it is users can carry out rotary parameter autotuning; otherwise, carry out static parameter autotuning, the parameter obtained from autotuning will be saved in P02 motor parameter group automatically.

- Step 4: Verify whether the encoder is installed and set properly
 - a) Confirm the encoder direction and parameter setup

Set P20.01 (encoder pulse-per-revolution), set P00.00=2 and P00.10=20Hz, and run the inverter, at this point, the motor rotates at 20Hz, observe whether the speed measurement value of P18.00 is correct, if the value is negative, it indicates the encoder direction is reversed, under such situation, set P20.02 to 1; if the speed measurement value deviates greatly, it indicates P20.01 is set improperly. Observe whether P18.02 (encoder Z pulse count value) fluctuates, if yes, it indicates the encoder suffers interference or P20.01 is set improperly, requiring users to check the wiring and the shielding

layer.

b) Determine Z pulse direction

Set P00.10=20Hz, and set P00.13 (running direction) to forward and reverse direction respectively to observe whether the difference value of P18.02 is less than 5, if the difference value remains to be larger than 5 after setting Z pulse reversal function of P20.02, power off and exchange phase A and phase B of the encoder, and then observe the difference between the value of P18.02 during forward and reverse rotation. Z pulse direction only affects the forward/reverse positioning precision of the spindle positioning carried out with Z pulse.

Step 5: Closed-loop vector pilot-run

Set P00.00=3, and carry out closed-loop vector control, adjust P00.10 and speed loop and current loop PI parameter in P03 group to make it run stably in the whole range.

Step 6: Flux-weakening control

Set flux-weakening regulator gain P03.26=0-8000, and observe the flux-weakening control effect. P03.22-P03.24 can be adjusted as needed.

2. Commissioning procedures for closed-loop vector control of synchronous motor

Step 1: Set P00.18=1, restore to default value

Step 2: Set P00.00=3 (VC), set P00.03, P00.04, and motor nameplate parameters in P02 group.

Step 3: Set P20.00 and P20.01 encoder parameters

When the encoder is resolver-type encoder, set the encoder pulse count value to (resolver pole pair number × 1024), eg, if pole pair number is 4, set P20.01 to 4096.

Step 4: Ensure the encoder is installed and set correctly

When motor stops, observe whether P18.21 (resolver angle) fluctuates, if it fluctuates sharply, check the wiring and grounding. Rotates the motor slowly, observe whether P18.21 changes accordingly. If yes, it indicates motor is connected correctly; if the value of P18.02 keeps constant at a non-zero value after rotating for multiple circles, it indicates encoder Z signal is correct.

Step 5: Autotuning of initial position of magnetic pole

Set P20.11=2 or 3 (3: rotary autotuning; 2: static autotuning), press RUN key to run the inverter.

a) Rotary autotuning (P20.11 = 3)

Detect the position of current magnetic pole when autotuning starts, and then accelerates to 10Hz, autotuning corresponding magnetic pole position of encoder Z pulse, and decelerate to stop.

During running, if ENC1O or ENC1D fault occurred, set P20.02=1 and carry out autotuning again.

After autotuning is done, the angle obtained from autotuning will be saved in P20.09 and P20.10 automatically.

b) Static autotuning

In cases where the load can be disconnected, it is recommended to adopt rotary autotuning (P20.11=3) as it has high angle precision. If the load cannot be disconnected, users can adopt static autotuning (P20.11=2). The magnetic pole position obtained from autotuning will be saved in P20.09 and P20.10.

Step 6: Closed-loop vector pilot-run

Adjust P00.10 and speed loop and current loop PI parameter in P03 group to make it run stably in the whole range. If oscillation occurred, reduce the value of P03.00, P03.03, P03.09 and P03.10. If current oscillation noise occurred during low speed, adjust P20.05.

Note: It is necessary to re-determine P20.02 (encoder direction) and carry out magnetic pole position autotuning again if the wiring of motor or encoder is changed.

3. Commissioning procedures for pulse string control

Pulse input is operated based on closed-loop vector control; speed detection is needed in the subsequent spindle positioning, zeroing operation and division operation.

Step 1: Restore to default value by keypad

Step 2: Set P00.03, P00.04 and motor nameplate parameters in P02 group

Step 3: Motor parameter autotuning: rotary parameter autotuning or static parameter autotuning

Step 4: Verity the installation and settings of encoder. Set P00.00=3 and P00.10=20Hz to run the system, and check the control effect and performance of the system.

Step 5: Set P21.00=0001 to set positioning mode to position control, namely pulse-string control. There are four kinds of pulse command modes, which can be set by P21.01 (pulse command mode).

Under position control mode, users can check high bit and low bit of position reference and feedback, P18.02 (count value of Z pulse), P18.00 (actual frequency of encoder), P18.17 (pulse command frequency) and P18.19 (position regulator output) via P18, through which users can figure out the relation between P18.8 (position of position reference point) and P18.02, pulse command frequency P18.17, feedforward P18.18 and position regulator output P18.19.

Step 6: The position regulator has two gains, namely P21.02 and P21.03, and they can be switched by speed command, torque command and terminals.


Step 7: When P21.08 (output limit of position controller) is set to 0, the position control will be invalid, and at this point, the pulse string acts as frequency source, P21.13 (position feedforward gain) should be set to 100%, and the speed acceleration/deceleration time is determined by the acceleration /deceleration time of pulse string, the pulse string acceleration/deceleration time of the system can be adjusted. If the pulse string acts as the frequency source in speed control, users can also set P21.00 to 0000, and set the frequency source reference P00.06 or P00.07 to 12 (set by pulse string AB), at this point, the acceleration/deceleration time is determined by the acceleration/deceleration time of the inverter, meanwhile, the parameters of pulse string AB is still set by P21 group. In speed mode, the filter time of pulse string AB is determined by P21.29.

Step 8: The input frequency of pulse string is the same with the feedback frequency of encoder pulse, the relation between them can be changed by altering P21.11 (numerator of position command ratio) and P21.12 (denominator of position command ratio)

Step 9: When running command or servo enabling is valid (by setting P21.00 or terminal function 63), it will enter pulse string servo running mode.

4. Commissioning procedures for spindle positioning

Spindle orientation is to realize orientation functions like zeroing and division based on closed-loop vector control



Step 1–4: These four steps are the same with the first four steps of the commissioning procedures for closed-loop vector control, which aim to fulfill the control requirements of closed-loop vector control, thus realizing spindle positioning function in either position control or speed control mode.

Step 5: Set P22.00.bit0=1 to enable spindle positioning, set P22.00.bit1 to select spindle zero input. If the system adopts encoder for speed measurement, set P22.00.bit1 to 0 to select Z pulse input; if the system adopts photoelectric switch for speed measurement, set P22.00.bit1 to 1 to select photoelectric switch as zero input; set P22.00.bit2 to select zero search mode, set P22.00.bit3 to enable or disable zero calibration, and select zero calibration mode by setting P22.00.bit7.

Step 6: Spindle zeroing operation

- a) Select the positioning direction by setting P22.00.bit4;
- b) There are four zero positions in P22 group, users can choose one out of four zeroing positions by setting zeroing input terminal selection (46, 47) in P05 group. When executing zeroing function, the motor will stop accurately at corresponding zeroing position according to the set positioning direction, which can be viewed via P18.10:
- c) The positioning length of spindle zeroing is determined by the deceleration time of accurate-stop and the speed of accurate-stop;

Step 7: Spindle division operation

There are seven scale-division positions in P22 group, users can choose one out of seven scale-division positions by setting scale-division input terminal selection (48, 49, 50) in P05 group. Enable corresponding scale-division terminal after the motor stops accurately, and the motor will

check the scale-division position state and switch to corresponding position incrementally, at this point, users can check P18.09.

Step 8: Priority level of speed control, position control and zeroing

The priority level of speed running is higher than that of the scale division, when the system runs in scale-division mode, if spindle orientation is prohibited, the motor will turn to speed mode or position mode.

The priority level of zeroing is higher than that of the scale division.

Scale-division command is valid when the scale-division terminal is from 000 state to non-000 state, eg, in 000–011, the spindle executes scale division 3. The transition time during terminal switch-over needs to be less than 10ms; otherwise, wrong scale division command may be executed.

Step 9: Hold positioning

The position loop gain during positioning is P21.03; while the position loop gain in positioning-completion-hold state is P21.02. In order to keep sufficient position-hold force and ensure no system oscillation occurred, adjust P03.00, P03.01, P20.05 and P21.02.

Step 10: Positioning command selection (bit6 of P22.00)

Electric level signal: Positioning command (zeroing and scale division) can be executed only when there is running command or the servo is enabled.

Step 11: Spindle reference point selection (bit0 of P22.00)

Encoder Z pulse positioning supports the following spindle positioning modes:

- a) the encoder is installed on the motor shaft, the motor shaft and spindle is 1:1 rigid connection;
- b) the encoder is installed on the motor shaft, the motor shaft and spindle is 1:1 belt connection:

At this point, the belt may slip during high-speed running and cause inaccurate positioning, it is recommended to install proximity switch on the spindle.

c) The encoder is installed on the spindle, and the motor shaft is connected to the spindle with belt, the drive ratio is not necessarily 1:1:

At this point, set P20.06 (speed ratio of the mounting shaft between motor and encoder), and set P22.14 (spindle drive ratio) to 1. As the encoder is not installed on the motor, the control performance of closed-loop vector will be affected.


Proximity switch positioning supports the following spindle positioning modes:

 a) The encoder is installed on the motor shaft, the drive ratio between motor shaft and spindle is not necessarily 1:1;

At this point, it is required to set P22.14 (spindle drive ratio).

5. Commissioning procedures for digital positioning

The diagram for digital positioning is shown below.



P21.25 Hold time of positioning completion signal

Step 1-4: These four steps are the same with the first four steps of the commissioning procedures for closed-loop vector control, which aim to fulfill the control requirements of closed-loop vector control.

Step 5: Set P21.00=0011 to enable digital positioning. Set P21.17, P21.11 and P21.12 (set positioning displacement) according to actual needs; set P21.18 and P21.19 (set positioning speed); set P21.20 and P21.21 (set acceleration/deceleration time of positioning).

Step 6: Single positioning operation


Set P21.16.bit1=0, and the motor will carry out single positioning action and stay in the positioning position according to the setup in step 5.

Step 7: Cyclic positioning operation

Set P21.16.bit1=1 to enable cyclic positioning. The cyclic positioning is divided into continuous mode and repetitive mode; users can also carry out cyclic positioning through terminal function (no. 55, enable digital positioning cycle)

6. Commissioning procedures for positioning of photoelectric switch

Photoelectric switch positioning is to realize positioning function based on closed-loop vector control.



Step 1-4: These four steps are the same with the first four steps of the commissioning procedures for closed-loop vector control, which aim to fulfill the control requirements of closed-loop vector control.

Step 5: Set P21.00=0021 to enable photoelectric switch positioning, the photoelectric switch signal can be connected to S8 terminal only, and set P05.08=43, meanwhile, set P21.17, P21.11 and P21.12 (set positioning displacement) based on actual needs; set P21.21 (deceleration time of positioning), however, when present running speed is too fast or the set positioning displacement is too small, the deceleration time of positioning will be invalid, and it will enter direct deceleration positioning mode.

Step 6: Cyclic positioning


After positioning is done, the motor will stay in current position. Users can set cyclic positioning through input terminal function selection (55: enable cyclic digital positioning) in P05 group; when the terminal receives cyclic positioning enable signal (pulse signal), the motor will continue running in the set speed as per the speed mode and re-enter positioning state after encountering photoelectric switch.

(7) Hold positioning

The position loop gain during positioning is P21.03; while the position loop gain in positioning-completion-hold state is P21.02. In order to keep sufficient position-hold force and ensure no system oscillation occurred, adjust P03.00, P03.01, P20.05 and P21.02.

5.5.19 Fault handling

GD350 series inverter provides abundant information concerning fault handling for the convenience of the users.



Function code	Name	Detailed parameter description	Default value
P07.27	Type of present fault	0: No fault	0
P07.28	Type of the last fault	1: Inverter unit U phase protection (OUt1)	/
P07.29	Type of the last but one fault	2: Inverter unit V phase protection (OUt2)	/
P07.30	Type of the last but two fault	3: Inverter unit W phase protection	/
P07.31	Type of the last but three	(OUt3)	/
	fault	4: Overcurrent during acceleration (OC1)	
		5: Overcurrent during deceleration (OC2)	
		6: Overcurrent during constant speed	
		(OC3)	
		7: Overvoltage during acceleration (OV1)8: Overvoltage during deceleration (OV2)	
		, ,	
		Overvoltage during constant speed (OV3)	
	Type of the last but four fault	10: Bus undervoltage fault (UV)	
		11: Motor overload (OL1)	
		12: Inverter overload (OL2)	
		13: Phase loss on input side (SPI)	
		14: Phase loss on output side (SPO)	
		15: Rectifier module overheat (OH1)	
		16: Inverter module overheat (OH2)	
		17: External fault (EF)	
		18: 485 communication fault (CE)	
P07.32		19: Current detection fault (ItE)	
		20: Motor autotuning fault (tE)	
		21: EEPROM operation fault (EEP)	
		22: PID feedback offline fault (PIDE)	
		23: Brake unit fault (bCE)	
		24: Running time reached (END)	
		25: Electronic overload (OL3)	
		26: Keypad communication error (PCE)	
		27: Parameter upload error (UPE)	
		28: Parameter download error (DNE)	
		29: Profibus DP communication fault	
		(E-DP)	
		30: Ethernet communication fault	
		(E-NET)	
		31: CANopen communication fault	
		(E-CAN)	

Function code	Name	Detailed parameter description	Default value
Code		32: To-ground short-circuit fault 1 (ETH1)	value
		33: To-ground short-circuit fault 2 (ETH2)	
		34: Speed deviation fault (dEu)	
		35: Mal-adjustment fault (STo)	
		36: Underload fault (LL)	
		37: Encoder offline fault (ENC10)	
		38: Encoder reversal fault (ENC1D)	
		39: Encoder Z pulse offline fault (ENC1Z)	
		40: Safe torque off (STO)	
		41: Channel H1 safety circuit exception	
		(STL1)	
		42: Channel H2 safety circuit exception	
		(STL2)	
		43: Channel H1 and H2 exception (STL3)	
		44: Safety code FLASH CRC check fault	
		(CrCE)	
		55: Repetitive extension card type fault	
		(E-Err)	
		56: Encoder UVW loss fault (ENCUV)	
		57: Profinet communication timeout fault	
		(E-PN)	
		58: CAN communication fault (SECAN)	
		59: Motor over-temperature fault (OT)	
		60: Card slot 1 card identification failure	
		(F1-Er)	
		61: Card slot 2 card identification failure	
		(F2-Er)	
		62: Card slot 3 card identification failure	
		(F3-Er)	
		63: Card slot 1 card communication	
		timeout fault (C1-Er)	
		64: Card slot 2 card communication	
		timeout fault (C2-Er)	
		65: Card slot 3 card communication	
		timeout fault (C3-Er)	
		66: EtherCat communication fault	
		(E-CAT)	
		67: Bacnet communication fault (E-BAC)	
		68: DeviceNet communication fault	

Function code	Name	Detailed parameter description	Default value
		(E-DEV)	
		69: Master-slave synchronous CAN	
		slave fault (S-Err)	
P07.33	Running frequency of present	t fault	0.00Hz
P07.34	Ramps reference frequency of	of present fault	0.00Hz
P07.35	Output voltage of present fau	lt	0V
P07.36	Output current of present faul	t	0.0A
P07.37	Bus voltage of present fault		0.0V
P07.38	Max. temperature of present to	fault	0.0°C
P07.39	Input terminal state of presen	t fault	0
P07.40	Output terminal state of prese	ent fault	0
P07.41	Running frequency of the last	fault	0.00Hz
P07.42	Ramps reference frequency of the last fault		0.00Hz
P07.43	Output voltage of the last fault		0V
P07.44	Output current of the last faul	t	0.0A
P07.45	Bus voltage of the last fault		0.0V
P07.46	Max. temperature of the last f	ault	0.0°C
P07.47	Input terminal state of the last	t fault	0
P07.48	Output terminal state of the la	ast fault	0
P07.49	Running frequency of the last	but one fault	0.00Hz
P07.50	Ramps reference frequency of	of the last but one fault	0.00Hz
P07.51	Output voltage of the last but	one fault	0V
P07.52	Output current of the last but	one fault	0.0A
P07.53	Bus voltage of the last but on	e fault	0.0V
P07.54	Max. temperature of the last b	out one fault	0.0°C
P07.55	Input terminal state of the last	t but one fault	0
P07.56	Output terminal state of the la	ast but one fault	0

Chapter 6 Function parameter list

6.1 What this chapter contains

This chapter lists all the function codes and corresponding description of each function code.

6.2 Function parameter list

Function parameters of GD350 series inverter are categorized according to functions. Among the function groups, P98 is analog input/output calibration group, and P99 is factory function group which cannot be accessed by users. The function code adopts three-level menu, eg, "P08.08" indicates it is the no. 8 function code in P8 group.

The function group no. corresponds to the first-level menu; function code no. corresponds to the second-level menu; function code parameter corresponds to the third-level menu.

1. The function list is divided into the following columns.

Column 1 "Function code": number of the function parameter group and the parameter;

Colum 2 "Name": complete name of the function parameter;

Colum 3 "Detailed parameter description": detailed description of this function parameter;

Colum 4 "Default value": The original set value of the function parameter by default;

Colum 5: "Modify": The modification attribute of the function parameter, namely whether the function parameter can be modified and the condition for modification, as shown below.

"O": the set value of this parameter can be modified when the inverter is in stop or running state:

"O": the set value of this parameter cannot be modified when the inverter is in running state;

"•": the parameter value is the measured value which cannot be modified.

(The inverter has assigned the modification attribute of each parameter automatically to avoid inadvertent modification by users.)

- 2. "System of numeration for parameters" is decimal; if the parameter is presented in hexadecimal numbers, the data of each bit will be independent of each other during parameter edit, and the value range of partial bits can be 0–F in hexadecimal system.
- 3. "Default value" is value restored after parameter refresh during restoring to default value; however, the measured value or recorded value will not be refreshed.
- 4. In order to enhance parameter protection, the inverter provides password protection for the function codes. After setting user password (namely user password P07.00 is not zero), when users press PRG/ESC key to enter function code edit state, the system will first enter user password verification state which displays "0.0.0.0.0.", requiring operators to input the correct user password. For factory parameters, besides user password, it is also required to input the correct factory password (users should not attempt to modify factory parameters as improper setup may easily lead to mal-operation or damage the inverter). When password protection is unlocked, the user password

can be modified at any time; user password is subject to the last input. User password can be cancelled by setting P07.00 to 0; if P01.00 is set to a non-zero value, the parameter will be protected by password. When modifying function parameters through serial communication, the function of user password also follows above rules.

Function	Name	Detailed parameter description	Default	Modi
code			value	fy
P00 group	p Basic function	ns		
		0:SVC 0		
		1:SVC 1		
P00.00	Speed control	2:SVPWM	0	0
P00.00	mode	3:VC	2	0
		Note: If 0, 1 or 3 is selected, it is required to carry out		
		motor parameter autotuning first.		
	Running	0: Keypad		
P00.01	command	1: Terminal	0	0
	channel	2: Communication		
		0: MODBUS		
		1: PROFIBUS/CANopen/Devicenet		
	Communication	2: Ethernet		
P00.02	running	3: EtherCat/Profinet	0	0
P00.02	command	4: PLC programmable card	U	0
	channel	5: Wireless communication card		
		Note: 1, 2, 3, 4 and 5 are extended functions which		
		are applicable with corresponding cards.		
		Used to set the maximum output frequency of the		
P00.03	Max. output	inverter. It is the basis of frequency setup and the	50.00Hz	0
P00.03	frequency	acceleration/deceleration.	50.00HZ	0
		Setting range: Max. (P00.04, 10.00) –630.00Hz		
		The upper limit of running frequency is upper limit		
		value of inverter output frequency. This value cannot		
	Upper limit of	be more than the maximum output frequency.		
P00.04	• • • • • • • • • • • • • • • • • • • •	When the set frequency is higher than the upper limit	50.00Hz	0
P00.04	running	frequency, the inverter runs at the upper limit	50.00HZ	0
	frequency	frequency.		
		Setting range: P00.05-P00.03 (Max. output		
		frequency)		
	Lower limit of	The lower limit of running frequency is the lower limit		
P00.05	running	value of inverter output frequency.	0.00Hz	0
1 00.03	frequency	When the set frequency is lower than the lower limit	0.00112	
	печиспсу	frequency, the inverter runs at the lower limit		

Frequency Note: Max. output frequency ≥ upper limit frequency ≥ lower limit frequency. Setting range: 0.00Hz–P00.04 (upper limit of running frequency)	Function	Name	Detailed parameter description	Default	Modi
Note: Max. output frequency ≥ upper limit frequency ≥ lower limit frequency.	code			value	fy
Frequency ≥ lower limit frequency. Setting range: 0.00Hz–P00.04 (upper limit of running frequency)			. ,		
Setting range: 0.00Hz_P00.04 (upper limit of running frequency) O: Set via keypad 1: Set via Al1 2: Set via Al2 3: Set via Al3 4: Set via high speed pulse HDIA 5: Set via multi-step speed running 7: Set via PID control 8: Set via MODBUS communication 9: Set via PROFIBUS / CANopen / DeviceNet communication 10: Set via bigh speed pulse HDIB 12: Set via pluse string AB 13: Set via pluse string AB 13: Set via Ethercat/Profinet communication 14: Set via pluc card 15: Reserved P00.08 Reference object of B frequency command O: A 1: B 2: (A+B) 3: (A-B) 4: Max. (A, B) 5: Min. (A, B) When A and B frequency commands are set by keypad, the value is the initial digital set value of the inverter frequency. Setting range: 0.00 Hz_P00.03 (Max. output frequency) Depend Occeleration Occel					
P00.06 A frequency 0: Set via keypad 1: Set via Al1 2: Set via Al2 3: Set via high speed pulse HDIA 5: Set via simple PLC program 6: Set via multi-step speed running 7: Set via PID control 8: Set via PID control 11: Set via high speed pulse HDIB 12: Set via pulse string AB 13: Set via Ethercat/Profinet communication 14: Set via PID card 15: Reserved 15: Reserved 15: Reserved 15: Reserved 15: Reserved 16: A frequency command 16: B 2: (A+B) 3: (A-B) 4: Max. (A, B) 5: Min. (A, B) 6: Max. output frequency Condition Cond					
P00.06 A frequency Command 1: Set via Al1 2: Set via Al2 3: Set via Al3 4: Set via high speed pulse HDIA 5: Set via multi-step speed running 7: Set via PID control 8: Set via MODBUS communication 9: Set via PROFIBUS / CANopen / DeviceNet 15 Ommunication 11: Set via pluse string AB 13: Set via PLC card 15: Reserved Ommunication 14: Set via PLC card 15: Reserved Ommunication 16: A frequency Command Combination Max. output frequency Command Ommunication Ommunicat					
P00.06 command selection 1: Set via Al1 2: Set via Al2 3: Set via Al3 4: Set via high speed pulse HDIA 5: Set via simple PLC program 6: Set via multi-step speed running 7: Set via PID control 8: Set via MODBUS communication 9: Set via PROFIBUS / CANopen / DeviceNet communication 10: Set via Ethernet communication 11: Set via high speed pulse HDIB 12: Set via pulse string AB 13: Set via EtherCat/Profinet communication 14: Set via PLC card 15: Reserved Depon.08 Reference object of B frequency command 0: A 1: B 2: (A+B) 3: (A-B) 4: Max. (A, B) 5: Min. (A, B) When A and B frequency commands are set by keypad, set value is the initial digital set value of the inverter frequency. Setting range: 0.00 Hz—P00.03 (Max. output frequency) P00.11 Acceleration Acceleration in Acceleration and program is the time needed for accelerating in the program is the time needed for accelerating in the program is the time needed for accelerating in the program is the time needed for accelerating in the program is the time needed for accelerating in the program is the time needed for accelerating in the program is the time needed for accelerating in the program is the time needed for accelerating in the program is the time needed for accelerating in the program is the time needed for accelerating in the program is the time needed for accelerating in the program is the time needed for accelerating in the program is the time needed for accelerating in the program is the time needed for accelerating in the program is the program is the time needed for accelerating in the program is the time needed for accelerating in the program is the time needed for accelerating in the program is the time needed for accelerating in the program is the time needed for accelerating in the program is the time needed for accelerating in the program is the program in the program is the progra			frequency)		
Selection 2: Set via AI2 3: Set via AI3 4: Set via high speed pulse HDIA 5: Set via simple PLC program 6: Set via multi-step speed running 7: Set via PID control 8: Set via MOBBUS communication 9: Set via PROFIBUS / CANopen / DeviceNet communication 10: Set via brigh speed pulse HDIB 12: Set via pulse string AB 13: Set via EtherCat/Profinet communication 14: Set via PLC card 15: Reserved 0: Max. output frequency 1: A frequency command 0: A 1: B 2: (A+B) 3: (A-B) 4: Max. (A, B) 5: Min. (A, B) Set frequency via keypad Set frequency via keypad Acceleration Acceleration Acceleration immediate is the time needed for accelerating Depend		A frequency	0: Set via keypad		
3: Set via AI3 4: Set via high speed pulse HDIA 5: Set via simple PLC program 6: Set via multi-step speed running 7: Set via PID control 8: Set via MODBUS communication 9: Set via PROFIBUS / CANopen / DeviceNet communication 10: Set via bligh speed pulse HDIB 12: Set via high speed pulse HDIB 12: Set via pulse string AB 13: Set via PLC card 15: Reserved 0: Max. output frequency 1: A frequency command 0: A 1: B 2: (A+B) 3: (A-B) 4: Max. (A, B) 5: Min. (A, B) Set frequency via keypad Set frequency via keypad Acceleration Acceleration Acceleration time is the time needed for accelerating Depend Acceleration Acceleration in mode of setting source Acceleration time is the time needed for accelerating	P00.06	command	1: Set via AI1	0	0
4: Set via high speed pulse HDIA 5: Set via simple PLC program 6: Set via multi-step speed running 7: Set via PID control 8: Set via MODBUS communication 9: Set via PROFIBUS / CANopen / DeviceNet communication 10: Set via pulse string AB 13: Set via pulse string AB 13: Set via PLC card 15: Reserved P00.08 Reference object of B frequency command P00.09 Combination mode of setting source P00.09 Set frequency via keypad P00.10 Set frequency via keypad Acceleration Acceleration Acceleration time is the time needed for accelerating Acceleration time is the time needed for accelerating Acceleration time is the time needed for accelerating Acceleration Depend		selection	2: Set via AI2		
5: Set via simple PLC program 6: Set via multi-step speed running 7: Set via PID control 8: Set via MODBUS communication 9: Set via PROFIBUS / CANopen / DeviceNet communication 10: Set via PROFIBUS / DeviceNet communication 11: Set via high speed pulse HDIB 12: Set via pulse string AB 13: Set via EtherCat/Profinet communication 14: Set via PLC card 15: Reserved P00.08 Reference object of B frequency command P00.09 Combination mode of setting Source P00.09 Set frequency via keypad Set frequency via keypad P00.10 Acceleration Acceleration time is the time needed for accelerating Set via PID control 8: Set via MODBUS communication 15: O Max. output frequency 15: A 15 O O O O O O O O O O O O O			3: Set via Al3		
B frequency command selection B frequency command C Set via PROFIBUS / CANopen / DeviceNet communication C Set via Ethernet communication C Set via pulse string AB C Set via pulse string AB C Set via PLC card C Set via PLC card C Set via PLC card C Set via pulse string AB C Set via p			4: Set via high speed pulse HDIA		
P00.07 B frequency command selection 7: Set via PID control 8: Set via MODBUS communication 9: Set via PROFIBUS / CANopen / DeviceNet communication 10: Set via Ethernet communication 11: Set via high speed pulse HDIB 12: Set via pulse string AB 13: Set via EtherCat/Profinet communication 14: Set via PLC card 15: Reserved P00.08 Reference object of B frequency command 0: Max. output frequency 1: A frequency command 0: A 1: B 2: (A+B) 3: (A-B) 4: Max. (A, B) 5: Min. (A, B) When A and B frequency commands are set by keypad, the value is the initial digital set value of the inverter frequency. Setting range: 0.00 Hz–P00.03 (Max. output frequency) P00.11 Acceleration Acceleration time is the time needed for accelerating Depend			5: Set via simple PLC program		
B frequency command selection Combination P00.09 Combination mode of setting source P00.10 Set frequency via keypad Acceleration B frequency command B frequency commands are set by keypad, the value is the initial digital set value of the inverter frequency. B frequency commands are set by keypad, the value is the initial digital set value of the inverter frequency. B frequency commands are set by keypad, the value is the initial digital set value of the inverter frequency. B frequency commands are set by keypad, the value is the initial digital set value of the inverter frequency. B frequency commands are set by keypad, the value is the initial digital set value of the inverter frequency. B frequency commands are set by keypad, the value is the initial digital set value of the inverter frequency. B frequency commands are set by keypad, the value is the initial digital set value of the inverter frequency. B frequency commands are set by keypad, the value is the initial digital set value of the inverter frequency. B frequency commands are set by keypad, the value is the initial digital set value of the inverter frequency. B frequency commands are set by keypad, the value is the initial digital set value of the inverter frequency. B frequency commands are set by keypad.			6: Set via multi-step speed running		
P00.07 B frequency command selection 9: Set via PROFIBUS / CANopen / DeviceNet communication 10: Set via Ethernet communication 11: Set via pulse HDIB 12: Set via pulse string AB 13: Set via PLC card 15: Reserved P00.08 Reference object of B frequency command 0: A			7: Set via PID control		
P00.07 Poolog Command selection Set via PROFIBUS / CANopen / DeviceNet communication 10: Set via Ethernet communication 11: Set via high speed pulse HDIB 12: Set via pulse string AB 13: Set via EtherCat/Profinet communication 14: Set via PLC card 15: Reserved 0: Max. output frequency 1: A frequency command 0: A 1: B 2: (A+B) 3: (A-B) 4: Max. (A, B) 5: Min. (A, B) Set frequency via keypad Set frequency via keypad Acceleration Acceleration Acceleration Acceleration Acceleration Acceleration Acceleration Acceleration Depend Depend		D (8: Set via MODBUS communication		
communication 10: Set via Ethernet communication 11: Set via high speed pulse HDIB 12: Set via pulse string AB 13: Set via EtherCat/Profinet communication 14: Set via PLC card 15: Reserved P00.08 Reference object of B frequency command 0: A 1: B 2: (A+B) 3: (A-B) 4: Max. (A, B) 5: Min. (A, B) Set frequency via keypad Set frequency via keypad Acceleration Acceleration time is the time needed for accelerating Communication 10: Set via EtherCat/Profinet communication 14: Set via PLC card 15: Reserved 0: Max. output frequency 1: A frequency command 0: A 1: B 2: (A+B) 3: (A-B) 4: Max. (A, B) 5: Min. (A, B) Set frequency via keypad, the value is the initial digital set value of the inverter frequency. Setting range: 0.00 Hz–P00.03 (Max. output frequency) Depend	Dag 07	command	9: Set via PROFIBUS / CANopen / DeviceNet		
10: Set via Ethernet communication 11: Set via high speed pulse HDIB 12: Set via pulse string AB 13: Set via EtherCat/Profinet communication 14: Set via PLC card 15: Reserved 0: Max. output frequency 1: A frequency command 0: A 1: B 2: (A+B) 3: (A-B) 4: Max. (A, B) 5: Min. (A, B) When A and B frequency commands are set by keypad, the value is the initial digital set value of the inverter frequency. Setting range: 0.00 Hz–P00.03 (Max. output frequency) P00.11 Acceleration Acceleration Acceleration ime is the time needed for accelerating	P00.07		communication	15	O
12: Set via pulse string AB 13: Set via EtherCat/Profinet communication 14: Set via PLC card 15: Reserved P00.08 Reference object of B frequency command 0: Max. output frequency 1: A frequency command 0: A 1: B 2: (A+B) 3: (A-B) 4: Max. (A, B) 5: Min. (A, B) When A and B frequency commands are set by keypad, the value is the initial digital set value of the inverter frequency. Set frequency P00.11 Acceleration Acceleration Acceleration time is the time needed for accelerating Depend			10: Set via Ethernet communication		
13: Set via EtherCat/Profinet communication 14: Set via PLC card 15: Reserved 0: Max. output frequency 1: A frequency command 0: A 1: B 2: (A+B) 3: (A-B) 4: Max. (A, B) 5: Min. (A, B) When A and B frequency commands are set by keypad, the value is the initial digital set value of the inverter frequency. Set frequency via keypad Acceleration Acceleration Acceleration in the set of the time needed for accelerating in the set of the properties of the time needed for accelerating in the set of the inverter frequency.			11: Set via high speed pulse HDIB		
13: Set via EtherCat/Profinet communication 14: Set via PLC card 15: Reserved 0: Max. output frequency 1: A frequency command 0: A 1: B 2: (A+B) 3: (A-B) 4: Max. (A, B) 5: Min. (A, B) When A and B frequency commands are set by keypad, the value is the initial digital set value of the inverter frequency. Set frequency via keypad Acceleration Acceleration Acceleration in the set of the time needed for accelerating in the property of the property the			12: Set via pulse string AB		
P00.08 Reference object of B frequency command Combination mode of setting source P00.10 Set frequency via keypad Acceleration Acceleration Combination mode of setting source 15: Reserved 0: Max. output frequency 1: A frequency command 0: A 1: B 2: (A+B) 3: (A-B) 4: Max. (A, B) 5: Min. (A, B) When A and B frequency commands are set by keypad, the value is the initial digital set value of the inverter frequency. Setting range: 0.00 Hz–P00.03 (Max. output frequency) Acceleration Depend			13: Set via EtherCat/Profinet communication		
P00.08 Reference object of B frequency command Combination mode of setting source P00.10 Set frequency via keypad Acceleration Acceleration Combination mode of setting source 15: Reserved 0: Max. output frequency 1: A frequency command 0: A 1: B 2: (A+B) 3: (A-B) 4: Max. (A, B) 5: Min. (A, B) When A and B frequency commands are set by keypad, the value is the initial digital set value of the inverter frequency. Setting range: 0.00 Hz–P00.03 (Max. output frequency) Acceleration Depend					
P00.08 of B frequency command O: Max. Output frequency 1: A frequency command O: A 1: B 2: (A+B) 3: (A-B) 4: Max. (A, B) 5: Min. (A, B) When A and B frequency commands are set by keypad, the value is the initial digital set value of the inverter frequency. Set frequency via keypad Acceleration Acceleration Acceleration in Max. Output frequency in Accelerating in Depend O O O O O O O O O O O O O O O O O O O			15: Reserved		
P00.08 of B frequency command O: Max. Output frequency 1: A frequency command O: A 1: B 2: (A+B) 3: (A-B) 4: Max. (A, B) 5: Min. (A, B) When A and B frequency commands are set by keypad, the value is the initial digital set value of the inverter frequency. Set frequency via keypad Acceleration Acceleration Acceleration in Max. Output frequency in Accelerating in Depend O O O O O O O O O O O O O O O O O O O		Reference object			
Combination P00.09 Combination mode of setting source 1: B 2: (A+B) 3: (A-B) 4: Max. (A, B) 5: Min. (A, B) When A and B frequency commands are set by keypad, the value is the initial digital set value of the inverter frequency. Setting range: 0.00 Hz–P00.03 (Max. output frequency) P00.11 Acceleration Acceleration Acceleration Depend	P00.08			0	0
P00.09 Combination mode of setting source 1: B 2: (A+B) 3: (A-B) 4: Max. (A, B) 5: Min. (A, B) When A and B frequency commands are set by keypad, the value is the initial digital set value of the inverter frequency. Setting range: 0.00 Hz–P00.03 (Max. output frequency) P00.11 Acceleration Acceleration Depend		command	1: A frequency command		
P00.09 Combination mode of setting source 2: (A+B) 3: (A-B) 4: Max. (A, B) 5: Min. (A, B) When A and B frequency commands are set by keypad, the value is the initial digital set value of the inverter frequency. Setting range: 0.00 Hz–P00.03 (Max. output frequency) P00.11 Acceleration Acceleration Depend			0: A		
P00.09 mode of setting source 2: (A+B) 3: (A-B) 4: Max. (A, B) 5: Min. (A, B) When A and B frequency commands are set by keypad, the value is the initial digital set value of the inverter frequency. Setting range: 0.00 Hz–P00.03 (Max. output frequency) Acceleration Acceleration Acceleration Acceleration Depend			1: B		
Source 3: (A-B) 4: Max. (A, B) 5: Min. (A, B) When A and B frequency commands are set by keypad, the value is the initial digital set value of the inverter frequency. Setting range: 0.00 Hz–P00.03 (Max. output frequency) Acceleration Acceleration Acceleration Acceleration Acceleration Depend			2: (A+B)	_	
4: Max. (A, B) 5: Min. (A, B) When A and B frequency commands are set by keypad, the value is the initial digital set value of the inverter frequency. Setting range: 0.00 Hz–P00.03 (Max. output frequency) Acceleration Acceleration Acceleration Acceleration Acceleration Acceleration Depend	P00.09	l .	3: (A-B)	0	O
P00.10 Set frequency via keypad Set frequency via heypad Acceleration Set frequency via heypad Acceleration Acceleration Set frequency via inverter frequency. Setting range: 0.00 Hz–P00.03 (Max. output frequency) Acceleration Depend		source	4: Max. (A, B)		
P00.10 Set frequency via keypad When A and B frequency commands are set by keypad, the value is the initial digital set value of the inverter frequency. Setting range: 0.00 Hz–P00.03 (Max. output frequency) Acceleration Acceleration Acceleration Depend			5: Min. (A, B)		
P00.10 Set frequency via keypad inverter frequency. Setting range: 0.00 Hz–P00.03 (Max. output frequency) Acceleration Acceleration time is the time needed for accelerating Depend					
P00.10 Set frequency via keypad inverter frequency. Setting range: 0.00 Hz–P00.03 (Max. output frequency) Acceleration Acceleration time is the time needed for accelerating Depend					
Setting range: 0.00 Hz–P00.03 (Max. output frequency) Acceleration Acceleration time is the time needed for accelerating	P00.10	l	1	50.00Hz	0
frequency) Acceleration Acceleration time is the time needed for accelerating		keypad	' '		
P00.11 Acceleration Acceleration time is the time needed for accelerating Depend			, , ,		
I P00.11 I IAcceleration time is the time needed for accelerating I I O I		Acceleration		Depend	
	P00.11	time 1	Acceleration time is the time needed for accelerating	•	0

Function code	Name	Detailed parameter description	Default value	Modi			
code		from OHz to May, output froquency (DOC 02)	value	fy			
		from 0Hz to Max. output frequency (P00.03). Deceleration time is the time needed from					
		Deceleration time is the time needed from decelerating from Max. output frequency (P00.03) to					
		OHz.					
	Deceleration	Goodrive350 series inverter defines four groups of	Depend				
P00.12	time 1	acceleration and deceleration time, which can be		0			
		selected via multi-function digital input terminals					
		(P05 group). The acceleration/deceleration time of					
		the inverter is the first group by default.					
		Setting range of P00.11 and P00.12: 0.0–3600.0s					
		0: Run in default direction					
P00.13	Running direction	1: Run in reverse direction	0	0			
		2: Reverse running is prohibited					
		Carrier Electro magnetic Noise and leakage Cooling frequency noise current level					
		4					
		1kHz					
		10kHz					
			15kHz ▼ Low ▼ High ▼ High				
					The relation between the model and carrier		
		frequency is shown below.					
		Default value of					
		Model carrier					
D00.44	Carrier frequency	frequency	Depend				
P00.14	setup	1.5–11kW 8kHz	on model	0			
		380V 15–55kW 4kHz					
		Above 75kW 2kHz					
		660V 22–55kW 4kHz					
		Above 75kW 2kHz					
		Advantages of high carrier frequency are as follows:					
		ideal current waveform, few current harmonics and					
		small motor noise.					
		Disadvantages of high carrier frequency are as					
		follows: growing switch consumption, enlarged					
		temperature rise, impacted output capacity; under					
		high carrier frequency, the inverter needs to be					
		derated for use, meanwhile, the leakage current will	i				

Function	Name	Detailed parameter description	Default	
code			value	fy
		increase, which increases electromagnetic		
		interference to the surroundings.		
		While low carrier frequency is the contrary. Low		
		carrier frequency will cause unstable operation at		
		low frequency, decrease the torque, or even lead to oscillation.		
		The carrier frequency of inverter is set properly by		
		default, and it should not be changed by users at will.		
		If the default carrier frequency is exceeded during		
		use, derating is required, derate by 10% for every additional 1k carrier frequency.		
		Setting range: 1.2–15.0kHz		
		0: No operation		
		Rotary autotuning; carry out comprehensive motor		
		parameter autotuning; rotary autotuning is used in		
		cases where high control precision is required;		
		Static autotuning 1 (comprehensive autotuning);		
	Motor parameter	static autotuning 1 is used in cases where the motor		
P00.15	autotuning	cannot be disconnected from load;	0	0
	autoturing	3: Static autotuning 2 (partial autotuning); when		
		current motor is motor 1, only P02.06, P02.07 and		
		P02.08 will be autotuned; when current motor is		
		motor 2, only P12.06, P12.07 and P12.08 will be		
		autotuned.		
		0: Invalid		
		1: Valid during the whole process		
P00.16	AVR function	Automatic voltage regulation function is used to	1	0
1 00.10	711111111111111111111111111111111111111	eliminate the impact on the output voltage of inverter	·	
		when bus voltage fluctuates.		
P00.17	Reserved	Reserved		
		0: No operation		
		1: Restore to default value		
		2: Clear fault history		
	Function	Note: After the selected function operations are		
P00.18	parameter	done, this function code will be restored to 0	0	0
	restoration	automatically. Restoration to default value will clear		
		the user password, this function should be used with		
		caution.		
		oauton.		

Function code	Name	Detailed parameter description	Default value	Modi fy
P01 grou	p Start/stop cor	trol		
P01.00	Running mode of start	O: Direct start 1: Start after DC brake 2: Start after speed-tracking 1 3: Start after speed-tracking 2	0	0
P01.01	Starting frequency of direct start	Starting frequency of direct startup is the initial frequency when the inverter starts. See P01.02 (hold time of starting frequency) for details. Setting range: 0.00–50.00Hz	0.50Hz	0
P01.02	Hold time of starting frequency	Output frequency F1 set by P01.01 T1 set by P01.02 T set by P01.01 T1 set by P01.02 T set by P01.01 T1 set by P01.01 T	0.0s	0
P01.03	DC brake current before start	During starting, the inverter will first perform DC brake based on the set DC brake current before	0.0%	0
P01.04	DC brake time before start	startup, and then it will accelerate after the set DC brake time before startup elapses. If the set DC brake time is 0, DC brake will be invalid. The larger the DC brake current, the stronger the brake force. The DC brake current before startup refers to the percentage relative to rated inverter current. Setting range of P01.03: 0.0–100.0% Setting range of P01.04: 0.00–50.00s	0.00s	0
P01.05	Acceleration/dec eleration mode	This function code is used to select the frequency variation mode during starting and running.	0	0

Function	Name	Detailed parameter description	Default	Modi
code	Nume	Betaned parameter description	value	fy
		0: Straight line; the output frequency increases or		
		decreases in straight line;		
		Output frequency f		
		fmax Time t		
		1: S curve; the output frequency increases or		
		decreases in S curve;		
		S curve is generally used in cases where smooth		
		start/stop is required, eg, elevator, conveyer belt, etc.		
		Output frequency f		
		fmax Time t		
		Note: When set to 1, it is required to set P01.06,		
		P01.07, P01.27 and P01.28 accordingly.		
	Time of starting	The curvature of S curve is determined by		
	section of	acceleration range and acceleration and		
P01.06	acceleration S	deceleration time.	0.1s	0
	curve	Output frequency f		
P01.07	Time of ending section of acceleration S curve	t1=P01.06 t2=P01.07 t3=P01.27 t4=P01.28 Setting range: 0.0–50.0s	0.1s	0
		0: Decelerate to stop; after stop command is valid,		
		the inverter lowers output frequency based on the		
		deceleration mode and the defined deceleration		
P01.08	04	time, after the frequency drops to the stop speed	0	
	Stop mode	(P01.15), the inverter stops.	0	0
		1: Coast to stop; after stop command is valid, the		
		inverter stops output immediately, and the load		
		coasts to stop as per mechanical inertia.		
P01.09	Starting	Starting frequency of DC brake after stop; during	0.00Hz	0

Function			Default	Modi
code	Name	Detailed parameter description	value	fy
	frequency of DC	decelerating to stop, when this frequency is reached,		
	brake after stop	DC brake will be performed after stop.		
	Waiting time of	Demagnetization time (waiting time of DC brake after		
P01.10	DC brake after	stop): Before the DC brake, the inverter will block	0.00s	0
	stop	output, and after the demagnetization time elapses,		
P01.11	DC brake current	DC brake will start. This function is used to prevent	0.0%	0
1 01.11	of stop	overcurrent fault caused by DC brake during high	0.070	
		speed.		
		DC brake current after stop: it means the DC brake		
		force applied, the larger the current, the stronger the		
		DC brake effect.		
P01.12	DC brake time of stop	P01.09 Acceleration Constant speed P13.151 P01.23 P13.14 P01.04 Deceleration P01.10 P01.12 In running	0.00s	0
		Setting range of P01.09: 0.00Hz-P00.03 (Max.		
		output frequency)		
		Setting range of P01.10: 0.00–30.00s		
		Setting range of P01.11: 0.0–100.0%		
		Setting range of P01.12: 0.0–50.0s		
		This function code refers to the transition time of the		
		threshold set by P01.14 during setting		
		forward/reverse rotation of the inverter, as shown		
		below.		
	Deadzone time of	Output frequency f		
P01.13	forward/reverse rotation	Starting frequency Switch over after starting frequency Switch over after zero frequency Time t	0.0s	0
		Setting range: 0.0–3600.0s		
	Forward/reverse	0: Switch over after zero frequency		
P01.14	rotation	1: Switch over after starting frequency	0	0
	switch-over mode	2: Switch over after passing stop speed and delay		
P01.15	Stop speed	0.00–100.00Hz	0.50Hz	0
P01.16	Stop speed	0: Set value of speed (the only detection mode valid	0	0

Function code	Name	Detailed parameter description	Default value	Modi fy
	detection mode	in SVPWM mode)		
		1: Detection value of speed		
P01.17	Stop speed detection time	0.00–100.00s	0.50s	0
P01.18	Running protection of power-on terminal	When the running command channel is controlled by terminals, the system will detect running terminal state automatically during power up. 0: Terminal running command is invalid during power up. The inverter will not run during power up even if the running command terminal is detected to be valid, and the system is in running protection state. The inverter will run only after this terminal is cancelled and enabled again. 1: Terminal running command is valid during power up. The system will start the inverter automatically after initialization is done if the running command terminal is detected to be valid during power up. Note: This function must be set with caution, otherwise, serious consequences may occur.	0	0
P01.19	Action selection when the running frequency is below lower limit (lower limit should be larger than 0)	This function code is used to set the running state of inverter when the set frequency is below lower limit frequency. 0: Run in lower limit of the frequency 1: Stop 2: Sleep When the set frequency is below lower limit frequency, the inverter coasts to stop; when the set frequency is above lower limit again and continues to be so after the time set by P01.20 elapses, the inverter will be restored to running state automatically.	0	0
P01.20	Wake-up-from-sl eep delay	This function code is used to set the sleep delay. When the running frequency of inverter is below the lower limit frequency, the inverter enters sleep state; when the set frequency is above the lower limit again and continues to be so after the time set by P01.20 elapses, the inverter will run automatically.	0.0s	0

Function	Name	Detailed parameter description	Default	Modi
code	Name	Detailed parameter description	value	fy
		Output frequency f t1 <t2, (valid="" 0.0–3600.0s="" 2)="" automatic="" code="" does="" function="" inverter="" is="" l3="" not="" of="" p.01.19="" range:="" run="" running="" runs="" sets="" setting="" sleep="" t="" t1+t2="t3," t3="P01.20" td="" the="" the<="" this="" time="" when=""><td></td><td></td></t2,>		
P01.21	Restart after power cut	inverter at next power-on after power down. 0: Disabled restart 1: Enable restart, namely the inverter will run automatically after the time set by P01.22 elapses if the starting conditions are met.	0	0
P01.22	Waiting time of restart after power cut	This function code sets the waiting time before automatically running at next power-on after power down. Output frequency 11=P01.22 12=P01.23 Running Power of Setting range: 0.0–3600.0s (valid when P01.21 is 1)	1.0s	0
P01.23	Start delay Stop speed delay	This function code sets the delay of the inverter's wake-up-from-sleep after running command is given, the inverter will start to run and output after the time set by P01.23 elapses to realize brake release. Setting range: 0.0–600.0s	0.0s	0 0
P01.25	Open-loop 0Hz output selection	O: No voltage output U: With voltage output C: Output as per DC brake current of stop	0	0
P01.26	Deceleration time of emergency-stop	0.0–60.0s	2.0s	0
P01.27	Time of starting section of deceleration S curve	0.0–50.0s	0.1s	0

Function	Name	Detailed parameter description		Modi
code	Time of anding		value	fy
P01.28	Time of ending section of deceleration S curve	0.0–50.0s	0.1s	0
P01.29	Short-circuit brake current	When the inverter starts in direct start mode (P01.00=0), set P01.30 to a non-zero value to enter	0.0%	0
P01.30	Hold time of short-circuit brake at startup	short-circuit brake. During stop, if the running frequency of inverter is below the starting frequency of brake after stop, set	0.00s	0
P01.31	Hold time of short-circuit brake at stop	P01.31 to a non-zero value to enter short-circuit brake after stop, and then carry out DC brake in the time set by P01.12 (refer to P01.09–P01.12). Setting range of P01.29: 0.0–150.0% (inverter) Setting range of P01.30: 0.0–50.0s Setting range of P01.31: 0.0–50.0s	0.00s	0
P01.32-	Reserved	0–65535	0	
P01.34	variables	0-0000	U	
P02 grou	p Parameters of	f motor 1		
P02.00	Type of motor 1	Asynchronous motor Synchronous motor	0	0
P02.01	Rated power of asynchronous motor 1	0.1–3000.0kW	Depend on model	0
P02.02	Rated frequency of asynchronous motor 1	0.01Hz-P00.03 (Max. output frequency)	50.00Hz	0
P02.03	Rated speed of asynchronous motor 1	1–36000rpm	Depend on model	0
P02.04	Rated voltage of asynchronous motor 1	0–1200V	Depend on model	0
P02.05	Rated current of asynchronous motor 1	0.8–6000.0A	Depend on model	0
P02.06	Stator resistance of asynchronous motor 1	0.001–65.535Ω	Depend on model	0

Function	Name	Detailed parameter description	Default	Modi
code	110.1110	Zotaliou paralition accompliant	value	fy
P02.07	Rotor resistance		Depend	
	of asynchronous	0.001–65.535Ω	on model	0
	motor 1			
P02.08	Leakage	0.1–6553.5Mh	Depend on model	0
	inductance of			
	asynchronous			
	motor 1			
	Mutual		Depend on model	0
P02.09	inductance of	0.1–6553.5Mh		
1 02.09	asynchronous	0.1-0333.3WII		
	motor 1			
	No-load current		Depend	
P02.10	of asynchronous	0.1–6553.5A	on model	0
	motor 1		on model	
	Magnetic		00.00/	0
	saturation			
P02.11	coefficient 1 of	0.0.100.09/		
P02.11	iron core of	0.0–100.0%	80.0%	0
	asynchronous			
	motor 1			
	Magnetic	0.0–100.0%	68.0%	0
	saturation			
P02.12	coefficient 2 of			
P02.12	iron core of		00.0%	0
	asynchronous			
	motor 1			
	Magnetic	0.0–100.0%	57.0%	0
	saturation			
P02.13	coefficient 3 of			
FU2.13	iron core of			
	asynchronous			
	motor 1			
	Magnetic	0.0–100.0%	40.0%	0
P02.14	saturation			
	coefficient 4 of			
	iron core of			
	asynchronous			
	motor 1			

Function	Name	Detailed parameter description		Modi
code	Data da assesa af		value	fy
P02.15	Rated power of	0.4. 2000 0KW	Depend	0
	synchronous	0.1–3000.0KW	on model	0
	motor 1			
P02.16	Rated frequency	0.01Hz, D00.03 (May, output fraguency)	50.00Hz	0
	of synchronous motor 1	0.01Hz–P00.03 (Max. output frequency)	50.00HZ	0
	Number of pole			
	pairs of	1–128	2	0
P02.17	synchronous			
	motor 1			
	Rated voltage of			
P02.18	synchronous	0–1200V	Depend on model	0
	motor 1			
	Rated current of		Depend on model	0
P02.19	synchronous	0.8–6000.0A		
	motor 1			
	Stator resistance			
P02.20	of synchronous	0.001–65.535Ω	Depend	0
	motor 1		on model	
	Direct-axis	0.01–655.35Mh	Depend on model	0
P02.21	inductance of			
102.21	synchronous			
	motor 1			
	Quadrature-axis	0.01–655.35Mh	Depend on model	0
P02.22	inductance of			
1 02.22	synchronous			
	motor 1			
	Counter-emf	0–10000	300	0
P02.23	constant of			
. 02.20	synchronous			
	motor 1			
P02.24	Reserved	0x0000-0xFFFF	0	•
P02.25	Reserved	0%–50% (rated motor current)	10%	•
P02.26		0: No protection		
	Overload	1: Common motor (with low-speed compensation).		
	protection of	As the cooling effect of common motor will be	2	0
	motor 1	degraded in low speed, the corresponding electronic		
		thermal protection value should also be adjusted		

Function code	Name	Detailed parameter description	Default value	Modi fy
3000		properly, the low compensation here means to lower the overload protection threshold of the motor whose running frequency is below 30Hz. 2: Frequency-variable motor (without low speed compensation). As the cooling effect of frequency-variable motor is not affected by the rotating speed, there is no need to adjust the protection value during low speed running.	value	.,,
P02.27	Overload protection coefficient of motor 1	Motor overload multiples M=lout/(lnxK) In is rated motor current, lout is inverter output current, K is motor overload protection coefficient. The smaller the K, the larger the value of M, and the easier the protection. M=116%: protection will be applied when motor overloads for 1h; M=200%: protection will be applied when motor overloads for 60s; M>=400%: protection will be applied immediately. Time t 1h Motor overload multiple 200% Setting range: 20.0%—120.0%	100.0%	0
P02.28	Power display calibration coefficient of motor 1	This function adjusts the power display value of motor 1 only, and it does not affect the control performance of the inverter. Setting range: 0.00–3.00	1.00	0
P02.29	Parameter display of motor 1	O: Display as per motor type; under this mode, only parameters related to current motor type will be displayed. The display all; under this mode, all the motor parameters will be displayed.	0	0
P02.30	System inertia of motor 1	0–30.000kgm2	0	0
P02.31- P02.32	Reserved variables	0–65535	0	0
P03 grou	p Vector contro	l of motor 1		

Function code	Name	Detailed parameter description	Default value	Modi fy
P03.00	Speed loop proportional gain 1	Parameters of P03.00–P03.05 fit for vector control mode only. Below P03.02, speed loop PI parameter	20.0	0
P03.01	Speed loop integral time 1	is P03.00 and P03.01; above P03.06, speed loop PI parameter is P03.03 and P03.04; in between, PI	0.200s	0
P03.02	Switch low point frequency	parameter is obtained by linear variation between two groups of parameters, as shown below.	5.00Hz	0
P03.03	Speed loop proportional gain 2	PI parameter P03.00, P03.01	20.0	0
P03.04	Speed loop integral time 2	P03.03, P03.04 Output frequency <u>f</u>	0.200s	0
P03.05	point frequency	P03.02 P03.05 The speed loop dynamic response characteristics of vector control can be adjusted by setting the proportional coefficient and integral time of speed regulator. Increase proportional gain or decrease integral time can accelerate dynamic response of speed loop, however, if the proportional gain is too large or integral time is too small, system oscillation and overshoot may occur; if proportional gain is too small, stable oscillation or speed offset may occur. Speed loop PI parameter is closely related to the system inertial, users should make adjustment based on default PI parameter according to different load characteristics to fulfill different needs. Setting range of P03.00:0.0–200.0; Setting range of P03.01: 0.000–10.000s Setting range of P03.03: 0.0–200.0 Setting range of P03.04: 0.000–10.000s Setting range of P03.04: 0.000–10.000s Setting range of P03.05: P03.02–P00.03 (Max. output frequency)	10.00Hz	0
P03.06	Speed loop output filter	0-8 (corresponds to 0-2^8/10ms)	0	0
P03.07	Vector control slip compensation coefficient	Slip compensation coefficient is used to adjust the slip frequency of vector control to improve speed control precision. This parameter can be used to control speed offset.	100%	0

Function code	Name	Detailed parameter description	Default value	Modi fy
Code	(motoring)	Setting range: 50–200%	Value	·y
P03.08	Vector control slip compensation coefficient (generating)		100%	0
P03.09	Current loop proportional coefficient P	Note: 1. These two parameters are used to adjust PI parameters of current loop; it affects dynamic	1000	0
P03.10	Current loop integral coefficient I	response speed and control precision of the system directly. The default value needs no adjustment under common conditions; 2. Fit for SVC mode 0 (P00.00=0) and VC mode (P00.00=3); 3. The value of this function code will be updated automatically after parameter autotuning of synchronous motor is done. Setting range: 0–65535	1000	0
P03.11	Torque setup mode selection	0–1: Set via keypad (P03.12) 2: Set via Al1 (100% corresponds to three times of rated motor current) 3: Set via Al2 (the same as above) 4: Set via Al3 (the same as above) 5: Set via pulse frequency HDIA (the same as above) 6: Set via multi-step torque (the same as above) 7: Set via MODBUS communication (the same as above) 8: Set via PROFIBUS/CANopen/DeviceNet communication (the same as above) 9: Set via Ethernet communication (the same as above) 10: Set via pulse frequency HDIB (the same as above) 11: Set via EtherCat/Profinet communication 12: Set via PLC	0	0
P03.12	Torque set by keypad	-300.0%–300.0% (rated motor current)	20.0%	0

Function	Name	Detailed parameter description	Default	
P03.13	Torque reference	0.000–10.000s	value 0.010s	fy O
P03.14	Source of upper limit frequency setup of forward rotation in torque control	0: Keypad (P03.16) 1: Al1 (100% corresponds to max. frequency) 2: Al2 (the same as above) 3: Al3 (the same as above) 4: Pulse frequency HDIA (the same as above) 5: Multi-step (the same as above) 6: MODBUS communication (the same as above) 7: PROFIBUS /CANopen/ DeviceNet communication (the same as above) 8: Ethernet communication (the same as above) 9: Pulse frequency HDIB (the same as above) 10: EtherCat/Profinet communication 11: PLC 12: Reserved	0	0
P03.15	Source of upper limit frequency setup of reverse rotation in torque control	0: Keypad (P03.17) 1: Al1 (100% corresponds to max. frequency) 2: Al2 (the same as above) 3: Al3 (the same as above) 4: Pulse frequency HDIA (the same as above) 5: Multi-step (the same as above) 6: MODBUS communication (the same as above) 7: PROFIBUS /CANopen/ DeviceNet communication (the same as above) 8: Ethernet communication (the same as above) 9: Pulse frequency HDIB (the same as above) 10: EtherCat/Profinet communication 11: PLC 12: Reserved Note: Source 1-11, 100% relative to the max. frequency	0	0
P03.16	Keypad limit value of upper limit frequency of forward rotation in torque control	This function code is used to set frequency limit. 100% corresponds to the max. frequency. P03.16 sets the value when P03.14=1; P03.17 sets the value when P03.15=1.	50.00Hz	0
P03.17	Max. output frequency	Setting range: 0.00Hz-P00.03 (Max. output frequency)	50.00Hz	0

Function	Nama	Detailed wavenester description	Default	Modi
code	Name	Detailed parameter description	value	fy
P03.18	Source of upper limit setup of the torque during motoring	0: Keypad (P03.20) 1: Al1 (100% relative to three times of motor current) 2: Al2 (the same as above) 3: Al3 (the same as above) 4: Pulse frequency HDIA (the same as above) 5: MODBUS communication (the same as above) 6: PROFIBUS/CANopen/DeviceNet communication (the same as above) 7: Ethernet communication (the same as above) 8: Pulse frequency HDIB (the same as above) 9: EtherCat/Profinet communication 10: PLC 11: Reserved	0	0
P03.19	Source of upper limit setup of brake torque	0: Keypad (P03.21) 1: Al1 (100% relative to three times of motor current) 2: Al2 (the same as above) 3: Al3 (the same as above) 4: Pulse frequency HDIA (the same as above) 5: MODBUS communication (the same as above) 6: PROFIBUS/CANopen/DeviceNet communication (the same as above) 7: Ethernet communication (the same as above) 8: Pulse frequency HDIB (the same as above) 9: EtherCat/Profinet communication 10: PLC 11: Reserved	0	0
P03.20	Set upper limit of the torque when motoring via keypad	This function code is used to set torque limit. Setting range: 0.0–300.0% (rated motor current)	180.0%	0
P03.21	Set upper limit of brake torque via keypad	3 × 3 × × × × × × × × × × × × × × × × ×	180.0%	0
P03.22	Flux-weakening coefficient of constant-power zone	Used when asynchronous motor is in flux-weakening control.	0.3	0
P03.23	Min. flux-weakening		20%	0

Function		5.9.1	Default	Modi
code	Name	Detailed parameter description	value	fy
	point of	Т		
	constant-power			
	zone	Flux-weakening		
		coefficient of motor		
		1.0		
		2.0 f		
		Min. flux-weakening limit of motor		
		P03.22 and P03.23 are valid during constant power.		
		When motor speed is above rated speed, motor		
		enters flux-weakening running state. The		
		flux-weakening control coefficient can change the		
		flux-weakening curvature, the larger the coefficient,		
		the steeper the curve, the smaller the coefficient, the		
		smoother the curve.		
		Setting range of P03.22: 0.1–2.0		
		Setting range of P03.23: 10%–100%		
		P03.24 sets the maximum output voltage of the		
P03.24	Max voltage limit	inverter, which is the percentage of rated motor voltage. This value should be set according to field	100.0%	0
F 03.24	iviax. Voltage III III	conditions.	100.076	
		Setting range:0.0–120.0%		
		Carry out motor pre-exciting during starting to build a		
		magnetic field inside the motor to improve the torque		
P03.25	Pre-exciting time	characteristics of motor during starting.	0.300s	0
		Setting range: 0.000–10.000s		
	Flux-weakening			
P03.26	proportional gain	0–8000	1000	0
	Vector control	0: Display as per actual value		
P03.27	speed display	1: Display as per the set value	0	0
	Static friction			
P03.28	compensation	0.0–100.0%	0.0%	0
	coefficient			
	Corresponding			
P03.29	frequency point	0.50- P03.31	1.00Hz	0
	of static friction			
	High speed			
P03.30	friction	0.0–100.0%	0.0%	0
	compensation			

Function code	Name	Detailed parameter description	Default value	Modi fy
	coefficient			
P03.31	Corresponding frequency of high speed friction torque	P03.29–400.00Hz	50.00Hz	0
P03.32	Torque control	0:Disable	0	0
	enable	1:Enable		
P03.33– P03.34	Reserved variables	0–65535	0	•
P03.35	Control optimization setting	Ones place: Reserved 0: Reserved 1: Reserved Tens place: Reserved 0: Reserved 1: Reserved Hundreds place: ASR integral separation enabling 0: Disabled 1: Enabled Thousands place: Reserved 0: Reserved 1: Reserved Range: 0x0000-0x1111	0x0000	0
P03.36	Speed loop differential gain	0.00–10.00s	0.00s	0
P03.37	High-frequency current loop proportional coefficient	Under closed-loop vector control mode (P00.00=3) and P03.39, the current loop PI parameters are	1000	0
P03.38	High-frequency current loop integral coefficient	P03.09 and P03.10; above P03.39, the PI parameters are P03.37 and P03.38. Setting range of P03.37: 0–20000 Setting range of P03.38: 0–20000 Setting range of P03.39: 0.0–100.0% (relative to	1000	0
P03.39	Current loop high-frequency switch-over point	Setting range of P03.39: 0.0–100.0% (relative to nax. frequency)	100.0%	0
P03.40	Inertia compensation enable	0: Disable 1: Enable	0	0

Function	Name	Detailed parameter description	Default	Modi
code	Name	Detailed parameter description	value	fy
	Upper limit of	Limit the max. inertia compensation torque to		
P03.41	inertia	prevent inertia compensation torque from being too	10.0%	0
1 03.41	compensation	large.	10.070	0
	torque	Setting range: 0.0–150.0% (rated motor torque)		
	Inertia	Filter times of inertia compensation torque, used to		
P03.42	compensation	smooth inertia compensation torque.	7	0
	filter times	Setting range: 0–10		
	Inertia	Due to friction force, it is required to set certain		
P03.43	identification	identification torque for the inertia identification to be	10.0%	0
1 03.43	torque value	performed properly.	10.076	
	torque value	0.0-100.0% (rated motor torque)		
P03.44	Enable inertia	0: No operation	0	0
1 03.44	identification	1: Start identification	0	•
P03.45-	Reserved	0–65535	0	
P03.46	variables	0 00000		
P04 grou	p V/F control			
		This group of function code defines the V/F curve of		
		motor 1 to satisfy different load characteristics		
		needs.		
		0: Straight V/F curve; fit for constant-torque load		
		1: Multi-point V/F curve		
		2: Torque down V/F curve (1.3 th order)		
		3: Torque down V/F curve (1.7 th order)		
		4: Torque down V/F curve (2.0 nd order)		
		Curve 2-4 are suitable for torque-variable load of fan		
	V/F curve setup	pump and similar equipment. Users can make		
P04.00	of motor 1	adjustment based on load characteristics to achieve	0	0
	OI IIIOIOI I	optimal energy-saving effect.		
		5: Customized V/F (V/F separation); under this		
		mode, V is separated from f. Users can adjust f		
		through the frequency reference channel set by		
		P00.06 to change the curve characteristic, or adjust		
		V through the voltage reference channel set by		
		P04.27 to change the curve characteristics.	o o o o o o o o o o o o o o o o o o o	
		Note: The $V_{\mbox{\scriptsize b}}$ in the figure below corresponds to		
		rated motor voltage, and f_b corresponds to rated		
		motor frequency.		

Function	Name	Detailed parameter description	Default	Modi
code	Name	· ·	value	fy
		Output voltage Torque step-down V/F curve (1.3 th order) Torque step-down V/F curve (1.7 th order) Torque step-down V/F curve (2.0 nd order) Square type Qutput frequency		
P04.01	Torque boost of motor 1	In order to compensate for low-frequency torque characteristics, users can make some boost	0.0%	0
P04.02	Motor 1 torque boost cut-off	compensation to the output voltage. P04.01 is relative to the maximum output voltage V _b . P04.02 defines the percentage of cut-off frequency of manual torque boost to the rated motor frequency torque characteristics of V/F. Users should select torque boost based on the load, eg, larger load requires larger torque boost, however, if the torque boost is too large, the motor will run at over-excitation, which will cause increased output current and motor heat-up, thus degrading the efficiency. When torque boost is set to 0.0%, the inverter is automatic torque boost. Torque boost cut-off threshold: Below this frequency threshold, the torque boost is valid, exceeding this threshold will nullify torque boost. Setting range of P04.01: 0.0%: (automatic) 0.1%—10.0% Setting range of P04.02: 0.0%—50.0%	20.0%	0
P04.03	V/F frequency point 1 of motor 1	When P04.00 =1 (multi-point V/F curve), users can set V/F curve via P04.03–P04.08.	0.00Hz	0
P04.04	V/F voltage point 1 of motor 1		00.0%	0
P04.05	V/F frequency	Note: V1 <v2<v3, f1<f2<f3.="" if="" low-frequency="" td="" voltage<=""><td>0.00Hz</td><td>0</td></v2<v3,>	0.00Hz	0

Function code	Name	Detailed parameter description	Default value	Modi fy
	point 2 of motor 1	is set too high, motor overheat or burnt-down may		- ,
P04.06	V/F voltage point 2 of motor 1	occur, and overcurrent stall or overcurrent protection may occur to the inverter.	0.0%	0
P04.07	V/F frequency point 3 of motor 1	Output voltage 100.0% V _b	0.00Hz	0
		V2		
P04.08	V/F voltage point 3 of motor 1	voltage of motor 1) Setting range of P04.05: P04.03–P04.07 Setting range of P04.06: 0.0%–110.0% (rated voltage of motor 1) Setting range of P04.07: P04.05–P02.02 (rated frequency of asynchronous motor 1) or P04.05–P02.16 (rated frequency of synchronous motor 1) Setting range of P04.08: 0.0%–110.0% (rated voltage of motor 1)	00.0%	0
P04.09	V/F slip compensation gain of motor 1	This parameter is used to compensate for the motor rotating speed change caused by load change in the SVPWM mode, and thus improve the rigidity of the mechanical characteristics of the motor. You need to calculate the rated slip frequency of the motor as follows: \$\times f=\text{fb-nxp/60}\$ where fb is the rated frequency of motor 1, corresponding to P02.02; n is the rated speed of motor 1, corresponding to P02.03; p is the number of pole pairs of motor 1. 100% corresponds to the rated slip frequency \$\times f\$ of motor 1. Setting range: 0.0-200.0%	0.0%	0
P04.10		Under SVPWM control mode, the motor, especially the large-power motor may experience current oscillation during certain frequencies, which may	10	0
P04.11	High-frequency	lead to unstable motor operation, or even inverter overcurrent, users can adjust these two parameters	10	0

Function code	Name	Detailed parameter description	Default value	Modi fy
	factor of motor 1	properly to eliminate such phenomenon.		
P04.12	Oscillation control threshold of motor 1	Setting range of P04.10: 0–100 Setting range of P04.11: 0–100 Setting range of P04.12: 0.00Hz–P00.03 (Max.	30.00Hz	0
P04.13	V/F curve setup of motor 2	output frequency) This parameter defines the V/F curve of motor 2 of the Goodrive350 series to meet various load characteristic requirements. 0: Straight V/F curve; 1: Multi-point V/F curve 2: Torque-down V/F curve (1.3 th order) 3: Torque-down V/F curve (1.7 th order) 4: Torque-down V/F curve (2.0 nd order) 5: Customize V/F (V/F separation)	0	0
P04.14	Torque boost of motor 2	Note: Refer to the parameter description of P04.01 and P04.02.	0.0%	0
P04.15	Motor 2 torque boost cut-off	Setting range of P04.14: 0.0%: (automatic) 0.1%–10.0% Setting range of 0.0%–50.0% (relative to rated frequency of motor 2)	20.0%	0
P04.16	V/F frequency point 1 of motor 2	Note: Refer to the parameter description of P04.03–P04.08	0.00Hz	0
P04.17	V/F voltage point 1 of motor 2	Setting range of P04.16: 0.00Hz–P04.18 Setting range of P04.17:0.0%–110.0% (rated voltage	00.0%	0
P04.18	V/F frequency point 2 of motor 2	of motor 2) Setting range of P04.18: P04.16–P04.20	0.00Hz	0
P04.19	V/F voltage point 2 of motor 2	Setting range of P04.19: 0.0%–110.0% (rated voltage of motor 2)	00.0%	0
P04.20	V/F frequency point 3 of motor 2	Setting range of P04.20: P04.18–P12.02 (rated frequency of asynchronous motor 2) or P04.18–	0.00Hz	0
P04.21	V/F voltage point 3 of motor 2	P12.16 (rated frequency of synchronous motor 2) Setting range of P04.21:0.0%–110.0%(rated voltage of motor 2)	00.0%	0
P04.22	V/F slip compensation gain of motor 2	This parameter is used to compensate for the motor rotating speed change caused by load change in the SVPWM mode, and thus improve the rigidity of the mechanical characteristics of the motor. You need to calculate the rated slip frequency of the motor as follows:	0.0%	0

Function			Default	Modi
code	Name	Detailed parameter description	value	fy
		△f=fb-n*p/60		
		where fb is the rated frequency of motor 2,		
		corresponding to P12.02; n is the rated speed of		
		motor 2, corresponding to P12.03; p is the number of		
		pole pairs of motor 2. 100% corresponds to the rated		
		slip frequency $\triangle f$ of motor 2.		
		Setting range: 0.0–200.0%		
	Low-frequency	In the SVPWM mode, current oscillation may easily		
P04.23	oscillation control	occur on motors, especially large-power motors, at	10	0
	factor of motor 2	some frequency, which may cause unstable running		
	High-frequency	of motors or even overcurrent of inverters. You can		
P04.24	oscillation control	modify this parameter to prevent current oscillation.	10	0
	factor of motor 2	Setting range of P04.23: 0-100		
	Oscillation	Setting range of P04.24: 0–100		
P04.25	control threshold	Setting range of P04.25: 0.00 Hz-P00.03 (Max.	30.00Hz	0
	of motor 2	output frequency)		
		0: No action		
	Energy-saving run	1: Automatic energy-saving operation		
P04.26		Under light-load state, the motor can adjust the	0	0
		output voltage automatically to achieve		
		energy-saving purpose		
		0: Keypad; output voltage is determined by P04.28		
		1: Al1		
		2: AI2		
		3: Al3		
		4: HDIA		
		5: Multi-step (the set value is determined by P10		
	Channel of	group)		
P04.27	voltage setup	6: PID	0	0
	voltage setup	7: MODBUS communication		
		8: PROFIBUS/CANopen/DeviceNet communication		
		9: Ethernet communication		
		10: HDIB		
		11: EtherCat/Profinet communication		
		12: PLC programmable card		
		13: Reserved		
	Set voltage value	When the channel for voltage setup is set to		
P04.28	-	"keypad", the value of this function code is digital	100.0%	0
	via keypad	voltage set value.		

Function code	Name	Detailed parameter description	Default value	Modi fy
		Setting range: 0.0%–100.0%		
P04.29	Voltage increase time	Voltage increase time means the time needed from outputting the min. voltage to accelerating to output	5.0s	0
P04.30	Voltage decrease time	the max. voltage. Voltage decrease time means the time needed from outputting max. voltage to outputting the min. voltage Setting range: 0.0–3600.0s	5.0s	0
P04.31	Output max. voltage	Set the upper/lower limit value of output voltage.	100.0%	0
P04.32	Output min. voltage	Vmax V set Vmin Vmin Vmin Vmin 12-P04.30 Vmin 12-P04.30 Vmin 12-P04.30 Vmin 12-P04.30 Vmin Vmin 12-P04.30 Vmin	0.0%	0
P04.33	Flux-weakening coefficient in the constant power zone	1.00–1.30	1.00	0
P04.34	Input current 1 in synchronous motor VF control	When the synchronous motor VF control mode is enabled, this parameter is used to set the reactive current of the motor when the output frequency is lower than the frequency set in P04.36. Setting range: -100.0%—+100.0% (of the rated current of the motor)	20.0%	0
P04.35	Input current 2 in synchronous motor VF control	When the synchronous motor VF control mode is enabled, this parameter is used to set the reactive current of the motor when the output frequency is higher than the frequency set in P04.36. Setting range: -100.0%—+100.0% (of the rated current of the motor)	10.0%	0
P04.36	Frequency threshold for input current switching in synchronous	When the synchronous motor VF control mode is enabled, this parameter is used to set the frequency threshold for the switching between input current 1 and input current 2. Setting range: 0.00 Hz–P00.03 (Max. output	50.00Hz	0

Function code	Name	Detailed parameter description	Default value	Modi fy
	motor VF control	frequency)		Í
P04.37	Reactive current closed-loop proportional coefficient in synchronous motor VF	When the synchronous motor VF control mode is enabled, this parameter is used to set the proportional coefficient of the reactive current closed-loop control. Setting range: 0–3000	50	0
P04.38	Reactive current closed-loop integral time in synchronous motor VF control	When the synchronous motor VF control mode is enabled, this parameter is used to set the integral coefficient of the reactive current closed-loop control. Setting range: 0–3000	30	0
P04.39	Reactive current closed-loop output limit in synchronous motor VF control	When the synchronous motor VF control mode is enabled, this parameter is used to set the output limit of the reactive current in the closed-loop control. A greater value indicates a higher reactive closed-loop compensation voltage and higher output power of the motor. In general, you do not need to modify this parameter. Setting range: 0–16000	8000	0
P04.40	Enable/disable IF mode for asynchronous motor 1	0: Disabled 1: Enabled	0	0
P04.41	Current setting in IF mode for asynchronous motor 1	When IF control is adopted for asynchronous motor 1, this parameter is used to set the output current. The value is a percentage in relative to the rated current of the motor. Setting range: 0.0–200.0%	120.0%	0
P04.42	Proportional coefficient in IF mode for asynchronous motor 1	When IF control is adopted for asynchronous motor 1, this parameter is used to set the proportional coefficient of the output current closed-loop control. Setting range: 0–5000	650	0
P04.43	Integral coefficient in IF mode for asynchronous	When IF control is adopted for asynchronous motor 1, this parameter is used to set the inetgral coefficient of the output current closed-loop control. Setting range: 0–5000	350	0

Function code	Name	Detailed parameter description	Default value	Modi fy
	motor 1			.,
P04.44	Frequency threshold for switching off IF mode for asynchronous motor 1	When IF control is adopted for asynchronous motor 1, this parameter is used to set the frequency threshold for switching off the output current closed-loop control. When the frequency is lower than the value of this parameter, the current closed-loop control in the IF control mode is enabled; and when the frequency is higher than that, the current closed-loop control in the IF control mode is disabled. Setting range: 0.00–20.00 Hz	10.00Hz	0
P04.45	Enable/disable IF mode for asynchronous motor 2	0: Disabled 1: Enabled	0	0
P04.46	Current setting in IF mode for asynchronous motor 2	When IF control is adopted for asynchronous motor 2, this parameter is used to set the output current. The value is a percentage in relative to the rated current of the motor. Setting range: 0.0–200.0%	120.0%	0
P04.47	Proportional coefficient in IF mode for asynchronous motor 2	When IF control is adopted for asynchronous motor 2, this parameter is used to set the proportional coefficient of the output current closed-loop control. Setting range: 0–5000	650	0
P04.48	Integral coefficient in IF mode for asynchronous motor 2	When IF control is adopted for asynchronous motor 2, this parameter is used to set the inetgral coefficient of the output current closed-loop control. Setting range: 0–5000	350	0
P04.49	Frequency threshold for switching off IF mode for asynchronous motor 2	When IF control is adopted for asynchronous motor 2, this parameter is used to set the frequency threshold for switching off the output current closed-loop control. When the frequency is lower than the value of this parameter, the current closed-loop control in the IF control mode is enabled; and when the frequency is higher than that, the current closed-loop control in the IF control mode is	10.00Hz	0

Function code	Name	Detailed parameter description	Default value	Modi fy
		disabled.		
		Setting range: 0.00–20.00 Hz		
P04.50	Reserved variable	0–65535	0	•
P04.51	Reserved variable	0–65535	0	•
P05 grou	p Input terminal	s		
		0x00–0x11		
		Ones: HDIA input type		
		0: HDIA is high-speed pulse input		
P05.00	HDI input type	1: HDIA is digital input	0	0
		Tens: HDIB input type		
		0: HDIB is high-speed pulse input		
		1: HDIB is digital input		
D05.04	Function of S1	0: No function	_	
P05.01	terminal	1: Forward running	1	0
D05.00	Function of S2	2: Reverse running		
P05.02	terminal	3: 3-wire control/Sin	4	0
D05.00	Function of S3	4: Forward jogging	_	
P05.03	terminal	5: Reverse jogging	7	0
D05.04	Function of S4	6: Coast to stop	0	
P05.04	terminal	7: Fault reset	0	0
DOE 05	Function of HDIA	8: Running pause	0	
P05.05	terminal	9: External fault input	0	0
		10: Frequency increase (UP)		
		11: Frequency decrease (DOWN)		
		12: Clear frequency increase/decrease setting		
		13: Switch-over between setup A and setup B		
		14: Switch-over between combination setup and		
		setup A		
	Function of HDIB	15: Switch-over between combination setup and		
P05.06	terminal	setup B	0	0
	terriiriai	16: Multi-step speed terminal 1		
		17: Multi-step speed terminal 2		
		18: Multi-step speed terminal 3		
		19: Multi-step speed terminal 4		
		20: Multi-step speed pause		
		21: Acceleration/deceleration time selection 1		
		22: Acceleration/deceleration time selection 2		

Function			Default	Modi
code	Name	Detailed parameter description	value	fy
5545		23: Simple PLC stop reset	raido	.,
		24: Simple PLC pause		
		25: PID control pause		
		26: Wobbling frequency pause		
		27: Wobbling frequency reset		
		28: Counter reset		
		29: Switch-over between speed control and torque		
		control		
		30: Acceleration/deceleration disabled		
		31: Counter trigger		
		32: Reserved		
		33: Clear frequency increase/decrease setting		
		temporarily		
		34: DC brake		
		35: Switch-over between motor 1 and motor 2		
		36: Command switches to keypad		
		37: Command switches to terminal		
		38: Command switches to communication		
		39: Pre-exciting command		
		40: Zero out power consumption quantity		
		41: Maintain power consumption quantity		
		42: Source of upper torque limit switches to keypad		
		43: Position reference point input (only S6, S7 and		
		S8 are valid)		
		44: Spindle orientation disabled		
		45: Spindle zeroing/local positioning zeroing		
		46: Spindle zero position selection 1		
		47: Spindle zero position selection 2		
		48: Spindle scale division selection 1		
		49: Spindle scale division selection 2		
		50: Spindle scale division selection 3		
		51: Position control and speed control switch-over		
		terminal		
		52: Pulse input disabled		
		53: Clear position deviation cleared		
		54: Switch over position proportional gain		
		55: Enable cyclic positioning of digital position		
		positioning		
		56: Emergency stop		

Function		5.11.1	Default	Modi
code	Name	Detailed parameter description	value	fy
		57: Motor over-temperature fault input		
		58: Enable rigid tapping		
		59: Switches to V/F control		
		60: Switches to FVC control		
		61: PID polarity switch-over		
		62: Reserved		
		63: Enable servo		
		64: Limit of forward run		
		65: Limit of reverse run		
		66: Zero out encoder counting		
		67: Pulse increase		
		68: Enable pulse superimposition		
		69: Pulse decrease		
		70: Electronic gear selection		
		71–79: Reserved		
P05.07	Reserved	0–65535	0	
1 03.07	variables	0-0000		
	Polarity of input terminal	This function code is used to set the polarity of input		
		terminals.		
		When the bit is set to 0, input terminal polarity is		
P05.08		positive;	0x000	0
		When the bit is set to 1, input terminal polarity is		
		negative;		
		0x000-0x3F		
		Set S1-S4, filter time of HDI terminal sampling. In		
P05.09	District Characters	cases where interference is strong, increase the	0.010s	0
F05.09	Digital filter time	value of this parameter to avoid mal-operation.	0.0108	
		0.000–1.000s		
		0x000–0x3F (0: disable, 1: enable)		
		BIT0: S1 virtual terminal		
	Virtual terminal	BIT1: S2 virtual terminal		
P05.10		BIT2: S3 virtual terminal	0x00	0
	setting	BIT3: S4 virtual terminal		
		BIT4: HDIA virtual terminal		
		BIT5: HDIB virtual terminal		
		This function code is used to set the 2/3 Wire control		
P05.11	2/3 Wire control	mode.	0	0
P05.11	mode	0: 2-Wire control 1; integrate enabling function with		
		direction. This mode is the most popular dual-line		

Function			Default	Modi
code	Name	Detailed parameter description	value	fy
		mode. Direction of motor rotation is determined by		
		the defined FWD/REV terminal command.		
		FWD REV Running command		
		K1 OFF OFF Stop		
		K2 REV ON OFF Forward running		
		OFF ON Reverse running		
		ON ON Hold		
		1: 2-wire control 2; separate enabling function with		
		direction. In this mode, the defined FWD is enabling		
		terminal, and the direction is determined by the state		
		of REV.		
		FWD REV Running command		
		K1 OFF OFF Stop		
		REV ON OFF Forward running		
		COM OFF ON Stop		
		ON ON Reverse running		
		2: 3-wire control 1; This mode defines Sin as		
		enabling terminal, and the running command is		
		generated by FWD, the direction is controlled by		
		REV. During running, the Sin terminal should be		
		closed, and terminal FWD generates a rising edge		
		signal, then the inverter starts to run in the direction		
		set by the state of terminal REV; the inverter should		
		be stopped by disconnecting terminal Sin.		
		SB1 FWD		
		SB2		
		SIn		
		K REV		
		сом		
		The direction control during running is shown below.		

Function code	Name	D	etailed para	ame	ter descrip	tion	Default value	Modi fy	j
		SIn	REV	r	revious unning irection	Current running direction			
		ON	OFF→ON		orward	Reverse			
					Reverse Reverse	Forward Forward			
		ON	ON→OFF		orward	Reverse			
		ON→OFF	ON OFF		Decelerat	e to stop			
		Reverse ru 3: 3-wire enabling generated running dir should be generates a and directi	control/Sin, nning control 2; terminal. I by FWD or ection. Duri closed, a a rising edge	This The r RE ing r ind e sig rter;	mode de running EV, and the unning, the terminal F nal to contre the inverterminal Sin.	ey control the exterminal Sin WD or REV of the running er should be			
		SIn	FWD	•	REV	Running direction			
		ON	OFF→C	ON	ON	Forward			
					OFF	Forward			
		ON	ON		OFF→ON	Reverse			
			OFF			Reverse			
		ON→OF	F			Decelerate to stop			
		Sln: 3-wire	control/Sin,	FWI	D: Forward	running, REV:			

Function	Nome	Datailed waremater description	Default	Modi
code	Name	Detailed parameter description	value	fy
		Reverse running		
		Note: For dual-line running mode, when		
		FWD/REV terminal is valid, if the inverter stops		
		due to stop command given by other sources, it		
		will not run again after the stop command		
		disappears even if the control terminals		
		FWD/REV are still valid. To make the inverter run		
		again, users need to trigger FWD/REV again, eg,		
		PLC single-cycle stop, fixed-length stop, and		
		valid STOP/RST stop during terminal control.		
		(see P07.04)		-
P05.12	S1 terminal		0.000s	0
	switch-on delay			
P05.13	S1 terminal		0.000s	0
	switch-off delay			
P05.14	S2 terminal		0.000s	0
	switch-on delay			
P05.15	S2 terminal	These function codes define corresponding delay of	0.000s	0
	switch-off delay	the programmable input terminals during level		-
P05.16	S3 terminal	variation from switch-on to switch-off.	0.000s	0
	switch-on delay	Si electrical level		
P05.17	S3 terminal	Citatid involid	0.000s	0
	switch-off delay	Si valid /// valid////// invalid Switcn-on Switcn-off		
P05.18	S4 terminal	delay delay	0.000s	0
	switch-on delay	Setting range: 0.000–50.000s		
P05.19	S4 terminal	Note: After a virtual terminal is enabled, the state of	0.000s	0
	switch-off delay	the terminal can be changed only in communication		
P05.20	HDIA terminal	mode. The communication address is 0x200A.	0.000s	0
	switch-on delay			
P05.21	HDIA terminal		0.000s	0
	switch-off delay			1
P05.22	HDIB terminal		0.000s	0
	switch-on delay			1
P05.23	HDIB terminal		0.000s	0
	switch-off delay			
P05.24	Lower limit value of Al1	These function codes define the relation between analog input voltage and corresponding set value of	0.00V	0
P05.25	Corresponding	analog input. When the analog input voltage	0.0%	0

Function code	Name	Detailed parameter description	Default value	Modi fy
	setting of lower	exceeds the range of max./min. input, the max. input		
	limit of AI1	or min. input will be adopted during calculation.		
P05.26	Upper limit value	When analog input is current input, 0-20mA current	10.00V	0
P05.26	of AI1	corresponds to 0–10V voltage.	10.000	U
	Corresponding	In different applications, 100% of analog setting		
P05.27	setting of upper	corresponds to different nominal values.	100.0%	0
	limit of AI1	The figure below illustrates several settings.		
P05.28	Input filter time of	Corresponding setting	0.030s	0
1 03.20	Al1	100%	0.0303	O
P05.29	Lower limit value		-10.00V	0
F05.29	of AI2	-10V 0 AI	-10.000	O
	Corresponding	10V 20mA		
P05.30	setting of lower	Al2 Al1	-100.0%	0
	limit of AI2	-100%		
P05.31	Intermediate		0.00V	0
1 00.01	value 1 of Al2	Input filter time: Adjust the sensitivity of analog input,	0.00 v	
	Corresponding	increase this value properly can enhance the		
P05.32	setting of	anti-interference capacity of analog variables;	0.0%	0
1 00.02	intermediate	however, it will also degrade the sensitivity of analog		
	value 1 of Al2	input.		
P05.33	Intermediate	Note: Al1 can support 0-10V/0-20mA input, when	0.00V	0
1 00.00	value 2 of Al2	Al1 selects 0–20mA input; the corresponding voltage	0.00 v	
	Corresponding	of 20mA is 10V; AI2 supports -10V-+10V input.		
P05.34	setting of	Setting range of P05.24: 0.00V-P05.26	0.0%	0
F05.54	intermediate	Setting range of P05.25: -100.0%-100.0%	0.076	
	value 2 of Al2	Setting range of P05.26: P05.24–10.00V		
P05.35	Upper limit value	Setting range of P05.27: -100.0%-100.0%	10.00V	0
F05.55	of AI2	Setting range of P05.28: 0.000s-10.000s	10.00 V	O
	Corresponding	Setting range of P05.29: -10.00V-P05.31		
P05.36	setting of upper	Setting range of P05.30: -100.0%-100.0%	100.0%	0
	limit of Al2	Setting range of P05.31: P05.29–P05.33		
		Setting range of P05.32: -100.0%-100.0%		
		Setting range of P05.33: P05.31–P05.35		
P05.37	Input filter time of	Setting range of P05.34: -100.0%-100.0%	0.020-	0
P05.37	Al2	Setting range of P05.35: P05.33–10.00V	0.030s	
		Setting range of P05.36: -100.0%-100.0%		
		Setting range of P05.37: 0.000s-10.000s		
P05.38	HDIA high-speed	0: Set input via frequency	0	0

Function code	Name	Detailed parameter description	Default value	Modi fy
	pulse input	1: Reserved		
	function	2: Input via encoder, used in combination with HDIB		
P05.39	Lower limit frequency of HDIA	0.000 KHz – P05.41	0.000 KHz	0
P05.40	Corresponding setting of lower limit frequency of HDIA	-100.0%–100.0%	0.0%	0
P05.41	Upper limit frequency of HDIA	P05.39 –50.000KHz	50.000 KHz	0
P05.42	Corresponding setting of upper limit frequency of HDIA	-100.0%–100.0%	100.0%	0
P05.43	HDIA frequency input filter time	0.000s-10.000s	0.030s	0
P05.44	HDIB high-speed pulse input function selection	Set input via frequency Reserved Encoder input, it should be used in combination with HDIA	0	0
P05.45	Lower limit frequency of HDIB	0.000 KHz – P05.47	0.000 KHz	0
P05.46	Corresponding setting of lower limit frequency of HDIB	-100.0%–100.0%	0.0%	0
P05.47	Upper limit frequency of HDIB	P05.45 –50.000KHz	50.000 KHz	0
P05.48	Corresponding setting of upper limit frequency of HDIB	-100.0%–100.0%	100.0%	0
P05.49	HDIB frequency input filter time	0.000s-10.000s	0.030s	0

Function			Default	Modi
code	Name	Detailed parameter description	value	fy
		0: Voltage type		
Do	Al1 input signal	1: Current type		
P05.50	type	Note: You can set the Al1 input signal type through	0	0
		the corresponding function code.		
P05.51-	Reserved			
P05.52	variables	0–65535	0	•
P06 grou	p Output termin			
		0: Open collector high-speed pulse output: Max.		
		frequency of the pulse is 50.00kHz. For details about		
P06.00	HDO output type	the related functions, see P06.27–P06.31.	0	0
		1: Open collector output: For details about the		
		related functions, see P06.02.		
D00 04	Y output	0: Invalid	0)
P06.01	selection	1: In running	0	0
D00.00	HDO output	2: In forward running	0)
P06.02	selection	3: In reverse running	0	0
D00.00	Relay RO1	4: In jogging	4)
P06.03	output selection	5: Inverter fault	1	0
		6: Frequency level detection FDT1		
		7: Frequency level detection FDT2		
		8: Frequency reached		
		9: Running in zero speed		
		10: Reach upper limit frequency		
		11: Reach lower limit frequency		
		12: Ready to run		
		13: In pre-exciting		
		14: Overload pre-alarm		
	Polov PO2	15: Underload pre-alarm		
P06.04	Relay RO2	16: Simple PLC stage completed	5	0
	output selection	17: Simple PLC cycle completed		
		18: Reach set counting value		
		19: Reach designated counting value		
		20: External fault is valid		
		21: Reserved		
		22: Reach running time		
		23: Virtual terminal output of MODBUS		
		communication		
		24: Virtual terminal output of POROFIBUS		
		/CANopen communication		

Function code	Name	Detailed parameter description	Default value	Modi fy
Code		25: Virtual terminal output of Ethernet	value	ıy
		communication		
		26: DC bus voltage established		
		27: z pulse output		
		28: During pulse superposition		
		29: STO act		
		30: Positioning completed		
		31: Spindle zeroing completed		
		32: Spindle scale-division completed		
		33: In speed limit		
		34–35: Reserved		
		36: Speed/position control switch-over completed		
		37–40: Reserved		
		41: C_Y1 from PLC (You need to set P27.00 to 1.)		
		42: C_Y2 from PLC (You need to set P27.00 to 1.)		
		43: C_HDO from PLC (You need to set P27.00 to 1.)		
		44: C_RO1 from PLC (You need to set P27.00 to 1.)		
		45: C_RO2 from PLC (You need to set P27.00 to 1.)		
		46: C_RO3 from PLC (You need to set P27.00 to 1.)		
		47: C_RO4 from PLC (You need to set P27.00 to 1.)		
		48–63: Reserved		
		29: STO action		
		48–63: Reserved		
	Output terminal	This function code is used to set the polarity of		
	polarity selection	·		
		When the bit is set to 0, input terminal polarity is		
		positive;		
P06.05		When the bit is set to 1 input terminal polarity is	00	0
		negative.		
		BIT3 BIT2 BIT1 BIT0		
		RO2 RO1 HDO Y		
		Setting range: 0x0–0xF		
P06.06	Y switch-on delay	This function code defines the corresponding delay	0.000s	0
P06.07	Y switch-off delay	of the level variation from switch-on to switch-off.	0.000s	0
DOC OS	HDO switch-on	Y electric level	0.000-	
P06.08	delay	jnyalid Y valid Invalid /// Valid////////////////////////////////////	0.000s	0
P06.09	HDO switch-off	Y valid	0.000s	0
F00.09	delay	ueiay ueiay	0.0008	

Function code	Name	Detailed parameter description	Default value	Modi fy
P06.10	Relay RO1 switch-on delay	Setting range: 0.000–50.000s Note: P06.08 and P06.09 are valid only when	0.000s	0
P06.11	Relay RO1 switch-off delay	P06.00=1.	0.000s	0
P06.12	Relay RO2 switch-on delay		0.000s	0
P06.13	Relay RO2 switch-off delay		0.000s	0
P06.14	AO1 output selection	0: Running frequency 1: Set frequency	0	0
P06.15	Reserved variables	Ramps reference frequency Running speed	0	0
P06.16	HDO high-speed pulse output	4: Output current (relative to inverter) 5: Output current (relative to motor) 6: Output voltage 7: Output power 8: Set torque value 9: Output torque 10: Al1 input value 11: Al2input value 12: Al3 input value 13: Input value of high-speed pulse HDIA 14: Set value 1 of MODBUS communication 15: Set value 2 of MODBUS communication 16: Set value 1 of PROFIBUS\CANopen communication 17: Set value 2 of PROFIBUS\CANopen communication 18: Set value 1 of Ethernet communication 19: Set value 2 of Ethernet communication 20: Input value of high-speed pulse HDIB 21: Reserved 22: Torque current (bipolar, 100% corresponds to 10V) 23: Exciting current (100% corresponds to 10V) 24: Set frequency (bipolar) 25: Ramps reference frequency (bipolar) 26: Running speed (bipolar) 27: Set value 2 of EtherCat/Profinet communication	0	0

Function			Default	Modi
code	Name	Detailed parameter description	value	fy
		28: C_AO1 from PLC (You need to set P27.00 to 1.)		
		29: C_AO2 from PLC (You need to set P27.00 to 1.)		
		30: Running speed		
		31–47: Reserved		
D00.47	Lower limit of	Above function codes define the relation between	0.007	
P06.17	AO1 output	output value and analog output. When the output	0.0%	0
	Corresponding	value exceeds the set max./min. output range, the		
P06.18	AO1 output of	upper/low limit of output will be adopted during	0.00V	0
	lower limit	calculation.		
D00.40	Upper limit of	When analog output is current output, 1mA	400.00/	
P06.19	AO1 output	corresponds to 0.5V voltage. In different	100.0%	0
	Corresponding	applications, 100% of output value corresponds to		
P06.20	AO1 output of	different analog outputs.	10.00V	0
	upper limit	AO 10V (20mA)		
P06.21	AO1 output filter time	Setting range of P06.17: -100.0%–P06.19 Setting range of P06.18: 0.00V–10.00V Setting range of P06.19: P06.17–100.0% Setting range of P06.20: 0.00V–10.00V Setting range of P06.21: 0.000s–10.000s	0.000s	0
P06.22- P06.26	Reserved variables	0–65535	0	•
P06.27	Lower limit of HDO output	-100.0%—P06.29	0.00%	0
P06.28	Corresponding HDO output of lower limit	0.00–50.00kHz	0.00kHz	0
P06.29	Upper limit of HDO output	P06.27–100.0%	100.0%	0
P06.30	Corresponding HDO output of upper limit	0.00–50.00kHz	50.00 kHz	0
P06.31	HDO output filter time	0.000s-10.000s	0.000s	0
P06.32-	Reserved	0–65535	0	•

Function	Name	Detailed parameter description	Default	
code			value	fy
P06.34	variable			
P07 grou	р НМІ			
P07.00	User password	0–65535 Set it to any non-zero value to enable password protection. 00000: Clear previous user password and disable password protection. After user password becomes valid, if wrong password is inputted, users will be denied entry. It is necessary to keep the user password in mind. Password protection will be effective one minute after exiting function code edit state, and it will display "0.0.0.0.0" if users press PRG/ESC key to enter function code edit state again, users need to input the correct password. Note: Restoring to default values will clear user password, use this function with caution.	0	0
P07.01	Reserved variable	j	/	/
P07.02	Function of keys	Range: 0x00–0x27 Ones: Function selection of QUICK/JOG key 0: No function 1: Jogging 2: Reserved 3: Forward/reverse rotation switch-over 4: Clear UP/DOWN setting 5: Coast to stop 6: Switch over the running command reference mode in sequence 7: Reserved Tens: Reserved	0x01	0
P07.03	Running command channel switch-over sequence of QUICK key	When P07.02=6, set the switch-over sequence of running command channel. 0: keypad control→terminal control→ communication control 1: keypad control←→terminal control 2: keypad control←→communication control 3: terminal control←→communication control	0	0
P07.04	Stop function	Validness selection of stop function of STOP/RST.	0	0

Function			Default	Modi
code	Name	Detailed parameter description	value	fy
	selection of	For fault reset, STOP/RST is valid under any		
	STOP/RST key	situation.		
		0: valid only for panel control only		
		1: valid for both panel and terminal control		
		2: valid for both panel and communication control		
		3: valid for all control modes		
P07.05-	Reserved variable	ne.	/	/
P07.07	iteserved variable		,	/
	Frequency	0.01–10.00		
P07.08	display	Display frequency=running frequency× P07.08	1.00	0
	coefficient	Display frequency=running frequency×1 07.00		
	Speed display	0.1–999.9%		
P07.09	coefficient	Mechanical speed=120×display running	100.0%	0
	COCITOICIL	frequency×P07.09/number of motor pole pairs		
	Linear speed	0.1–999.9%		
P07.10	display	Linear speed=mechanical speed×P07.10	1.0%	0
	coefficient	Elited Speed-Incondition Speedx1 07.10		
	Temperature of			
P07.11	rectifier bridge	-20.0–120.0°C	/	•
	module			
P07.12	Temperature of	-20.0–120.0°C	/	•
	inverter module	20.0 . 20.0 0	,	Ľ
P07.13	Software version	1.00–655.35	/	•
	of control board		,	Ľ
P07.14	Accumulated	0-65535h	/	•
	running time			
	High bit of			
P07.15	inverter power	Display the power consumption of the inverter.	/	•
	consumption	Inverter power consumption=P07.15×1000+P07.16		
	Low bit of inverter	, ,		
P07.16	power	Setting range of P07.16: 0.0–999.9 kWh	/	•
	consumption			
P07.17	Reserved		/	/
P07.18	Rated power of	0.4–3000.0kW	/	
F 07.10	inverter	0.T-0000.0RVV	,	
P07.19	Rated voltage of	50–1200V	/	
1 07.13	inverter			
P07.20	Rated current of	0.1–6000.0A	/	•

Function		5.9.1	Default	Modi
code	Name	Detailed parameter description	value	fy
	inverter			
P07.21	Factory barcode 1	0x0000-0xFFFF	/	•
P07.22	Factory barcode 2	0x0000–0xFFFF	/	•
P07.23	Factory barcode 3	0x0000–0xFFFF	/	•
P07.24	Factory barcode 4	0x0000-0xFFFF	/	•
P07.25	Factory barcode 5	0x0000–0xFFFF	/	•
P07.26	Factory barcode 6	0x0000-0xFFFF	/	•
P07.27	Type of present	0: No fault	/	•
P07.27	fault	1: Inverter unit U phase protection (OUt1)	/	
P07.28	Type of the last	2: Inverter unit V phase protection (OUt2)	/	
P07.28	fault	3: Inverter unit W phase protection (OUt3)	/	
P07.29	Type of the last	4: Overcurrent during acceleration (OC1)	/	
P07.29	but one fault	5: Overcurrent during deceleration (OC2)	/	
D07.00	Type of the last	6: Overcurrent during constant speed (OC3)	,	
P07.30	but two fault	7: Overvoltage during acceleration (OV1)	/	•
D07.04	Type of the last	8: Overvoltage during deceleration (OV2)	/	
P07.31	but three fault	9: Overvoltage during constant speed (OV3)	/	
		10: Bus undervoltage fault (UV)		
		11: Motor overload (OL1)		
		12: Inverter overload (OL2)		
		13: Phase loss on input side (SPI)		
		14: Phase loss on output side (SPO)		
		15: Rectifier module overheat (OH1)		
		16: Inverter module overheat (OH2)		
		17: External fault (EF)		
		18: 485 communication fault (CE)		
	T £ 4b - 14	19: Current detection fault (ItE)		
P07.32	Type of the last	20: Motor autotuning fault (tE)	/	•
	but four fault	21: EEPROM operation fault (EEP)		
		22: PID feedback offline fault (PIDE)		
		23: Brake unit fault (bCE)		
		24: Running time reached (END)		
		25: Electronic overload (OL3)		
		26: Keypad communication error (PCE)		
		27: Parameter upload error (UPE)		
		28: Parameter download error (DNE)		
		29: Profibus communication fault (E-DP)		
		30: Ethernet communication fault (E-NET)		

Function			Default	Modi
code	Name	Detailed parameter description	value	fy
5545		31: CANopen communication fault (E-CAN)	raido	.,
		32: To-ground short-circuit fault 1 (ETH1)		
		33: To-ground short-circuit fault 2 (ETH2)		
		34: Speed deviation fault (dEu)		
		35: Mal-adjustment fault (STo)		
		36: Underload fault (LL)		
		37: Encoder offline fault (ENC10)		
		38: Encoder reversal fault (ENC1D)		
		39: Encoder Z pulse offline fault (ENC1Z)		
		40: Safe torque off (STO)		
		41: Channel H1 safety circuit exception (STL1)		
		42: Channel H2 safety circuit exception (STL2)		
		43: Channel H1 and H2 exception (STL3)		
		44: Safety code FLASH CRC fault (CrCE)		
		45: PLC card customized fault 1 (P-E1)		
		46: PLC card customized fault 2 (P-E2)		
		47: PLC card customized fault 3 (P-E3)		
		48: PLC card customized fault 4 (P-E4)		
		49: PLC card customized fault 5 (P-E5)		
		50: PLC card customized fault 6 (P-E6)		
		51: PLC card customized fault 7 (P-E7)		
		52: PLC card customized fault 8 (P-E8)		
		53: PLC card customized fault 9 (P-E9)		
		54: PLC card customized fault 10 (P-E10)		
		55: Repetitive extension card type fault (E-Err)		
		56: Encoder UVW loss fault (ENCUV)		
		57: Profibus communication fault (E-PN)		
		58: CANopen communication fault (ESCAN)		
		59: Motor over-temperature fault (OT)		
		60: Card slot 1 card identification failure (F1-Er)		
		61: Card slot 2 card identification failure (F2-Er)		
		62: Card slot 3 card identification failure (F3-Er)		
		63: Card slot 1 card communication timeout fault		
		(C1-Er)		
		64: Card slot 2 card communication timeout fault		
		(C2-Er)		
		65: Card slot 3 card communication timeout fault		
		(C3-Er)		
		66: EtherCat communication fault (E-CAT)		

Function code	Name	Detailed parameter description	Default value	Modi fy
55.05		67: Bacnet communication fault (E-BAC)	7 311 31 5	- ,
		68: DeviceNet communication fault (E-DEV)		
		69: Master-slave synchronous CAN slave fault		
		(S-Err)		
P07.33	Running frequency	y of present fault	0.00Hz	•
P07.34	Ramps reference	frequency of present fault	0.00Hz	•
P07.35	Output voltage of	present fault	0V	•
P07.36	Output current of p	present fault	0.0A	•
P07.37	Bus voltage of pre	sent fault	0.0V	•
P07.38	Max. temperature	of present fault	0.0°C	•
P07.39	Input terminal stat	e of present fault	0	•
P07.40	Output terminal sta	ate of present fault	0	•
P07.41	Running frequency	y of the last fault	0.00Hz	•
P07.42	Ramps reference	frequency of the last fault	0.00Hz	•
P07.43	Output voltage of	the last fault	0V	•
P07.44	Output current of t	he last fault	0.0A	•
P07.45	Bus voltage of the	last fault	0.0V	•
P07.46	Max. temperature	of the last fault	0.0°C	•
P07.47	Input terminal stat	e of the last fault	0	•
P07.48	Output terminal sta	ate of the last fault	0	•
P07.49	Running frequency	y of the last but one fault	0.00Hz	•
P07.50	Ramps reference	frequency of the last but one fault	0.00Hz	•
P07.51	Output voltage of	the last but one fault	0V	•
P07.52	Output current of t	he last but one fault	0.0A	•
P07.53	Bus voltage of the	last but one fault	0.0V	•
P07.54	Max. temperature	of the last but one fault	0.0°C	•
P07.55	Input terminal stat	e of the last but one fault	0	•
P07.56	Output terminal sta	ate of the last but one fault	0	•
P08 grou	p Enhanced fun	ctions		
P08.00	Acceleration	Can DOO 44 and DOO 40 for datailed definitions	Depend	0
P06.00	time 2	See P00.11 and P00.12 for detailed definitions.	on model	
P08.01	Deceleration time 2	Goodrive350 series inverter defines four groups of acceleration/deceleration time, which can be	Depend on model	0
P08.02	Acceleration time 3	selected by multi-function digital input terminal (P05 group). The acceleration/deceleration time of the invertex is the first group by default.	Depend on model	0
P08.03	Deceleration time 3	inverter is the first group by default. Setting range: 0.0–3600.0s	Depend on model	0

Function	Name	Detailed parameter description	Default	Modi
code	1100	2014.1014 Pall 411.1010.1	value	fy
P08.04	Acceleration		Depend	0
	time 4		on model	
P08.05	Deceleration		Depend	0
	time 4		on model	
	Running	This function code is used to define the reference		
P08.06	frequency of	frequency of the inverter during jogging.	5.00Hz	0
	jogging	Setting range: 0.00Hz–P00.03 (Max. output		
	, 55 5	frequency)		
	Acceleration time	Jogging acceleration time is the time needed for the		
P08.07	of jogging	inverter to accelerate from 0Hz to Max. output		0
	o. joggg	frequency (P00.03).	Depend	
		Jogging deceleration time is the time needed from	on model	
P08.08	Deceleration time	decelerating from Max. output frequency (P00.03) to		0
. 00.00	of jogging	0Hz.		
		Setting range: 0.0–3600.0s		
P08.09	Jump frequency 1	When the set frequency is within the range of jump	0.00Hz	0
P08.10	Jump frequency	frequency, the inverter will run at the boundary of	0.00Hz	0
1 00.10	amplitude 1	jump frequency.	0.00112	0
P08.11	Jump frequency 2	The inverter can avoid mechanical resonance point	0.00Hz	0
D00.40	Jump frequency	by setting the jump frequency, and three jump		
P08.12	amplitude 2	frequency points can be set. If the jump frequency	0.00Hz	0
P08.13	Jump frequency 3	points are set to 0, this function will be invalid.	0.00Hz	0
	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Jump Set frequency f		
		frequency 3 1/2* jump amplitude 3		
		Jump Jump amplitude 2		
		frequency 2 1/2* jump amplitude 2		
P08.14	Jump frequency	Jump frequency 1 1/2* jump amplitude 1 1/2* jump amplitude 1 1/2* jump amplitude 1	0.00Hz	0
	amplitude 3	± 1/2 jump amplitude 1		
		Time t		
		Setting range: 0.00Hz–P00.03 (Max. output		
		frequency)		
	Amplitude of			0
P08.15	wobbling	0.0-100.0% (relative to set frequency)	0.0%	
	frequency			
P08.16	Amplitude of	0.0-50.0% (relative to amplitude of wobbling	0.0%	0
. 55.16	jump frequency	frequency)	0.070	
P08.17	Rise time of	0.1–3600.0s	5.0s	0
1 00.17	wobbling	0.7 0000.00	0.03	

Function code	Name	Detailed parameter description	Default value	Modi fy
	frequency		valuo	.,
P08.18	Descend time of wobbling frequency	0.1–3600.0s	5.0s	0
P08.19	Switching frequency of acceleration/dec eleration time	0.00–P00.03 (Max. output frequency) 0.00Hz: no switch-over Switch to acceleration/deceleration time 2 if the running frequency is larger than P08.19	0.00Hz	0
P08.20	Frequency threshold of the start of droop control	0.00–50.00Hz	2.00Hz	0
P08.21	Reference frequency of acceleration/dec eleration time	0: Max. output frequency 1: Set frequency 2: 100Hz Note: Valid for straight acceleration/deceleration only	0	0
P08.22	Output torque calculation mode	0: Calculated based on torque current	0	0
P08.23	Number of decimal points of frequency	0: Two decimal points 1: One decimal point	0	0
P08.24	Number of decimal points of linear speed	0: No decimal point 1: One 2: Two 3: Three	0	0
P08.25	Set count value	P08.26–65535	0	0
P08.26	Designated count value	0–P08.25	0	0
P08.27	Set running time	0–65535min	0min	0
P08.28	Automatic fault reset times	Automatic fault reset times: When the inverter selects automatic fault reset, it is used to set the	0	0
P08.29	Automatic fault reset time interval	times of automatic reset, if the continuous reset times exceeds the value set by P08.29, the inverter will report fault and stop to wait for repair. Interval of automatic fault reset: select the interval time from when fault occurred to automatic fault reset actions.	1.0s	0

Function	Name	Detailed parameter description	Default	Modi
code	Name	Detailed parameter description	value	fy
		After inverter starts, if no fault occurred during 60s,		
		the fault reset times will be zeroed out.		
		Setting range of P08.28: 0–10		
		Setting range of P08.29: 0.1–3600.0s		
		This function code sets the variation rate of the		
	Reduction ratio of	inverter output frequency based on the load; it is		
P08.30	droop control	mainly used in balancing the power when multiple	0.00Hz	0
	droop control	motors drive the same load.		
		Setting range: 0.00-50.00Hz		
		0x00–0x14		
		Ones: Switch-over channel		
		0: Switch over by terminal		
	Outlieb access	1: Switch over by MODBUS communication		
D00.04	Switch-over	2: Switch over by PROFIBUS/CANopen/DeviceNet	000	
P08.31	between motor 1	3: Switch over by Ethernet communication	0x00	0
	and motor 2	4: Switch over by EtherCat/Profinet communication		
		Tens: Motor switch over during running		
		0: Disable switch over during running		
		1: Enable switch over during running		
D00.00	FDT1 level	When the output frequency exceeds the	50.0011	
P08.32	detection value	corresponding frequency of FDT level, multi-function	50.00Hz	0
500.00	FDT1 lag	digital output terminal outputs "frequency level	= 00/	
P08.33	detection value	detection FDT" signal, this signal will be valid until	5.0%	0
	FDT2 level	the output frequency lowers to below the		
P08.34	detection value	corresponding frequency (FDT level-FDT lag	50.00Hz	0
		detection value), the waveform is shown in the figure		
		below.		
		Output frequency f		
		FDT level FDT lag		
		Time t		
P08.35	FDT2 lag	A	5.0%	
P08.35	detection value		5.0%	0
		Y1, RO1, RO2		
		Time t		
		Setting range of P08.32: 0.00Hz-P00.03 (Max.		
		output frequency)		
		Setting range of P08.33: 0.0–100.0% (FDT1 level)		
		Setting range of P08.34: 0.00Hz-P00.03 (Max.		

Function	Name	Detailed parameter description		Modi
code		autout fra guangul	value	fy
		output frequency)		
		Setting range of P08.35: 0.0–100.0% (FDT2 level) When the output frequency is within the positive		
		/negative detection range of the set frequency, the		
		multi-function digital output terminal outputs		
		"frequency arrival" signal as shown below.		
		Output frequency		
		Set Detection amplitude		
	Detection value	frequency		
P08.36	for frequency	Time t	0.00Hz	0
	arrival			
		↑		
		Y.		
		Y, R01, R02 Time t		
		Setting range: 0.00Hz–P00.03 (Max. output		
		frequency)		
	Enable/disable			
P08.37	energy-	0: Disable energy-consumption	1	0
. 55.51	consumption	1: Enable energy-consumption	•	
	brake			
			220V	
		Set the starting hus valtage of energy consumption	voltage: 380.0V;	
	Energy-	Set the starting bus voltage of energy-consumption brake, adjust this value properly can brake the load	380V	
P08.38	consumption	effectively. The default value will change with the	voltage:	0
1 00.00	brake threshold	change of voltage class.	700.0V;	
	voltage	Setting range: 200.0–2000.0V	660V	
		3 3	voltage:	
			1120.0V	
P08.39	Running mode of	0: Common running mode	0	0
FU0.39	cooling fan	1: The fan keeps running after power up	U	U
		0x0000–0x2121		
		Ones: PWM mode		
P08.40	PWM selection	0: 3PH modulation and 2-phase modulation	0x0001	0
	20.00.011	1: 3PH modulation		
		Tens: PWM low-speed carrier limit		
		0: Limit low-speed carrier to 2K		

Function			Default	Modi
code	Name	Detailed parameter description	value	fy
		1: Limit low-speed carrier to 4K		
		2: No limit on low-speed carrier		
		Hundreds: Reserved		
		Thousands: PWM loading mode		
		0: PWM loading mode 1		
		1: PWM loading mode 2		
		2: Reserved		
		0x00–0x11		
		Ones		
	Ou common de electione	0: Overmodulation is invalid		
P08.41	Overmodulation selection	1: Overmodulation is valid	01	0
	selection	Tens		
		0: Mild overmodulation		
		1: Deepened overmodulation		
P08.42	Reserved variable	/	/	
P08.43	Reserved variable	/	/	
		0x000-0x221		
		Ones: Frequency control selection		
		0: UP/DOWN terminal setup is valid		
		1: UP/DOWN terminal setup is invalid		
		Tens: Frequency control selection		
	UP/DOWN	0: Valid only when P00.06=0 or P00.07=0		
P08.44	01,201111	1: All frequency modes are valid	0x000	0
P08.44	terminal control	2: Invalid for multi-step speed when multi-step speed	UXUUU	0
	setup	takes priority		
		Hundreds: Action selection during stop		
		0: Valid		
		1: Valid during running, clear after stop		
		2: Valid during running, clear after receiving stop		
		command		
	UP terminal			
P08.45	frequency	0.01–50.00Hz/s	0.50Hz/s	0
1 00.43	incremental	0.01-30.00112/3	0.50112/3	
	integral rate			
	DOWN terminal			
P08.46	frequency	0.01–50.00Hz/s	0.50Hz/s	0
1 00.40	decremental	0.01 00.001123	U.SUHZ/S	
	change rate			

Function			Default	Modi
code	Name	Detailed parameter description	value	fy
P08.47	Action selection for frequency setup during power down	0x000–0x111 Ones: Action selection for frequency setup (by keypad digits) during power down 0: Save during power down 1: Zero out during power down Tens: Action selection for frequency setup (by MODBUS) during power down 0: Save during power down 1: Zero out during power down Hundreds: Action selection for frequency setup (by other communication) during power down 0: Save during power down 1: Zero out during power down	0x000	0
P08.48	High bit of initial value of power consumption	Set the initial value of power consumption. Initial value of power consumption=P08.48×1000+P08.49	0°	0
P08.49	Low bit of initial value of power consumption	Setting range of P08.48: 0–59999 kWh (k) Setting range of P08.49: 0.0–999.9 kWh	0.0°	0
P08.50	Flux braking	This function code is used to enable flux braking function. 0: Invalid 100–150: The larger the coefficient, the stronger the brake intensity The inverter enables motor to decelerate quickly by increasing the motor flux which converts energy generated during braking into thermal energy. The inverter monitors motor state continuously even during flux braking, thus flux braking can be applied in motor stop or used to change motor speed. The flux braking also carries the following advantages. 1) Brake immediately after sending stop command, removing the need to wait for flux to attenuate. 2) Better cooling effect. During flux braking, the stator current of the motor increases, while the rotor current does not change, while the cooling effect of stator is much more effective than that of the rotor.	0	0
P08.51	Current regulation	This function code is used to adjust the current display value on the AC input side.	0.56	0

Function			Default	Modi
code	Name	Detailed parameter description	value	fy
	coefficient on	0.00–1.00		
	input side			
P08.52	STO lock	STO alarm lock Alarm-lock means STO alarm must be reset after state restoration when STO occurs. STO alarm unlock Alarm-unlock means when STO occurs, after state restoration, STO alarm will disappear automatically.	0	0
P08.53	Bias value of upper limit frequency of torque control	0.00 Hz–P00.03 (Max. output frequency) Note: This parameter is valid only for the torque control mode.	0.00Hz	0
P08.54	Acceleration/dec eleration selection of upper limit frequency of torque control	O: No limit on acceleration or deceleration 1: Acceleration/deceleration time 1 2: Acceleration/deceleration time 2 3: Acceleration/deceleration time 3 4: Acceleration/deceleration time 4	0	0
P09 grou	p PID control			
P09.00	PID reference source	When frequency command (P00.06, P00. 07) is set to 7, or channel of voltage setup (P04.27) is set to 6, the inverter running mode is process PID control. This parameter determines the target reference channel of process PID. 0: Keypad (P09.01) 1: Al1 2: Al2 3: Al3 4: High-speed pulse HDIA 5: Multi-step 6: MODBUS communication 7: PROFIBUS/CANopen/DeviceNet communication 8: Ethernet communication 9: High-speed pulse HDIB 10: EtherCat/Profinet communication 11: Programmable extension card 12: Reserved The set target value of process PID is relative value, the set 100% corresponds to 100% of the feedback	0	0

Function code	Name	Detailed parameter description	Default value	Modi fy
code		signal of controlled system.	value	ıy
		The system operates based on the relative value (0–		
		100.0%)		
		Users need to set this parameter when P09.00 is set		
	Pre-set PID	to 0, the reference value of this parameter is the		
P09.01	reference of	feedback variable of the system.	0.0%	0
	keypad	Setting range: -100.0%—100.0%		
		This parameter is used to select PID feedback		
		channel.		
		0: Al1		
		1: AI2		
		2: Al3		
		3: High-speed pulse HDIA		
		4: MODBUS communication		
	PID feedback	5: PROFIBUS/CANopen/DeviceNet communication		
P09.02	source	6: Ethernet communication	0	0
	554.55	7: High-speed pulse HDIB		
		8: EtherCat/Profinet communication		
		9: Programmable extension card		
		10: Reserved		
		Note: The reference channel and feedback		
		channel cannot overlap; otherwise, PID cannot		
		be controlled effectively.		
		0: PID output is positive characteristic: namely, the		
		feedback signal is larger than the PID reference,		
		which requires the inverter output frequency to		
		decrease for PID to reach balance, eg, tension PID		
	PID output	control of winding		_
P09.03	characteristics	1: PID output is negative characteristics: namely the	0	0
		feedback signal is less than PID reference, which		
		requires inverter output frequency to increase for		
		PID to reach balance, eg, tension PID control of		
		unwinding.		
		This function code is suitable for proportional gain P		
		of PID input.		
D00.04	Proportional gain	It determines the regulation intensity of the whole	4.00	
P09.04	(Kp)	PID regulator, the larger the value of P, the stronger	1.80	0
		the regulation intensity. If this parameter is 100, it		
		means when the deviation between PID feedback		

Function	Name	Detailed parameter description		Modi
code			value	fy
		and reference is 100%, the regulation amplitude of		
		PID regulator (ignoring integral and differential		
		effect) on output frequency command is the max.		
		frequency (ignoring integral and differential actions).		
		Setting range: 0.00–100.00		
		It determines the speed of integral regulation made	0.90s	
		on the deviation between PID feedback and		
		reference by PID regulator. When the deviation		
		between PID feedback and reference is 100%, the		
		regulation of integral regulator (ignoring integral and		
P09.05	Integral time (Ti)	differential actions), after undergoing continuous		0
		regulation during this time period, can reach Max.		
		output frequency (P00.03)		
		The shorter the integral time, the stronger the		
		regulation intensity.		
		Setting range: 0.00–10.00s		
	Derivative time (Td)	It determines the intensity of the regulation made on		
		the change rate of deviation between PID feedback		
		and reference by PID regulator. If feedback changes		
		by 100% during this period, the regulation of		
P09.06		differential regulator (ignoring integral and differential	0.00s	0
		actions) is Max. output frequency (P00.03)		
		The longer the derivative time, the stronger the		
		regulation intensity.		
		Setting range: 0.00–10.00s		
		It means the sampling cycle of feedback. The		
	0 " 1	regulator operates once during each sampling cycle.		
P09.07	Sampling cycle	The larger the sampling cycle, the slower the	0.001s	0
	(T)	response.		
		Setting range: 0.001–10.000s		
		It is the max. allowable deviation of PID system		
		output value relative to closed-loop reference value.		
D00.00	Limit of PID	Within this limit, PID regulator stops regulation. Set	0.00/	
P09.08	control deviation	this function code properly to regulate the precision	0.0%	0
		and stability of PID system.		
		Setting range: 0.0–100.0%		

Function			Default	Modi
code	Name	Detailed parameter description	value	fy
		Reference Time t Output frequency f		
P09.09	Upper limit value of PID output	These two function codes are used to set the upper/lower limit value of PID regulator.	100.0%	0
P09.10	Lower limit value of PID output	100.0% corresponds to Max. output frequency (P00.03) or max. voltage (P04.31) Setting range of P09.09: P09.10–100.0% Setting range of P09.10: -100.0%–P09.09	0.0%	0
P09.11	Feedback offline detection value	Set PID feedback offline detection value, when the detection value is no more than the feedback offline	0.0%	0
P09.12	Feedback offline detection time	detection value, and the duration exceeds the value set in P09.12, the inverter will report "PID feedback offline fault", and keypad displays PIDE. Output frequency 11 < T2, so the inverter continues running 12=P09.12 P09.11 PIDE Fault output PIDE Setting range of P09.11: 0.0–100.0% Setting range of P09.12: 0.0–3600.0s	1.0s	0
P09.13	PID control selection	0x0000–0x1111 Ones: 0: Continue integral control after the frequency reaches upper/lower limit 1: Stop integral control after the frequency reaches upper/lower limit Tens: 0: The same with the main reference direction 1: Contrary to the main reference direction	0x0001	0

Function					
code	Name	Detailed parameter description	Default value	Modi fy	
		Hundreds:			
		0: Limit based on the max. frequency			
		1: Limit based on A frequency			
		Thousands:			
		0: A+B frequency, acceleration /deceleration of main			
		reference A frequency source buffering is invalid			
		1: A+B frequency, acceleration/ deceleration of main			
		reference A frequency source buffering is valid,			
		acceleration and deceleration are determined by			
		P08.04 (acceleration time 4).			
		0.00–100.00			
		Low-frequency switching point: 5.00Hz,			
	Low-frequency	high-frequency switching point: 10.00Hz (P09.04			
P09.14	proportional gain	corresponds to high-frequency parameter), and the	1.00	0	
	(Kp)	middle is the linear interpolation between these two			
		points			
	Acceleration/				
P09.15	deceleration time	0.0–1000.0s	0.0s	0	
	of PID command				
	Filter time of PID				
P09.16	output	0.000-10.000s	0.000s	0	
P09.17-	Reserved	0.05500	0		
P09.28	variables	0–65536	0	0	
P10 grou	p Simple PLC a	nd multi-step speed control			
		0: Stop after running once; the inverter stops			
		automatically after running for one cycle, and it can			
		be started only after receiving running command.			
	Cimania DI C	1: Keep running in the final value after running once;			
P10.00	Simple PLC	The inverter keeps the running frequency and	0	0	
	mode	direction of the last section after a single cycle.			
		2: Cyclic running; the inverter enters the next cycle			
		after completing one cycle until receiving stop			
		command and stops.			
		0: No memory after power down	· · · · · · · · · · · · · · · · · · ·		
D40.04	Simple PLC	1: Memory after power down; PLC memories its	0		
P10.01	memory selection	running stage and running frequency before power	0	0	
	-	down.			
P10.02	Multi-step speed 0	Setting range of the frequency in 0 th -15 th sections	0.0%	0	

Function	Name	Detailed parameter description		Modi
code			value	fy
P10.03	Running time of 0 th step	are -100.0–100.0%, 100% corresponds to Max. output frequency P00.03.	0.0s(min)	0
P10.04	Multi-step speed 1	Setting range of the running time in 0 th –15 th sections	0.0%	0
P10.05	Running time of 1 st step	are 0.0–6553.5s (min), the time unit is determined by P10.37.	0.0s(min)	0
P10.06	Multi-step speed 2	When simple PLC operation is selected, it is required to set P10.02–P10.33 to determine the running	0.0%	0
P10.07	Running time of 2 nd step	frequency and running time of each section. Note: The symbol of multi-step speed	0.0s(min)	0
P10.08	Multi-step speed 3	determines the running direction of simple PLC,	0.0%	0
P10.09	Running time of 3 rd step	and the negative value means reverse running. Deceleration time P10.28 (two sections)	0.0s(min)	0
P10.10	Multi-step speed 4	P10.02 P10.04	0.0%	0
P10.11	Running time of 4 th step	Acceleration lime (two sections)	0.0s(min)	0
P10.12	Multi-step speed 5	P10.06	0.0%	0
P10.13	Running time of 5 th step	When selecting multi-step speed running, the	0.0s(min)	0
P10.14	Multi-step speed 6	multi-step speed is within the range of -fmax-fmax,	0.0%	0
P10.15	Running time of 6 th step	and it can be set continuously. The start/stop of multi-step stop is also determined by P00.01.	0.0s(min)	0
P10.16	Multi-step speed 7	Goodrive350 series inverter can set 16-step speed,	0.0%	0
P10.17	Running time of 7 th step	which are set by combined codes of multi-step terminals 1-4 (set by S terminal, correspond to	0.0s(min)	0
P10.18	Multi-step speed 8	function code P05.01–P05.06) and correspond to	0.0%	0
P10.19	Running time of 8 th step	multi-step speed 0 to multi-step speed 15.	0.0s(min)	0
P10.20	Multi-step speed 9		0.0%	0
P10.21	Running time of 9 th step	terminal 1 ON ON ON ON ON ON ON	0.0s(min)	0
P10.22	Multi-step speed 10	terminal 2	0.0%	0
P10.23	Running time of 10 th step	terminal 4	0.0s(min)	0
P10.24	Multi-step speed 11	When terminal 1, terminal 2, terminal 3 and terminal 4 are OFF, the frequency input mode is set by	0.0%	0
P10.25	Running time of	P00.06 or P00.07. When terminal 1, terminal 2,	0.0s(min)	0

Function code	Name		Det	ailed	parar	nete	er de	scripti	ion		Default value	Modi fy
	11 th step	terminal	3 a	nd te	rmina	al 4	are	not a	all OF	F, the		
P10.26	Multi-step speed 12	frequence the prior	ity of	multi-	step	setti	ng is	highe	r than	that of	0.0%	0
P10.27	Running time of 12 th step	the key	icatio	on sett	ings.	•	•	·			0.0s(min)	0
P10.28	Multi-step speed 13	The rela	rmina	al 4 are	e sho	wn i	n the	table	below.	erminai	0.0%	0
P10.29	Running time of 13 th step	Terminal 1 Terminal 2	OFF	ON OFF	OFF	ON	OF OF			ON ON	0.0s(min)	0
P10.30	Multi-step speed 14	Terminal 3 Terminal 4		OFF	OFF OFF	OFF				ON OFF	0.0%	0
P10.31	Running time of 14 th step	Step Terminal 1	0 OFF	1 ON	2 OFF	3 ON	4 OF		6 OFF	7 ON	0.0s(min)	0
P10.32	Multi-step speed 15	Terminal 2		OFF	ON OFF	ON OFF	OF ON		+	ON ON	0.0%	0
P10.33	Running time of 15 th step	Terminal 4 Step	ON 8	ON 9	ON 10	ON 11	ON 12		ON 14	ON 15	0.0s(min)	0
P10.34	Acceleration/dec eleration time of 0 th –7 th step of simple PLC	Detailed Function code		ration nary	Ste num	ep ber	ACC/ DEC	ACC/ DEC	ACC/ DEC	ACC/ DEC	0x0000	0
P10.35	Acceleration/dec eleration time of 8 th – 15 th step of simple PLC	P10.35	BIT1 BIT3 BIT9 BIT11 BIT13 BIT15 BIT16 BIT17 BIT3 BIT17 BIT3 BIT17	BITO	1 1 2 2 3 3 4 4 4 5 5 6 6 6 7 7 7 8 8 9 9 10 11 12 12 13 14 14 15 15 16 17 17 17 17 17 17 17 17 17 17 17 17 17	22 23 3 4 4 4 5 5	00 00 00 00 00 00 00 00 00 00 00 00 00	time 2 01 01 01 01 01 01 01 01 01 01 01 01 01	time 3 10 10 10 10 10 10 10 10 10 10 10 10 10	time 4 11 11 11 11 11 11 11 11 11	0x0000	0

Function code	Name	Detailed parameter description	Default value	Modi
code		and than convert 16 hit hinary number into	value	fy
		and then convert 16-bit binary number into		
		hexadecimal number, finally, set corresponding function code.		
		Acceleration/deceleration time 1 is set by P00.11		
		and P00.12; Acceleration/deceleration time 2 is set		
		by P08.00 and P08.01; Acceleration/deceleration		
		time 3 is set by P08.02 and P08.03; Acceleration		
		/deceleration time 4 is set by P08.04 and P08.05.		
		Setting range: 0x0000–0xFFFF		
		0: Restart from the first step, namely if the inverter		
		stops during running (caused by stop command,		
		fault or power down), it will run from the first step		
		after restart.		
		1: Continue running from the step frequency when		
P10.36	PLC restart mode	interruption occurred, namely if the inverter stops	0	0
		during running (caused by stop command or fault), it		
		will record the running time of current step, and		
		enters this step automatically after restart, then		
		continue running at the frequency defined by this		
		step in the remaining time.		
		0: s; the running time of each step is counted in		
P10.37	Multi-step time	seconds;	0	0
	unit	1: min; the running time of each step is counted in		
minutes;				
P11 grou	p Protection par	rameters		1
		0x000–0x111		
		Ones:		
		0: Disable software input phase loss protection		
	5	1: Enable software input phase loss protection		
P11.00	Phase-loss	Tens:	0x110	0
	protection	0: Disable output phase loss protection		
		Enable output phase loss protection Hundreds:		
		0: Disable hardware input phase loss protection		
		Disable Hardware input phase loss protection Enable hardware input phase loss protection		
	Frequency-drop	11. Endote natumate input phase 1055 protection		
P11.01	at transient	0: Disable	0	0
1 11.01	power down	1: Enable	J	
	POWEL GOWII			

Function code	Name	Detailed parameter description	Default value	Modi fy
P11.02	Reserved variables	0–65535	0	0
P11.03	Overvoltage stall protection	0: Disable 1: Enable DC bus voltage V Overvoltage stall threshold Output I frequency Time t	1	0
	Overvoltage stall	120–150% (standard bus voltage) (380V)	136%	
P11.04	protection voltage	120–150% (standard bus voltage) (220V)	120%	0
P11.05	Current-limit selection	During accelerated running, as the load is too large, the actual acceleration rate of motor is lower than that of output frequency, if no measures are taken, the inverter may trip due to overcurrent during acceleration. 0x00–0x11 Ones: Current-limit action selection 0: Invalid 1: Always valid Tens: Hardware current-limit overload alarm selection 0: Valid 1: Invalid	01	0
P11.06	Automatic current-limit level	Current-limit protection function detects output current during running, and compares it with the current-limit level defined by P11.06, if it exceeds the current-limit level, the inverter will run at stable	160.0%	0
P11.07	Frequency-drop rate during current limit	frequency during accelerated running, or run in decreased frequency during constant-speed running; if it exceeds the current-limit level continuously, the inverter output frequency will drop continuously until reaching lower limit frequency. When the output current is detected to be lower than	10.00 Hz/s	0

Function	Name	Detailed parameter description	Default	
code			value	fy
		the current-limit level again, it will continue		
		accelerated running.		
		Output frequency f Set frequency Acceleration Time t		
		Setting range of P11.06: 50.0–200.0%		
		Setting range of P11.07: 0.00-50.00Hz/s		
	Inverter or motor	If the inverter or motor output current is larger than		
P11.08	overload/underlo	the overload pre-alarm detection level (P11.09), and	0x000	0
	ad pre-alarm	the duration exceeds the overload pre-alarm		
	Overload	detection time (P11.10), overload pre-alarm signal	G model:	
P11.09	pre-alarm detection level	will be outputted.	150%	0
		Output current	P model:	
P11.10	Overload pre-alarm detection time	Setting range of P11.08: Enable and define overload pre-alarm function of the inverter and motor Setting range: 0x000–0x131 Ones: 0: Motor overload/underload pre-alarm, relative to rated motor current; 1: Inverter overload/underload pre-alarm, relative to rated inverter current. Tens: 0: The inverter continues running after	120% 1.0s	0

Function	Name	Detailed parameter description	Default	
code		everload/underload elermi	value	fy
		overload/underload alarm;		
		1: The inverter continues running after underload		
		alarm, and stops running after overload fault;		
		2: The inverter continues running after overload		
		alarm, and stops running after underload fault;		
		3: The inverter stops running after overload/underload		
		fault.		
		Hundreds:		
		0: Always detect		
		1: Detect during constant-speed running		
		Setting range of P11.09: P11.11–200%		
		Setting range of P11.10: 0.1–3600.0s		
	Underload	Underload pre-alarm signal will be outputted if the		
P11.11	pre-alarm	output current of the inverter or motor is lower than	50%	0
	detection level	underload pre-alarm detection level (P11.11), and		
	Underload pre-alarm detection time	the duration exceeds underload pre-alarm detection		
D44.40		time (P11.12).	1.00	
P11.12		Setting range of P11.11: 0- P11.09	1.0s	0
		Setting range of P11.12: 0.1–3600.0s		
		This function code is used to set the action of fault		
		output terminals during undervoltage and fault reset.		
		0x00-0x11		
	Fault output	Ones:		
P11.13	terminal action	0: Act during undervoltage fault	0x00	0
	during fault	1: Do not act during undervoltage fault		
	· ·	Tens:		
		0: Act during fault reset		
		1: Do not act during fault reset		
		0.0–50.0%		
P11.14	Speed deviation	This parameter is used to set the speed deviation	10.0%	0
	detection value	detection value.	10.070	
		This parameter is used to set the speed deviation		
	Speed deviation	detection time.		
P11.15	detection time	Note: Speed deviation protection will be invalid if	1.0s	0
	doteotion time	P11.15 is set to 0.0.		
		1 11.10 10 001 10 0.0.		

		official terror inverter		iapiei I
Function	Name	Detailed parameter description	Default	Modi
code		·	value	fy
		Actual detection value Set detection value Set detection value Set detection value 11<12, so the inverter continues running t2=P11.15 Setting range: 0.0–10.0s		
P11.16	Automatic frequency-reducti on during voltage drop	0–1 0: Invalid 1: Valid	0	0
P11.17	Proportional coefficient of voltage regulator during undervoltage stall	This parameter is used to set the proportional coefficient of the bus voltage regulator during undervoltage stall. Setting range: 0–1000	100	0
P11.18	Integral coefficient of voltage regulator during undervoltage stall	This parameter is used to set the integral coefficient of the bus voltage regulator during undervoltage stall. Setting range: 0–1000	40	0
P11.19	Proportional coefficient of current regulator during undervoltage stall	This parameter is used to set the proportional coefficient of the active current regulator during undervoltage stall. Setting range: 0–1000	25	0
P11.20	Integral coefficient of current regulator during undervoltage stall	This parameter is used to set the integral coefficient of the active current regulator during undervoltage stall. Setting range: 0–2000	150	0
P11.21	Proportional coefficient of voltage regulator during overvoltage stall	Setting range: 0–1000	60	0
P11.22	Integral	This parameter is used to set the integral coefficient	10	0

Function code	Name	Detailed parameter description	Default value	Modi fy
- 55.00	coefficient of voltage regulator during	of the bus voltage regulator during overvoltage stall. Setting range: 0–1000	74.40	,,
P11.23	overvoltage stall Proportional coefficient of current regulator during overvoltage stall	This parameter is used to set the proportional coefficient of the active current regulator during overvoltage stall. Setting range: 0–1000	60	0
P11.24	Integral coefficient of current regulator during overvoltage stall	This parameter is used to set the integral coefficient of the active current regulator during overvoltage stall. Setting range: 0–2000		0
P11.25	Enable inverter overload integral	0: Disabled 1: Enabled When this parameter is set to 0, the overload timing value is reset to zero after the inverter is stopped. In this case, the determination of inverter overload takes more time, and therefore the effective protection over the inverter is weakened. When this parameter is set to 1, the overload timing value is not reset, and the overload timing value is accumulative. In this case, the determination of inverter overload takes less time, and therefore the protection over the inverter can be performed more quickly.		
P11.26– P11.27	Reserved variables	0–65536	0	0
P12 grou		i motor 2		<u> </u>
P12.00	Type of motor 2	0: Asynchronous motor 1: Synchronous motor	0	0
P12.01	Rated power of asynchronous motor 2	0.1–3000.0kW	Depend on model	0
P12.02	Rated frequency of asynchronous motor 2	0.01Hz–P00.03 (Max. output frequency)	50.00Hz	0

Function	Name	Detailed parameter description	Default	Modi
code	Hamo	Dotailoù paralliotor docompilion	value	fy
	Rated speed of		Depend	
P12.03	asynchronous	1–36000rpm	on model	0
	motor 2			
	Rated voltage of		Depend	
P12.04	asynchronous	0–1200V	on model	0
	motor 2		on model	
	Rated current of		Depend	
P12.05	asynchronous	0.8–6000.0A	on model	0
	motor 2		on model	
	Stator resistance		Depend	
P12.06	of asynchronous	0.001–65.535Ω	on model	0
	motor 2		on model	
	Rotor resistance		Depend	
P12.07	of asynchronous	0.001–65.535Ω	on model	0
	motor 2		on model	
	Leakage	0.1–6553.5mH		
P12.08	inductance of		Depend	0
1 12.00	asynchronous		on model	
	motor 2			
	Mutual			
P12.09	inductance of	0.1–6553.5mH	Depend	0
1 12.00	asynchronous	0.1-055.51111	on model	
	motor 2			
	No-load current		Depend	
P12.10	of asynchronous	0.1–6553.5A	on model	0
	motor 2		on model	
	Magnetic			
	saturation			
P12.11	coefficient 1 of	0.0–100.0%	80%	0
1 12.11	iron core of	0.0 100.070	0070)
	asynchronous			
	motor 2			
	Magnetic			
P12.12	saturation			
	coefficient 2 of	0.0–100.0%	68%	0
1 12.12	iron core of	0.0 100.070	00 /6	
	asynchronous			
	motor 2			

Function			Default	Modi
Function code	Name	Detailed parameter description	Default value	fy
COGC	Magnetic		Value	·y
	saturation			
	coefficient 3 of			
P12.13	iron core of	0.0–100.0%	57%	0
	asynchronous			
	motor 2			
	Magnetic			
	saturation			
	coefficient 4 of			
P12.14	iron core of	0.0–100.0%	40%	0
	asynchronous			
	motor 2			
	Rated power of			
P12.15	synchronous	0.1–3000.0kW	Depend	0
	motor 2		on model	
	Rated frequency			
P12.16	of synchronous	0.01Hz–P00.03 (Max. output frequency)	50.00Hz	0
	motor 2			
	Number of pole			
D40.47	pairs of	1–128	0	
P12.17	synchronous		2	0
	motor 2			
	Rated voltage of		Donand	
P12.18	synchronous	0–1200V	Depend on model	0
	motor 2		on model	
	Rated voltage of		Depend	
P12.19	synchronous	0.8–6000.0A	on model	0
	motor 2		on model	
	Stator resistance		Depend	
P12.20	of synchronous	0.001–65.535Ω	on model	0
	motor 2		on model	
	Direct-axis			
P12.21	inductance of	0.01–655.35mH	Depend	0
1 12.21	synchronous	0.01 000.001111	on model	
	motor 2			
	Quadrature-axis			
P12.22	inductance of	0.01–655.35mH	Depend	0
	synchronous		on model	
	motor 2	102		

Function code	Name	Detailed parameter description	Default value	Modi fy
P12.23	Counter-emf constant of synchronous motor 2	0-10000V	300	0
P12.24	Reserved	0-0xFFFF	0x0000	•
P12.25	Reserved	0%-50% (of the rated current of the motor)	10%	•
P12.26	Overload protection of motor 2	O: No protection 1: Common motor (with low-speed compensation) 2: Frequency-variable motor (without low-speed compensation)	2	0
P12.27	Overload protection coefficient of motor 2	Motor overload multiples M = lout/(lnxK) In is rated motor current, lout is inverter output current, K is motor overload protection coefficient. The smaller the K, the larger the value of M, the easier the protection. if M is 116%, protection will be applied when motor overloads for 1h; if M is 200%, protection will be applied when motor overloads for 60s; if M is no less than 400%, protection will be applied immediately.	100.0%	0
P12.28	Power display calibration coefficient of motor 2	0.00–3.00	1.00	0
P12.29	Parameter display of motor 2	O: Display based on the motor type; under this mode, only parameters related to current motor type will be displayed. 1: Display all; under this mode, all the parameters will be displayed.	0	0
P12.30	System inertia of motor 2	0–30.000kgm²	0.000	0

Function code	Name	Detailed parameter description	Default value	Modi fy
P12.31-	Reserved		value	ıy
P12.32	variables	0–65535	0	0
P13 grou		neters of synchronous motor		ı
g	p common pummin	This parameter is used to set the reduction rate of		
	Reduction rate of	the input reactive current. When the active current of		
	the injection	the synchronous motor increases to some extent,		
P13.00	current of	the input reactive current can be reduced to improve	80.0%	0
	synchronous	the power factor of the motor.		
	motor	Setting range: 0.0%–100.0% (of the rated current of		
		the motor)		
		0: Disabled		
P13.01	Initial pole	1: In pulse detection mode	0	0
	detection mode	2: In pulse detection mode		
		Input current is the pole position orientation current;		
	Input current 1	input current 1 is valid within the lower limit of input		
		current switch-over frequency threshold. If users		
P13.02		need to increase the starting torque, increase the	20.0%	0
		value of this function code properly.		
		Setting range: 0.0%–100.0% (rated motor current)		
		Input current is the pole position orientation current;		
	Input current 2	input current 2 is valid within the upper limit of input		
D. 10.00		current switch-over frequency threshold, and users	40.00/	
P13.03		do not need to change input current 2 under	10.0%	0
		common situations.		
		Setting range: 0.0%–100.0% (rated motor current)		
	Switch-over			
P13.04	frequency of	0.00Hz–P00.03 (Max. output frequency)	10.00Hz	0
	input current			
	High-frequency			
P13.05	superposition	200Hz-1000Hz	500Hz	0
P13.05	frequency	20002-100002	300HZ	0
	(reserved)			
		This parameter is used to set the pulse current		
		threshold when the initial magnetic pole position is		
P13.06	Pulse current	detected in the pulse mode. The value is a	100.0%	0
1 13.00	setting	percentage in relative to the rated current of the	100.070	9
		motor.		
		Setting range: 0.0-300.0% (of the rated voltage of		

Function code	Name	Detailed parameter description	Default value	Modi fy
		the motor)		
P13.07	Reserved variables	0.0–400.0	0.0	0
P13.08	Control parameter 1	0–0xFFFF	0	0
P13.09	Control parameter 2	This parameter is used to set the frequency threshold for enabling the counter-electromotive force phase-locked loop in SVC 0. When the running frequency is lower than the value of this parameter, the phase-locked loop is disabled; and when the running frequency is higher than that, the phase-locked loop is enabled. Setting range: 0–655.35	2.00	0
P13.10	Reserved variables	0.0–359.9	0.0	0
P13.11	Maladjustment detection time	This parameter is used to adjust the responsiveness of anti-maladjustment function. If the load inertia is large, increase the value of this parameter properly, however, the responsiveness may slow down accordingly. Setting range: 0.0–10.0s	0.5s	0
P13.12	High-frequency compensation coefficient of synchronous motor	This parameter is valid when the motor speed exceeds the rated speed. If motor oscillation occurred, adjust this parameter properly. Setting range: 0.0–100.0%	0.0	0
P13.13-	Reserved	0–65535	0	0
P13.19	variables			
P14 grou	p Serial commu	Inication function		1
P14.00	Local communication address	Setting range: 1–247 When the master is writing frames, and the slave communication address is set to 0, it is the broadcast communication address, and all the slaves on the MODBUS bus will accept this frame, but the slave never responds. Local communication address is unique in the communication network, which is the basis for point-to-point communication between the upper	1	0

code computer and the inverter. Note: The slave address cannot be set to 0. This parameter is used to set the data transmission speed between upper computer and the inverter. 0: 1200BPS 1: 2400BPS 2: 4800BPS 3: 9600BPS 4: 19200BPS 6: 57600BPS 7: 115200BPS Note: Baud rate of the upper computer must be the same with the inverter; otherwise, communication speed. The data format of upper computer must be the same with the inverter; otherwise, communication cannot be performed. The larger the baud rate, the faster the communication speed. Data bit check setup Data bit check setup Data bit check setup Data bit check setup Communication cannot be performed. 1: Even parity (E, 8, 1) for RTU 2: Odd parity (O, 8, 1) for RTU 3: No parity check (N, 8, 2) for RTU 4: Even parity (E, 8, 1) for RTU 5: Odd parity (O, 8, 2) for RTU 6: Even parity (E, 8, 1) for RTU 7: Even parity (E, 8, 1) for RTU 8: Even parity (E, 8, 1) for RTU 9: Odd parity (O, 8, 2) for RTU 9: Odd parity (O, 8, 2	Function	Name	Detailed parameter description	Default	Modi
Note: The slave address cannot be set to 0. This parameter is used to set the data transmission speed between upper computer and the inverter. 0: 1200BPS 1: 2400BPS 2: 4800BPS 3: 9600BPS 4: 19200BPS 6: 57600BPS 7: 115200BPS Note: Baud rate of the upper computer must be the same with the inverter; otherwise, communication cannot be performed. The larger the baud rate, the faster the communication speed. The data format of upper computer must be the same with the inverter; otherwise, communication cannot be performed. O: No parity check (N, 8, 1) for RTU 1: Even parity (E, 8, 1) for RTU 2: Odd parity (O, 8, 2) for RTU 4: Even parity (E, 8, 2) for RTU 5: Odd parity (O, 8, 2) for RTU 5: Odd parity (O, 8, 2) for RTU 6-200ms 1t refers to the time interval from when the data is received by the inverter to the moment when the data is sent to the upper computer. If the response delay is less than the system processing time, the response delay will be subject to system processing time; if the response delay is longer than the system processing time; if the response delay is longer than the system processing time; if the response delay is longer than the system processing time, data will be sent to the upper computer at a delay after data process is done by system. Communication timeout period ti	code	Name	Detailed parameter description	value	fy
This parameter is used to set the data transmission speed between upper computer and the inverter. 0: 1200BPS 1: 2400BPS 2: 4800BPS 3: 9600BPS 4: 19200BPS 6: 57600BPS 7: 115200BPS Note: Baud rate of the upper computer must be the same with the inverter; otherwise, communication speed. The data format of upper computer must be the same with the inverter; otherwise, communication cannot be performed. The larger the baud rate, the faster the communication speed. The data format of upper computer must be the same with the inverter; otherwise, communication cannot be performed. 0: No parity check (N, 8, 1) for RTU 1: Even parity (E, 8, 1) for RTU 2: Odd parity (O, 8, 1) for RTU 3: No parity check (N, 8, 2) for RTU 4: Even parity (E, 8, 2) for RTU 5: Odd parity (O, 8, 2) for RTU 5: Odd parity (O, 8, 2) for RTU 6-200ms 8 trefers to the time interval from when the data is received by the inverter to the moment when the data is sent to the upper computer. If the response delay is less than the system processing time, the response delay will be subject to system processing time; if the response delay is longer than the system processing time; if the response delay is longer than the system processing time; if the response delay is longer than the system processing time; if the response delay is longer than the system processing time; if the response delay is longer than the system processing time; if the response delay after data process is done by system. 0.0 (invalid) -60.0s This parameter will be invalid if it is set to 0.0; 0.0s			computer and the inverter.		
speed between upper computer and the inverter. 0: 1200BPS 1: 2400BPS 2: 4800BPS 3: 9600BPS 4: 19200BPS 5: 38400BPS 6: 57600BPS 7: 115200BPS Note: Baud rate of the upper computer must be the same with the inverter; otherwise, communication speed. P14.02 Data bit check setup Data bit check setup			Note: The slave address cannot be set to 0.		
P14.01 P14.01 Communication baud rate setup P14.02 Data bit check setup Communication cannot be performed. Data bit check setup Cod parity (C, 8, 1) for RTU Sod parity (C, 8, 1) for RTU Sod parity (C, 8, 2) for RTU Sod parity (C, 8, 2) for RTU Communication response delay will be subject to system processing time, the response delay will be subject to system processing time; if the response delay is longer than the system processing time, if the response delay is longer than the system processing time, if the response delay is longer than the system processing time, at a delay after data process is done by system. Communication timeout period timeout per			This parameter is used to set the data transmission		
P14.01 P14.01 P14.01 P14.01 P14.01 P14.02 P14.02 P14.02 P14.03 P14.03 P14.04 P14.04 Communication baud rate setup P14.04 P14.04 Communication baud rate setup P14.05 P14.06 P14.06 P14.06 P14.07 P14.06 P14.06 P14.07 P14.08 P14.08 P14.09 P14.09 P14.00 P14.0			speed between upper computer and the inverter.		
P14.01 P14.01 Communication baud rate setup 2: 4800BPS 3: 9600BPS 4: 19200BPS 5: 38400BPS 6: 57600BPS 7: 115200BPS Note: Baud rate of the upper computer must be the same with the inverter; otherwise, communication speed. The data format of upper computer must be the same with the inverter; otherwise, communication cannot be performed. Data bit check setup Sold parity (D, 8, 1) for RTU Sold parity (D, 8, 1) for RTU Sold parity (D, 8, 2) for RTU Sold parity (D, 8, 2) for RTU Sold parity (D, 8, 2) for RTU Communication response delay sold be subject to system processing time, the response delay will be subject to system processing time, if the response delay is longer than the system processing time, if the response delay is longer than the system processing time, if the response delay is longer than the system processing time, if the response delay is longer than the system processing time, if the response delay is longer than the system processing time, and a will be sent to the upper computer at a delay after data process is done by system. Data bit check setup Sold parity (D, 8, 1) for RTU Sold parity (D, 8, 2) for			0: 1200BPS		
P14.01 P14.01 Communication baud rate setup S: 38400BPS 4: 19200BPS 5: 38400BPS 6: 57600BPS 7: 115200BPS Note: Baud rate of the upper computer must be the same with the inverter; otherwise, communication cannot be performed. The larger the baud rate, the faster the communication speed. P14.02 Data bit check setup Set			1: 2400BPS		
P14.01 Communication baud rate setup 4			2: 4800BPS		
P14.01 Communication baud rate setup 5: 38400BPS 6: 57600BPS 7: 115200BPS Note: Baud rate of the upper computer must be the same with the inverter; otherwise, communication cannot be performed. The larger the baud rate, the faster the communication speed. The data format of upper computer must be the same with the inverter; otherwise, communication cannot be performed. 0: No parity check (N, 8, 1) for RTU 1: Even parity (E, 8, 1) for RTU 2: Odd parity (O, 8, 1) for RTU 3: No parity check (N, 8, 2) for RTU 4: Even parity (E, 8, 2) for RTU 5: Odd parity (O, 8, 2) for RTU 0-200ms It refers to the time interval from when the data is received by the inverter to the moment when the data is sent to the upper computer. If the response delay is less than the system processing time; if the response delay is longer than the system processing time; if the response delay is longer than the system processing time, data will be sent to the upper computer at a delay after data process is done by system. P14.04 Communication timeout period Communication timeout period This parameter will be invalid if it is set to 0.0; 0.00 (invalid) -60.0s This parameter will be invalid if it is set to 0.0;			3: 9600BPS		
P14.01 baud rate setup 5: 38400BPS 6: 57600BPS 7: 115200BPS Note: Baud rate of the upper computer must be the same with the inverter; otherwise, communication cannot be performed. The larger the baud rate, the faster the communication speed.		Communication	4: 19200BPS		
P14.02 Data bit check setup Data bit check setup Data bit check setup Communication Communication P14.03 Communication response delay Communication Communication Communication Communication Communication Communication response delay Communication Communication Communication Timeout period Communication The data format of upper computer must be the same with the inverter; otherwise, Communication the period the inverter; otherwise, communication the same with the inverter; otherwise, communication to response delay (N, 8, 1) for RTU 1	P14.01		5: 38400BPS	4	0
Note: Baud rate of the upper computer must be the same with the inverter; otherwise, communication cannot be performed. The larger the baud rate, the faster the communication speed. The data format of upper computer must be the same with the inverter; otherwise, communication cannot be performed. O: No parity check (N, 8, 1) for RTU 1: Even parity (E, 8, 1) for RTU 2: Odd parity (O, 8, 1) for RTU 4: Even parity (E, 8, 2) for RTU 5: Odd parity (O, 8, 2) for RTU 5: Odd parity (O, 8, 2) for RTU Communication response delay Communication response delay Communication fit the response delay after data process is done by system. O.0 (invalid) –60.0s This parameter will be invalid if it is set to 0.0; O.0s		badd rate setup	6: 57600BPS		
the same with the inverter; otherwise, communication cannot be performed. The larger the baud rate, the faster the communication speed. The data format of upper computer must be the same with the inverter; otherwise, communication cannot be performed. 0: No parity check (N, 8, 1) for RTU 1: Even parity (E, 8, 1) for RTU 2: Odd parity (O, 8, 1) for RTU 3: No parity check (N, 8, 2) for RTU 4: Even parity (E, 8, 2) for RTU 5: Odd parity (O, 8, 2) for RTU 5: Odd parity (O, 8, 2) for RTU 0-200ms It refers to the time interval from when the data is received by the inverter to the moment when the data is sent to the upper computer. If the response delay is less than the system processing time, the response delay will be subject to system processing time; if the response delay is longer than the system processing time; if the response delay is longer than the system processing time, data will be sent to the upper computer at a delay after data process is done by system. D.0 (invalid) -60.0s This parameter will be invalid if it is set to 0.0; 0.0s			7: 115200BPS		
Communication cannot be performed. The larger the baud rate, the faster the communication speed. The data format of upper computer must be the same with the inverter; otherwise, communication cannot be performed. 0: No parity check (N, 8, 1) for RTU 1: Even parity (E, 8, 1) for RTU 2: Odd parity (O, 8, 1) for RTU 3: No parity check (N, 8, 2) for RTU 4: Even parity (E, 8, 2) for RTU 5: Odd parity (O, 8, 2) for RTU 0-200ms It refers to the time interval from when the data is received by the inverter to the moment when the data is sent to the upper computer. If the response delay is less than the system processing time; if the response delay is longer than the system processing time; if the response delay is longer than the system processing time; if the response delay after data process is done by system. P14.04 Communication timeout period Communication timeout period Communication timeout period			Note: Baud rate of the upper computer must be		
the baud rate, the faster the communication speed. The data format of upper computer must be the same with the inverter; otherwise, communication cannot be performed. O: No parity check (N, 8, 1) for RTU 1: Even parity (E, 8, 1) for RTU 2: Odd parity (O, 8, 1) for RTU 3: No parity check (N, 8, 2) for RTU 4: Even parity (E, 8, 2) for RTU 5: Odd parity (O, 8, 2) for RTU 0-200ms It refers to the time interval from when the data is received by the inverter to the moment when the data is sent to the upper computer. If the response delay is less than the system processing time; if the response delay will be subject to system processing time; if the response delay is longer than the system processing time; if the response delay is longer than the system processing time, data will be sent to the upper computer at a delay after data process is done by system. P14.04 Communication timeout period Communication timeout period Communication timeout period			the same with the inverter; otherwise,		
P14.02 Data bit check setup Data bit check same with the inverter; otherwise, communication cannot be performed. Data bit check same with the inverter; otherwise, communication same with the inverter to the motion setup. Data bit check same with the inverter; otherwise, communication same with the inverter to the utility setup. Data bit check same with the inverter; otherwise, communication same with			communication cannot be performed. The larger		
P14.02 Data bit check setup Data bit check same with the inverter; otherwise, communication setup. Data bit check same with the inverter; otherwise, communication setup. Data bit check same with the inverter setup. P14.02 Data bit check same with the inverter; otherwise, communication setup. Data bit check same with the inverter; otherwise, communication setup. Data bit check same with the inverter; otherwise, communication setup. Data bit check same with the inverter; otherwise, communication setup. P14.03 Data bit check same with the inverter; otherwise, communication setup. Data bit check same with the inverter; otherwise, communication setup. Data bit check same with the inverter; otherwise, communication setup. Data bit check same with the inverter setup. Data bit check same with the inverter setup. Data bit check same with the inverter setup. Data bit setup. Data bit check same with the inverter setup. Data bit set			the baud rate, the faster the communication		
P14.02 Data bit check setup Setup Data bit check setup Data bit check setup Setup Data bit check setup Data bit check setup Setup Data bit check (N, 8, 1) for RTU Data bit setup Setup Data bit check (N, 8, 1) for RTU Setup setup Data bit setup Dat			speed.		
P14.02 Data bit check setup Data bit check setup Data bit check S			The data format of upper computer must be the		
P14.02 Data bit check setup 0: No parity check (N, 8, 1) for RTU 1: Even parity (E, 8, 1) for RTU 2: Odd parity (O, 8, 1) for RTU 3: No parity check (N, 8, 2) for RTU 4: Even parity (E, 8, 2) for RTU 5: Odd parity (O, 8, 2) for RTU 0-200ms It refers to the time interval from when the data is received by the inverter to the moment when the data is sent to the upper computer. If the response delay is less than the system processing time, the response delay will be subject to system processing time; if the response delay is longer than the system processing time; if the response delay is longer than the system processing time, data will be sent to the upper computer at a delay after data process is done by system. P14.04 Communication timeout period Communication timeout period O: No parity check (N, 8, 1) for RTU 1: Even parity (E, 8, 2) for RTU 4: Even parity (E, 8, 2) for RTU 5: Odd parity (O, 8, 2			same with the inverter; otherwise, communication		
P14.02 Data bit check setup 1: Even parity (E, 8, 1) for RTU 2: Odd parity (O, 8, 1) for RTU 3: No parity check (N, 8, 2) for RTU 4: Even parity (E, 8, 2) for RTU 5: Odd parity (O, 8, 2) for RTU 0-200ms It refers to the time interval from when the data is received by the inverter to the moment when the data is sent to the upper computer. If the response delay is less than the system processing time, the response delay will be subject to system processing time; if the response delay is longer than the system processing time; if the response delay is longer than the system processing time, data will be sent to the upper computer at a delay after data process is done by system. P14.04 Communication timeout period Communication timeout period This parameter will be invalid if it is set to 0.0; 0.0s			cannot be performed.		
P14.02 Setup 1: Even parity (E, 8, 1) for RTU 2: Odd parity (O, 8, 1) for RTU 3: No parity check (N, 8, 2) for RTU 4: Even parity (E, 8, 2) for RTU 5: Odd parity (O, 8, 2) for RTU 0-200ms It refers to the time interval from when the data is received by the inverter to the moment when the data is sent to the upper computer. If the response delay is less than the system processing time, the response delay will be subject to system processing time; if the response delay is longer than the system processing time, data will be sent to the upper computer at a delay after data process is done by system. P14.04 Communication timeout period Communication timeout period This parameter will be invalid if it is set to 0.0; 0.0s			0: No parity check (N, 8, 1) for RTU		
P14.03 2: Odd parity (O, 8, 1) for RTU 3: No parity check (N, 8, 2) for RTU 4: Even parity (E, 8, 2) for RTU 5: Odd parity (O, 8, 2) for RTU 0-200ms It refers to the time interval from when the data is received by the inverter to the moment when the data is sent to the upper computer. If the response delay is less than the system processing time, the response delay will be subject to system processing time; if the response delay is longer than the system processing time; if the response delay is longer than the system processing time, data will be sent to the upper computer at a delay after data process is done by system. Communication timeout period Communication timeout period Communication timeout period This parameter will be invalid if it is set to 0.0;	P14.02		1: Even parity (E, 8, 1) for RTU	1	0
4: Even parity (E, 8, 2) for RTU 5: Odd parity (O, 8, 2) for RTU 0–200ms It refers to the time interval from when the data is received by the inverter to the moment when the data is sent to the upper computer. If the response delay is less than the system processing time, the response delay will be subject to system processing time; if the response delay is longer than the system processing time, data will be sent to the upper computer at a delay after data process is done by system. P14.04 Communication timeout period Communication timeout period This parameter will be invalid if it is set to 0.0; 0.0s		setup	2: Odd parity (O, 8, 1) for RTU		
P14.03 Signature Communication response delay Communication timeout period			3: No parity check (N, 8, 2) for RTU		
P14.03 Communication response delay it refers to the time interval from when the data is received by the inverter to the moment when the data is sent to the upper computer. If the response delay is less than the system processing time, the response delay will be subject to system processing time; if the response delay is longer than the system processing time, data will be sent to the upper computer at a delay after data process is done by system. Communication timeout period Communication timeout period Communication timeout period This parameter will be invalid if it is set to 0.0; O.0s			4: Even parity (E, 8, 2) for RTU		
P14.03 Communication response delay if the response delay will be subject to system processing time; if the response delay is longer than the system processing time; if the response delay is longer than the system processing time; if the response delay is longer than the system processing time; if the response delay is longer than the system processing time, data will be sent to the upper computer at a delay after data process is done by system. Communication timeout period Communication timeout period Communication timeout period This parameter will be invalid if it is set to 0.0;			5: Odd parity (O, 8, 2) for RTU		
P14.03 Communication response delay is less than the system processing time; if the response delay is longer than the system processing time; if the response delay is longer than the system processing time; if the response delay is longer than the system processing time, data will be sent to the upper computer at a delay after data process is done by system. Communication timeout period Communication timeout period Communication timeout period Communication timeout period P14.04 P14.04 Communication timeout period			0–200ms		
P14.03 Communication response delay is less than the system processing time, the response delay will be subject to system processing time; if the response delay is longer than the system processing time; if the response delay is longer than the system processing time, data will be sent to the upper computer at a delay after data process is done by system. P14.04 Communication timeout period Communication timeout period D.0 (invalid) –60.0s This parameter will be invalid if it is set to 0.0;			It refers to the time interval from when the data is		
P14.03 Communication response delay is less than the system processing time, the response delay will be subject to system processing time; if the response delay is longer than the system processing time, data will be sent to the upper computer at a delay after data process is done by system. P14.04 Communication timeout period Communication timeout period D14.05 Communication timeout period D25 Communication timeout period D36 Communication timeout period D37 Communication timeout period D38 Communication timeout period D38 Communication timeout period D38 Communication timeout period D39 Communication timeout period D30 Communication timeout period D30 Communication timeout period			received by the inverter to the moment when the		
response delay response delay will be subject to system processing time; if the response delay is longer than the system processing time, data will be sent to the upper computer at a delay after data process is done by system. Communication timeout period Communication timeout period			data is sent to the upper computer. If the response		
response delay response delay will be subject to system processing time; if the response delay is longer than the system processing time, data will be sent to the upper computer at a delay after data process is done by system. Communication timeout period Communication timeout period		Communication	delay is less than the system processing time, the	_	
processing time, data will be sent to the upper computer at a delay after data process is done by system. P14.04 Communication timeout period This parameter will be invalid if it is set to 0.0; 0.0s O.0s	P14.03	response delay	response delay will be subject to system processing	5	O
computer at a delay after data process is done by system. Delay after data process is done by system. O.0 (invalid) –60.0s This parameter will be invalid if it is set to 0.0; O.0s			time; if the response delay is longer than the system		
system. P14.04 Communication timeout period timeou			processing time, data will be sent to the upper		
P14.04 Communication timeout period			computer at a delay after data process is done by		
P14.04 Communication timeout period This parameter will be invalid if it is set to 0.0; 0.0s			system.		
P14.04 Communication timeout period This parameter will be invalid if it is set to 0.0; 0.0s					
I I timeout period I	P14.04		` '	0.0s	0
I WINCH ILIO SCLIU A HUH-ZEHU VAIUE. II LIIE IIIILEIVAH		timeout period	When it is set to a non-zero value, if the time interval		

Function	Name	Detailed negameter description	Default	Modi
code	Name	Detailed parameter description	value	fy
		between current communication and the next		
		communication exceeds the communication timeout		
		period, the system will report "485 communication		
		fault" (CE).		
		Under common situations, it is set to 0.0. In systems		
		which have continuous communication, users can		
		monitor the communication condition by setting this		
		parameter.		
		0: Alarm and coast to stop		
		1: Do not alarm and continue running		
D44.05	Transmission	2: Do not alarm and stop as per the stop mode		
P14.05	error processing	(under communication control mode only)	0	0
		3: Do not alarm and stop as per the stop mode		
		(under all control modes)		
	Communication processing action	0x00–0x11		
		Ones:		
		0: Write operation has response		
P14.06		1: Write operation has no response	0x00	0
		Tens:		
		0: Communication password protection is invalid		
		1: Communication password protection is valid		
P14.07-	Reserved	0.05525	0	
P14.24	variables	0–65535	0	
P15 grou	p Functions of	communication extension card 1		
P15.00-	See the operation	manual of communication extension card for details		
P15.27	See the operation			
P15.28	Master/slave	0–127	1	0
	CAN			
	communication			
	address			
P15.29	Master/slave	0: 50Kbps	2	0
	CAN	1: 100 Kbps		
	communication	2: 125Kbps		
	baud rate	3: 250Kbps		
	selection	4: 500Kbps		
		5: 1M bps		
P15.30	Master/slave	0.0 (invalid)–300.0s	0.0s	0
	CAN			

Function code	Name	Detailed parameter description	Default value	Modi fy
	communication timeout period			
P15.31– P15.69	See the operation	manual of communication extension card for details		
P16 grou	p Functions of	communication extension card 2		
P16.00– P16.23	See the operation	manual of communication extension card for details		
P16.24	Identification time for the extension card in card slot 1	0.0–600.0s If it is set to 0.0, identification fault will not be detected	0.0s	0.0
P16.25	Identification time for the extension card in card slot 2	0.0–600.0s If it is set to 0.0, offline fault will not be detected	0.0s	0.0
P16.26	Identification time for the extension card in card slot 3	0.0–600.0s If it is set to 0.0, offline fault will not be detected	0.0s	/
P16.27	Communication timeout period of extension card in card slot 1	0.0–600.0s If it is set to 0.0, offline fault will not be detected	0.0s	/
P16.28	Communication timeout period of extension card in card slot 2	0.0–600.0s If it is set to 0.0, offline fault will not be detected	0.0s	/
P16.29	Communication timeout period of extension card in card slot 3	0.0–600.0s If it is set to 0.0, offline fault will not be detected	0.0s	/
P16.30– P16.69	See the operation	manual of communication extension card for details		
P17 grou	p State-check fu	unctions		
P17.00	Set frequency	Display current set frequency of the inverter. Range: 0.00Hz–P00.03	50.00Hz	•
P17.01	Output frequency	Display current output frequency of the inverter. Range: 0.00Hz–P00.03	0.00Hz	•

Function code	Name	Detailed parameter description	Default value	Modi fy
P17.02	Ramps reference frequency	Display current ramps reference frequency of the inverter. Range: 0.00Hz–P00.03	0.00Hz	•
P17.03	Output voltage	Display current output voltage of the inverter. Range: 0–1200V	0V	•
P17.04	Output current	Display the valid value of current output current of the inverter. Range: 0.0–5000.0A	0.0A	•
P17.05	Motor speed	Display current motor speed. Range: 0–65535RPM	0 RPM	•
P17.06	Torque current	Display current torque current of the inverter. Range: -3000.0–3000.0A	0.0A	•
P17.07	Exciting current	Display current exciting current of the inverter. Range: -3000.0–3000.0A	0.0A	•
P17.08	Motor power	Display current motor power; 100% relative to rated motor power, positive value is motoring state, negative value is generating state. Range: -300.0–300.0% (relative to rated motor power)	0.0%	•
P17.09	Motor output torque	Display current output torque of the inverter; 100% relative to rated motor torque, during forward running, positive value is motoring state, negative value is generating state, during reverse running, positive value is generating state, negative value is motoring state. Range: -250.0–250.0%	0.0%	•
P17.10	Estimated motor frequency	The estimated motor rotor frequency under open-loop vector condition. Range: 0.00– P00.03	0.00Hz	•
P17.11	DC bus voltage	Display current DC bus voltage of the inverter. Range: 0.0–2000.0V	0V	•
P17.12	Digital input terminal state	Display current digital input terminal state of the inverter. 0000-03F Corresponds to HDIB, HDIA, S4, S3, S2 and S1 respectively	0	•
P17.13	Digital output terminal state	Display current digital output terminal state of the inverter.	0	•

Function		Datailed wavenester description	Default	Modi
code	Name	Detailed parameter description	value	fy
		0000-000F		
		Corresponds to R02, RO1, HDO and Y1 respectively		
	Digital	Display the regulating variable by UP/DOWN		
P17.14	adjustment	terminals of the inverter.	0.00Hz	•
	variable	Range: 0.00Hz-P00.03		
	Torque reference	Relative to percentage of the rated torque of current		
P17.15	Torque reference value	motor, display torque reference.	0.0%	•
	value	Range: -300.0%–300.0% (rated motor current)		
P17.16	Linear speed	0–65535	0	•
P17.17	Reserved	0–65535	0	
P17.17	variables	0-0000	0	
P17.18	Count value	0–65535	0	•
D47.40	A14 :	Display input signal of Al 1	0.001/	
P17.19	Al1 input voltage	Range: 0.00-10.00V	0.00V	
P17.20	Al2 input voltage	Display input signal of Al2	0.00V	
P17.20	Al2 input voltage	Range: -10.00V–10.00V	0.000	
P17.21	HDIA input	Display input frequency of HDIA	0.000	
F17.21	frequency	Range: 0.000–50.000kHz	kHz	
P17.22	HDIB input	Display input frequency of HDIB	0.000	
1 17.22	frequency	Range: 0.000–50.000kHz	kHz	
P17.23	PID reference	Display PID reference value	0.0%	
F 17.23	value	Range: -100.0–100.0%	0.076	
P17.24	PID feedback	Display PID feedback value	0.0%	
F 17.24	value	Range: -100.0–100.0%	0.076	
P17.25	Motor power	Display the power factor of current motor.	1.00	
1 17.20	factor	Range: -1.00–1.00	1.00	
P17.26	Current running	Display current running time of the inverter.	0m	
F 17.20	time	Range: 0–65535min	OIII	
	Simple PLC and	Display simple PLC and current step number of		
P17.27	current step	multi-step speed	0	
1 17.27	number of	Range: 0–15	O	
	multi-step speed	inango. o 10		
		Display the speed loop ASR controller output value		
P17.28	Motor ASR	under vector control mode, relative to the percentage	0.0%	•
23	controller output	of rated torque of the motor.	2.070	-
		Range: -300.0%–300.0% (rated motor current)		<u> </u>
P17.29	Pole angle of	Display initial identification angle of synchronous	0.0	•
	open-loop	motor		

Function	Name	Detailed parameter description		Modi
code			value	fy
	synchronous	Range: 0.0–360.0		
	motor			
	Phase			
P17.30	compensation of	Display phase compensation of synchronous motor	0.0	•
	synchronous	Range: -180.0–180.0		
	motor			
	High-frequency			
	superposition			
P17.31	current of	0.0%-200.0% (rated motor current)	0.0	•
	synchronous			
	motor			
P17.32	Motor flux linkage	0.0%–200.0%	0.0%	•
	Exciting current	Display the exciting current reference value under		
P17.33	reference	vector control mode	0.0A	•
	Tererence	Range: -3000.0–3000.0A		
	Torque current	Display torque current reference value under vector		
P17.34	Torque current reference	control mode	0.0A	•
	reference	Range: -3000.0–3000.0A		
	AC incoming current	Display the valid value of incoming current on AC	0.0A	
P17.35		side		•
		Range: 0.0–5000.0A		
		Display output torque value, during forward running,		
		positive value is motoring state, negative value is		
P17.36	Output torque	generating state; during reverse running, positive	0.0Nm	
1 17.00	Output torque	value is generating state, negative value is motoring	0.014111	
		state.		
		Range: -3000.0Nm-3000.0Nm		
P17.37	Motor overload	0–65535	0	•
1 17.07	count value			
P17.38	Process PID	-100.0%—100.0%	0.00%	•
1 17.00	output	100.070	0.0070	
	Parameter			
P17.39	download wrong	0.00–99.00	0.00	•
	function code			
		Ones: Control mode		
P17.40	Motor control	0: Vector 0	2	•
	mode	1: Vector 1	-	
		2: SVPWM control		

Function			Default	Modi
code	Name	Detailed parameter description	value	fy
		3: VC		
		Tens: Control state		
		0: Speed control		
		1: Torque control		
		Hundreds: Motor number		
		0: Motor 1		
		1: Motor 2		
	Upper limit of the			
P17.41	torque when	0.0%-300.0% (rated motor current)	180.0%	•
	motoring			
	Upper limit of			_
P17.42	brake torque	0.0%–300.0% (rated motor current)	180.0%	•
	Upper limit			
	frequency of			_
P17.43	forward running	0.00-P00.03	50.00Hz	•
	of torque control			
	Upper limit			
	frequency of	0.00-P00.03		
P17.44	reverse running		50.00Hz	•
	of torque control			
	Inertia			
P17.45	compensation	-100.0%–100.0%	0.0%	•
	torque			
	Friction			
P17.46	compensation	-100.0%–100.0%	0.0%	•
	torque			
P17.47	Motor pole pairs	0–65535	0	•
5.1- 1-	Inverter overload			
P17.48	count value	0–65535	0	•
D47.40	Frequency set by	0.00 000 00	0.0011-	
P17.49	A source	0.00-P00.03	0.00Hz	•
D47.50	Frequency set by	0.00 000 00	0.001.1-	
P17.50	B source	0.00-P00.03	0.00Hz	
D17.51	PID proportional	100.09/, 100.09/	0.009/	
P17.51	output	-100.0%–100.0%	0.00%	•
D47.50	PID integral	400.00/, 400.00/	0.000/	
P17.52	output	-100.0%–100.0%	0.00%	
P17.53	PID differential	-100.0%—100.0%	0.00%	•

Function code	Name	Detailed parameter description	Default value	Modi fy
	output			
P17.54– P17.63	Reserved variables	0–65535	0	•
P18 grou	p Closed-loop o	control state check		
P18.00	Actual frequency of encoder	The actual-measured encoder frequency; the value of forward running is positive; the value of reverse running is negative. Range: -999.9–3276.7Hz	0.0Hz	•
P18.01	Encoder position count value	Encoder count value, quadruple frequency, Range: 0–65535	0	•
P18.02		Corresponding count value of encoder Z pulse. Range: 0–65535	0	•
P18.03	High bit of position reference value	High bit of position reference value, zero out after stop. Range: 0–30000	0	•
P18.04	Low bit of position reference value	Low bit of position reference value, zero out after stop. Range: 0–65535	0	•
P18.05	High bit of position feedback value	High bit of position feedback value, zero out after stop. Range: 0–30000	0	•
P18.06	Low bit of position feedback value	Low bit of position feedback value, zero out after stop. Range: 0–65535	0	•
P18.07	Position deviation	Deviation between current reference position and actual running position. Range: -32768–32767	0	•
P18.08	Position of position reference point	Position of reference point of Z pulse when the spindle stops accurately. Range: 0–65535	0	•
P18.09	Current position setup of spindle	Current position setup when the spindle stops accurately. Range: 0–359.99	0.00	•
P18.10	Current position when spindle stops accurately	Current position when spindle stops accurately. Range: 0–65535	0	•
P18.11	Encoder Z pulse direction	Z pulse direction display. When the spindle stops accurately, there may be a couple of pulses' error	0	•

between the position of forward and reverse orientation, which can be eliminated by adjusting Z pulse direction of P20.02 or exchanging phase AB of encoder. D: Forward 1: Reverse P18.12 Encoder Z pulse angle Reserved. Angle: 0.00–359.99 P18.13 Encoder Z pulse error times High bit of encoder pulse count value Low bit of encoder pulse count value P18.15 Pulse command frequency P18.16 Reserved variables P18.17 Pulse command frequency P18.18 Pulse command (A2, B2 terminal) is converted to the set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0-655.35Hz P18.19 Position regulator output P18.20 Count value of resolver Range: 0-65535 The output frequency of the position regulator during position control. Range: 0-655.35 The pole position angle read according to the resolver-type encoder. Range: 0.00–359.99 P18.21 Resolver angle P18.22 Count value of closed-loop synchronous P18.23 Current pole position. Range: 0.00–359.99 Delagage Original for the resolver-type encoder. Range: 0.00–359.99 O.000 Incompany AB of the reverse orientation, which can be eliminated by adjusting Z pulse and pulse and pulse immanded to the set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0-655.35Hz P18.21 Resolver angle P18.22 Count value of resolver. Range: 0-655.35 The pole position angle read according to the resolver-type encoder. Range: 0.00–359.99 P18.22 Current pole position. Range: 0.00–359.99	Function	Name	Detailed parameter description	Default	Modi
orientation, which can be eliminated by adjusting Z pulse direction of P20.02 or exchanging phase AB of encoder. 0: Forward 1: Reverse P18.12 Encoder Z pulse angle Reserved. Range: 0.00–359.99 P18.13 Encoder Z pulse error times Range: 0.65535 High bit of encoder pulse count value Low bit of encoder pulse count value P18.15 Pulse command frequency Pulse command frequency mode and pulse speed mode. Range: 0-655.35Hz P18.18 Pulse command feedforward mode and pulse speed mode. Range: 0-655.35Hz P18.19 Position regulator output Range: 0-65635 Count value of resolver Range: 0-65635 Count value of resolver Range: 0-65635 P18.20 Count value of resolver. Range: 0-65635 P18.21 Resolver angle of closed-loop synchronous Range: 0.00–359.99 Pole angle of closed-loop synchronous Range: 0.00–359.99 O.000 • O.000	code	Name	betailed parameter description	value	fy
pulse direction of P20.02 or exchanging phase AB of encoder. 0: Forward 1: Reverse Reserved. angle Range: 0.00–359.99 P18.13 Encoder Z pulse arror times Range: 0.065535 High bit of encoder pulse count value Low bit of encoder pulse ecount value P18.15 Reserved variables Pulse command frequency Pulse command frequency Pulse command feedforward P18.17 Pulse command feedforward P18.18 Pulse command feedforward P18.19 Position regulator output P18.19 Position regulator output P18.20 Count value of resolver Resolver angle P18.21 Resolver angle Pole angle of closed-loop synchronous Range: 0.00–359.99 D.000			between the position of forward and reverse		
encoder. 0: Forward 1: Reverse			orientation, which can be eliminated by adjusting Z		
D: Forward 1: Reverse			pulse direction of P20.02 or exchanging phase AB of		
1: Reverse			encoder.		
P18.12 Encoder Z pulse angle Range: 0.00–359.99 P18.13 Encoder Z pulse error times Range: 0.00–359.99 P18.14 Encoder Z pulse error times Range: 0-65535 P18.15 Encoder Z pulse error times Range: 0-65535 P18.16 P18.15 encoder pulse count value P18.16 Reserved variables P18.17 Pulse command frequency and it is valid under pulse position mode and pulse speed mode. Range: 0-655.35Hz P18.18 Pulse command feedforward Pulse command (A2, B2 terminal) is converted to the set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0-655.35Hz P18.19 Position regulator output Position regulator output The output frequency of the position regulator output Range: 0-655.35 P18.20 Count value of resolver. Range: 0-655.35 P18.21 Resolver angle Count value of closed-loop synchronous Range: 0.00–359.99 Pole angle of closed-loop synchronous Range: 0.00–359.99 O			0: Forward		
P18.12 angle Range: 0.00–359.99 P18.13 Encoder Z pulse error times Range: 0-65535 High bit of encoder pulse count value Low bit of encoder pulse count value P18.15 Reserved variables Pulse command frequency Pulse command frequency Pulse command frequency Pulse command (A2, B2 terminal) is converted to the set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0-655.35Hz Pulse command feedforward set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0-655.35Hz P18.18 Position regulator output Position regulator output frequency of the position regulator during position control. Range: 0-65535 P18.20 Count value of resolver Range: 0-65535 The output frequency of the position regulator during position control. Range: 0-65535 The pole position angle read according to the resolver-type encoder. Range: 0-00-359.99 Pole angle of closed-loop synchronous Range: 0.00-359.99			1: Reverse		
Angle Range: 0.00–359.99 P18.13 Encoder Z pulse error times Range: 0-65535 P18.14 Encoder pulse crount value Low bit of encoder pulse count value P18.15 Pulse command frequency Range: 0-65535 Pulse command (A2, B2 terminal) is converted to the set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0-655.35Hz P18.18 Pulse command feedforward Range: 0-655.35Hz P18.19 Position regulator output Range: 0-655.35 P18.20 Count value of resolver Range: 0-655.35 P18.21 Resolver angle P18.22 Pole angle of closed-loop synchronous Range: 0.00–359.99 Reserved. 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	D40.40	Encoder Z pulse	Reserved.	0.00	
P18.13 error times Range: 0-65535 0 0	P18.12	angle	Range: 0.00-359.99	0.00	
High bit of encoder pulse count value Low bit of encoder pulse count value P18.15 encoder pulse count value P18.16 Reserved variables Pulse command frequency Pulse command (A2, B2 terminal) is converted to the set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0-655.35Hz Pulse command (A2, B2 terminal) is converted to the set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0-655.35Hz P18.19 Position regulator output P18.19 Count value of resolver Range: 0-65535 P18.20 Count value of resolver Range: 0-65535 P18.21 Resolver angle Pole angle of closed-loop synchronous Pole angle of closed-loop synchronous P18.22 Current pole position. Range: 0.00-359.99 O 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	D40.40	Encoder Z pulse	Reserved.	0	
P18.14 encoder pulse count value Low bit of encoder pulse count value P18.15 encoder pulse count value P18.16 Reserved variables Pulse command frequency Pulse command frequency Pulse command frequency Pulse command frequency Pulse command (A2, B2 terminal) is converted to the set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0-655.35Hz Pulse command feedforward set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0-655.35Hz Pulse command (A2, B2 terminal) is converted to the set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0-655.35Hz The output frequency of the position regulator during position control. Range: 0-655.35 P18.20 Count value of resolver. Range: 0-65535 The pole position angle read according to the resolver-type encoder. Range: 0.00-359.99 Pole angle of closed-loop synchronous P18.22 Current pole position. Range: 0.00-359.99	P18.13	error times	Range: 0-65535	0	•
Count value Low bit of encoder pulse count value P18.15 Reserved variables Pulse command frequency Pulse command frequency Pulse command (A2, B2 terminal) is converted to the set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0-655.35Hz Pulse command feedforward ende and pulse speed mode. Range: 0-655.35Hz Pulse command (A2, B2 terminal) is converted to the set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0-655.35Hz The output frequency of the position regulator during position control. Range: 0-655.35 P18.20 Count value of resolver. Range: 0-655.35 The pole position angle read according to the resolver-type encoder. Range: 0.00-359.99 Pole angle of closed-loop synchronous P18.22 Current pole position. Range: 0.00-359.99		High bit of			
P18.15 Low bit of encoder pulse count value P18.16 Reserved variables P18.17 Pulse command frequency P18.18 Pulse command frequency P18.18 Pulse command feedforward P18.19 Position regulator output P18.20 Count value of resolver Range: 0–655.35 P18.21 Resolver angle P18.22 Pole angle of closed-loop synchronous P18.20 Current pole position. P18.21 Position feed and pulse position on the position angle read according to the resolver Range: 0.00–359.99 P18.22 Current pole position. P18.23 Position feed and pulse position angle read according to the resolver Range: 0.00–359.99 P18.24 Pole angle of closed-loop synchronous Range: 0.00–359.99	P18.14	encoder pulse	0–65535	0	•
P18.15 encoder pulse count value P18.16 Reserved variables Pulse command (A2, B2 terminal) is converted to the set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0-655.35Hz Pulse command feedforward Pulse command (A2, B2 terminal) is converted to the set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0-655.35Hz Pulse command (A2, B2 terminal) is converted to the set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0-655.35Hz The output frequency of the position regulator during position control. Range: 0-65535 P18.20 Count value of resolver Range: 0-65535 The pole position angle read according to the resolver-type encoder. Range: 0.00-359.99 Pole angle of closed-loop synchronous Range: 0.00-359.99		count value			
Count value P18.16 Reserved variables Pulse command (A2, B2 terminal) is converted to the set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0-655.35Hz Pulse command feedforward Pulse command (A2, B2 terminal) is converted to the set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0-655.35Hz Pulse command (A2, B2 terminal) is converted to the set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0-655.35Hz The output frequency of the position regulator during position control. Range: 0-65535 P18.20 Count value of resolver. Range: 0-65535 The pole position angle read according to the resolver-type encoder. Range: 0.00-359.99 Pole angle of closed-loop synchronous Range: 0.00-359.99		Low bit of			
P18.16 Reserved variables 0–65535 0 0 • Pulse command (A2, B2 terminal) is converted to the set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0–655.35Hz Pulse command feedforward Pulse command (A2, B2 terminal) is converted to the set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0–655.35Hz Position regulator output P18.19 Position regulator output Range: 0–65535 P18.20 Count value of resolver Range: 0–65535 P18.21 Resolver angle Fesolver Range: 0–65535 The pole position angle read according to the resolver-type encoder. Range: 0.00–359.99 Pole angle of closed-loop synchronous Range: 0.00–359.99	P18.15	encoder pulse	0–65535	0	•
P18.16 variables Pulse command (A2, B2 terminal) is converted to the set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0–655.35Hz Pulse command feedforward Pulse command (A2, B2 terminal) is converted to the set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0–655.35Hz Pulse command (A2, B2 terminal) is converted to the set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0–655.35Hz The output frequency of the position regulator during position control. Range: 0–655.35 P18.20 Count value of resolver. Range: 0–655.35 The pole position angle read according to the resolver-type encoder. Range: 0.00–359.99 Pole angle of closed-loop synchronous Range: 0.00–359.99		count value			
P18.17 Pulse command frequency Pulse command (A2, B2 terminal) is converted to the set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0–655.35Hz Pulse command feedforward Pulse command (A2, B2 terminal) is converted to the set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0–655.35Hz P18.19 Position regulator output The output frequency of the position regulator during position control. Range: 0–655.35 P18.20 Count value of resolver. Range: 0–655.35 P18.21 Resolver angle The pole position angle read according to the resolver-type encoder. Range: 0.00–359.99 Pole angle of closed-loop synchronous Range: 0.00–359.99 O.000 •		Reserved			
P18.17 Pulse command frequency set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0–655.35Hz Pulse command feedforward Pulse command feedforward Position regulator output Position regulator output Position control. Range: 0–655.35Hz Position regulator output Position control. Range: 0–65535 Count value of resolver Range: 0–65535 The pole position angle read according to the resolver-type encoder. Range: 0.00–359.99 Pole angle of closed-loop synchronous Current pole position. Range: 0.00–359.99	P18.16	variables	0–65535	0	•
P18.17 frequency mode and pulse speed mode. Range: 0–655.35Hz Pulse command feedforward mode and pulse speed mode. Range: 0–655.35Hz Pulse command feedforward mode and pulse speed mode. Range: 0–655.35Hz Position regulator output mode and pulse speed mode. Range: 0–655.35Hz The output frequency of the position regulator during position control. Range: 0–65535 Count value of resolver Range: 0–65535 The pole position angle read according to the resolver-type encoder. Range: 0.00–359.99 Pole angle of closed-loop synchronous Range: 0.00–359.99			Pulse command (A2, B2 terminal) is converted to the		
frequency mode and pulse speed mode. Range: 0–655.35Hz Pulse command (A2, B2 terminal) is converted to the set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0–655.35Hz Position regulator output Position regulator position control. Range: 0–65535 Count value of resolver Range: 0–65535 The pole position angle read according to the resolver-type encoder. Range: 0.00–359.99 Pole angle of closed-loop synchronous Range: 0.00–359.99 Pulse command (A2, B2 terminal) is converted to the set frequency, and it is valid under pulse position on the requency of the position regulator during position control. Range: 0–655.35 Output frequency of the position regulator during position control. Range: 0–65535 Output value of resolver. Range: 0.00–359.99 Current pole position. Range: 0.00–359.99		Pulse command	set frequency, and it is valid under pulse position		_
Pulse command (A2, B2 terminal) is converted to the set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0–655.35Hz The output frequency of the position regulator position control. Range: 0–65535 Count value of resolver Range: 0–65535 The pole position angle read according to the resolver-type encoder. Range: 0.00–359.99 Pole angle of closed-loop synchronous Pulse command (A2, B2 terminal) is converted to the set frequency, and it is valid under pulse position O.00Hz O.00H	P18.17	frequency	mode and pulse speed mode.	0.00Hz	•
P18.18 Pulse command feedforward set frequency, and it is valid under pulse position mode and pulse speed mode. Range: 0–655.35Hz Position regulator output The output frequency of the position regulator during position control. Range: 0–65535 Count value of resolver Range: 0–65535 The pole position angle read according to the resolver-type encoder. Range: 0.00–359.99 Pole angle of closed-loop synchronous Current pole position. Range: 0.00–359.99			Range: 0-655.35Hz		
P18.18 feedforward mode and pulse speed mode. Range: 0–655.35Hz Position regulator output The output frequency of the position regulator during position control. Range: 0–65535 Count value of resolver Range: 0–65535 The pole position angle read according to the resolver-type encoder. Range: 0.00–359.99 Pole angle of closed-loop synchronous Range: 0.00–359.99			Pulse command (A2, B2 terminal) is converted to the		
feedforward mode and pulse speed mode. Range: 0–655.35Hz Position regulator output The output frequency of the position regulator during position control. Range: 0–65535 Count value of resolver. Range: 0–65535 The pole position angle read according to the resolver-type encoder. Range: 0.00–359.99 Pole angle of closed-loop synchronous Range: 0.00–359.99 mode and pulse speed mode. Range: 0–655.35Hz The output frequency of the position regulator during position control. 0 • 0 • 0 • 0 • 0 0 • 0 0		Pulse command	set frequency, and it is valid under pulse position		_
P18.19 Position regulator output The output frequency of the position regulator during position control. Range: 0–65535 Count value of resolver. Range: 0–65535 The pole position angle read according to the resolver-type encoder. Range: 0.00–359.99 Pole angle of closed-loop synchronous Current pole position. Range: 0.00–359.99	P18.18		mode and pulse speed mode.	0.00Hz	•
P18.19 Position regulator output position control. Range: 0–65535 Count value of resolver. Range: 0–65535 The pole position angle read according to the resolver-type encoder. Range: 0.00–359.99 Pole angle of closed-loop synchronous Range: 0.00–359.99			Range: 0-655.35Hz		
P18.19 Position regulator output position control. Range: 0–65535 Count value of resolver. Range: 0–65535 The pole position angle read according to the resolver-type encoder. Range: 0.00–359.99 Pole angle of closed-loop synchronous Range: 0.00–359.99			- V		
Range: 0–65535 Count value of resolver. Range: 0–65535 The pole position angle read according to the resolver-type encoder. Range: 0.00–359.99 Pole angle of closed-loop synchronous Range: 0.00–359.99 Range: 0.00–359.99	P18.19	· ·	position control.	0	•
P18.20 resolver Range: 0–65535 The pole position angle read according to the resolver-type encoder. Range: 0.00–359.99 Pole angle of closed-loop synchronous Range: 0.00–359.99 Range: 0.00–359.99 0.00		output	Range: 0-65535		
resolver Range: 0–65535 The pole position angle read according to the resolver-type encoder. Range: 0.00–359.99 Pole angle of closed-loop synchronous Range: 0.00–359.99 Range: 0.00–359.99 0.00		Count value of	Count value of resolver.		
P18.21 Resolver angle resolver-type encoder. Range: 0.00–359.99 Pole angle of closed-loop synchronous Range: 0.00–359.99 Current pole position. Range: 0.00–359.99	P18.20	resolver	Range: 0–65535	0	•
P18.21 Resolver angle resolver-type encoder. Range: 0.00–359.99 Pole angle of closed-loop synchronous Range: 0.00–359.99 Current pole position. Range: 0.00–359.99			- V		
P18.22 Range: 0.00–359.99 Pole angle of closed-loop current pole position. Range: 0.00–359.99 O.00	P18.21	Resolver angle	resolver-type encoder.	0.00	•
P18.22 closed-loop synchronous Current pole position. Range: 0.00–359.99			I		
P18.22 closed-loop synchronous Current pole position. Range: 0.00–359.99		Pole angle of	-		
P18.22 synchronous Range: 0.00–359.99			Current pole position.		
	P18.22	•	l · · · ·	0.00	•
		motor			

Function code	Name	Detailed parameter description	Default value	Modi fy
P18.23	State control word 3	0–65535	0	•
P18.24	High bit of count value of pulse reference	0–65535	0	•
P18.25	Low bit of count value of pulse reference	0–65535	0	•
P18.26	Spindle reduction ratio	It is the drive ratio (speed ratio) between the mounting shaft and the spindle of the encoder when spindle stops accurately. Range: 0.000–65.535	0.000	•
P18.27	Encoder UVW sector	0–7	0	•
P18.28	Encoder PPR (pulse-per- revolution) display	0–65535	0	•
P18.29	Angle compensation value of synchronous motor	-180.0–180.0	0.00	•
P18.30	Reserved variables	0–65535	0	•
P18.31	Pulse reference Z pulse value	0–65535	0	•
P18.32– P18.35	Reserved variables	0–65535	0	•
P19 grou	p Extension car	d state check		
P19.00	State of card slot 1	0-65535 0: No card 1: PLC programmable card 2: I/O card 3: Incremental PG card 4: Incremental PG card with UVW 5: Ethernet communication card 6: DP communication card	0	•

Function			Default	Modi
code	Name	Detailed parameter description	value	fy
		7: Bluetooth card		
		8: Resolver PG card		
		9: CANopen communication card		
		10: WIFI card		
		11: Profinet communication card		
		12: Sine/Cosine PG card without CD signal		
		13: Sine/Cosine PG card with CD signal		
		14: Absolute encoder PG card		
		15: CAN master/slave communication card		
		16: MODBUS communication card		
		17: EtherCat communication card		
		18: BacNet communication card		
		19: DeviceNet communication card		
		0–65535		
		0: No card		
		1: PLC programmable card		
		2: I/O card		
		3: Incremental PG card		
		4: Incremental PG card with UVW		
		5: Ethernet communication card		
		6: DP communication card		
		7: Bluetooth card		
	State of card slot	8: Resolver PG card		
P19.01	2	9: CANopen communication card	0	•
	2	10: WIFI card		
		11: Profinet communication card		
		12: Sine/Cosine PG card without CD signal		
		13: Sine/Cosine PG card with CD signal		
		14: Absolute encoder PG card		
		15: CAN master/slave communication card		
		16: MODBUS communication card		
		17: EtherCat communication card		
		18: BacNet communication card		
		19: DeviceNet communication card		
		0–65535		
	State of card slot	0: No card		
P19.02	3	1: PLC programmable card	0	•
		2: I/O card		
		3: Incremental PG card		

Function			Default	Modi
code	Name	Detailed parameter description	value	fy
		4: Incremental PG card with UVW		
		5: Ethernet communication card		
		6: DP communication card		
		7: Bluetooth card		
		8: Resolver PG card		
		9: CANopen communication card		
		10: WIFI card		
		11: Profinet communication card		
		12: Sine/Cosine PG card without CD signal		
		13: Sine/Cosine PG card with CD signal		
		14: Absolute encoder PG card		
		15: CAN master/slave communication card		
		16: MODBUS communication card		
		17: EtherCat communication card		
		18: BacNet communication card		
		19: DeviceNet communication card		
	Software version			
P19.03	of the extension	0.00–655.35	0.00	•
	card in card slot 1			
	Software version			
P19.04	of the extension	0.00–655.35	0.00	•
	card in card slot 2			
	Software version			
P19.05	of the extension	0.00–655.35	0.00	•
	card in card slot 3			
	Input state of			
P19.06	extension I/O	0-0xFFFF	0	•
	card terminals			
	Output state of			
P19.07	extension I/O	0-0xFFFF	0	•
	card terminals			
	HDI3 input			
D40.00	frequency of	0.000 50.000111-	0.000	
P19.08	extension I/O	0.000–50.000kHz	kHz	•
	card			
	Al3 input voltage			
P19.09	of extension I/O	0.00–10.00V	0.00V	•
	card			

Function code	Name	Detailed parameter description	Default value	Modi fy
P19.10-	Reserved	0–65535	0	
P19.39	variables	0-05555	0	
P20 grou	p Encoder of m	otor 1		
		0: Incremental encoder		
P20.00	Encoder type	1: Resolver-type encoder	0	
7 20.00	display	2: Sin/Cos encoder	U	
		3: Endat absolute encoder		
	Encoder pulse	Number of pulses generated when the encoder		
P20.01	number	revolves for one circle.	1024	0
		Setting range: 0–60000		
		Ones: AB direction		
		0: Forward		
		1: Reverse		
		Tens: Z pulse direction (reserved)		
P20.02	Encoder direction		0x000	0
		1: Reverse		
		Hundreds: CD/UVW pole signal direction		
		0: Forward 1: Reverse		
	Detection time of	1. Nevelse		
P20.03	encoder offline	The detection time of encoder offline fault.	1.0s	0
1 20.03	fault	Setting range: 0.0–10.0s	1.03	0
P20.04	Detection time of encoder reversal fault	Detection time of encoder reversal fault. Setting range: 0.0–100.0s	0.8s	0
		Setting range: 0x00-0x99		
	Filter times of	Ones: Low-speed filter time, corresponds to 2^(0-		
P20.05	encoder	9)×125us.	0x33	0
	detection	Tens: High-speed filter times, corresponds to 2^(0-		
		9)×125us.		
	Speed ratio	Users need to set this parameter when the encoder		
P20.06	between encoder	is not installed on the motor shaft and the drive ratio	1.000	0
	mounting shaft	is not 1.		
	and motor	Setting range: 0.001–65.535		
	Control	Bit0: Enable Z pulse calibration		
P20.07	parameters of	Bit1: Enable encoder angle calibration	0x3	0
	synchronous	Bit2: Enable SVC speed measurement		
	motor	Bit3: Select resolver speed measurement mode		

Bit4: Z pulse capture mode Bit5: Do not detect encoder initial angle in v/f control Bit6: Enable CD signal calibration Bit7: Disable sin/cos sub-division speed measurement Bit8: Do not detect encoder fault during autotuning Bit9: Enable Z pulse detection optimization Bit10: Enable initial Z pulse calibration optimization Bit12: Clear Z pulse arrival signal after stop 0x00-0x11 Ones: Z pulse 0: Do not detect 1: Enable Tens: UVW pulse (for synchronous motor) 0: Do not detect 1: Enable Relative electric angle of encoder Z pulse and motor	Function			Default	Modi
Bit5: Do not detect encoder initial angle in v/f control Bit6: Enable CD signal calibration Bit7: Disable sin/cos sub-division speed measurement Bit8: Do not detect encoder fault during autotuning Bit9: Enable Z pulse detection optimization Bit10: Enable initial Z pulse calibration optimization Bit12: Clear Z pulse arrival signal after stop 0x00-0x11 Ones: Z pulse 0: Do not detect 1: Enable Tens: UVW pulse (for synchronous motor) 0: Do not detect 1: Enable Relative electric angle of encoder Z pulse and motor	code	Name	Detailed parameter description	value	fy
Bit6: Enable CD signal calibration Bit7: Disable sin/cos sub-division speed measurement Bit8: Do not detect encoder fault during autotuning Bit9: Enable Z pulse detection optimization Bit10: Enable initial Z pulse calibration optimization Bit12: Clear Z pulse arrival signal after stop 0x00-0x11 Ones: Z pulse 0: Do not detect 1: Enable Tens: UVW pulse (for synchronous motor) 0: Do not detect 1: Enable Relative electric angle of encoder Z pulse and motor			Bit4: Z pulse capture mode		
Bit7: Disable sin/cos sub-division speed measurement Bit8: Do not detect encoder fault during autotuning Bit9: Enable Z pulse detection optimization Bit10: Enable initial Z pulse calibration optimization Bit12: Clear Z pulse arrival signal after stop 0x00–0x11 Ones: Z pulse 0: Do not detect 1: Enable Tens: UVW pulse (for synchronous motor) 0: Do not detect 1: Enable Relative electric angle of encoder Z pulse and motor			Bit5: Do not detect encoder initial angle in v/f control		
P20.08 Measurement			Bit6: Enable CD signal calibration		
Bit8: Do not detect encoder fault during autotuning Bit9: Enable Z pulse detection optimization Bit10: Enable initial Z pulse calibration optimization Bit12: Clear Z pulse arrival signal after stop 0x00–0x11 Ones: Z pulse 0: Do not detect 1: Enable Tens: UVW pulse (for synchronous motor) 0: Do not detect 1: Enable Relative electric angle of encoder Z pulse and motor			Bit7: Disable sin/cos sub-division speed		
Bit9: Enable Z pulse detection optimization Bit10: Enable initial Z pulse calibration optimization Bit12: Clear Z pulse arrival signal after stop 0x00–0x11 Ones: Z pulse 0: Do not detect 1: Enable Tens: UVW pulse (for synchronous motor) 0: Do not detect 1: Enable Relative electric angle of encoder Z pulse and motor			measurement		
P20.08 Bit10: Enable initial Z pulse calibration optimization Bit12: Clear Z pulse arrival signal after stop 0x00–0x11 Ones: Z pulse 0: Do not detect 1: Enable Tens: UVW pulse (for synchronous motor) 0: Do not detect 1: Enable Relative electric angle of encoder Z pulse and motor			Bit8: Do not detect encoder fault during autotuning		
P20.08 Bit12: Clear Z pulse arrival signal after stop			Bit9: Enable Z pulse detection optimization		
P20.08 Enable Z pulse offline detection Enable Z pulse of I: Enable Tens: UVW pulse (for synchronous motor) O: Do not detect 1: Enable Tens: UVW pulse (for synchronous motor) O: Do not detect 1: Enable Relative electric angle of encoder Z pulse and motor			Bit10: Enable initial Z pulse calibration optimization		
P20.08 Enable Z pulse Offline detection Cones: Z pulse O: Do not detect 1: Enable Tens: UVW pulse (for synchronous motor) O: Do not detect 1: Enable Relative electric angle of encoder Z pulse and motor			Bit12: Clear Z pulse arrival signal after stop		
P20.08 Enable Z pulse offline detection 0: Do not detect 1: Enable Tens: UVW pulse (for synchronous motor) 0: Do not detect 1: Enable Initial angle of Z			0x00–0x11		
P20.08 Enable Z pulse offline detection 1: Enable Tens: UVW pulse (for synchronous motor) 0: Do not detect 1: Enable Initial angle of Z			Ones: Z pulse		
offline detection of the control			0: Do not detect		
Tens: UVW pulse (for synchronous motor) 0: Do not detect 1: Enable Relative electric angle of encoder Z pulse and motor	P20.08		1: Enable	0x10	0
1: Enable Initial angle of Z Relative electric angle of encoder Z pulse and motor		offline detection	Tens: UVW pulse (for synchronous motor)		
Initial angle of Z			0: Do not detect		
I Initial angle of Z I			1: Enable		
I Initial angle of / I			Relative electric angle of encoder Z pulse and motor		
P20.09	P20.09	Initial angle of Z	pole position.	0.00	0
pulse Setting range: 0.00–359.99		pulse	Setting range: 0.00–359.99		
Relative electric angle of encoder position and motor			Relative electric angle of encoder position and motor		
P20.10 pole position. 0.00 O	P20.10	Initial angle of the pole	pole position.	0.00	0
Setting range: 0.00–359.99			Setting range: 0.00–359.99		
0–3			0–3		
Autotuning of 1: Rotary autotuning (DC brake)		Autotuning of	1: Rotary autotuning (DC brake)		
P20.11 initial angle of 2: Static autotuning (suitable for resolver-type 0	P20.11	initial angle of	2: Static autotuning (suitable for resolver-type	0	0
pole encoder, sin/cos with CD signal feedback)			encoder, sin/cos with CD signal feedback)		
3: Rotary autotuning (initial angle identification)			3: Rotary autotuning (initial angle identification)		
Speed		Speed			
0: No optimization measurement	D00.40	measurement	•	4	
P20.12 optimization 1: Optimization mode 1 1 ©	P20.12	optimization	·	1	0
2: Optimization mode 2		selection	2: Optimization mode 2		
CD signal zero	B06 15	CD signal zero	0.05505	-	
P20.13 0-65535 0 0	P20.13	offset gain	0–65535	0	O
Ones: Incremental encoder		-	Ones: Incremental encoder		
0: without UVW			0: without UVW		
Encoder type 1: with UVW	D00.4.4	Encoder type	1: with UVW	000	
P20.14 selection Tens: Sin/Cos encoder 0x00 ©	P20.14	selection	Tens: Sin/Cos encoder	UXUU	0
0: without CD signal			0: without CD signal		
1: with CD signal			1: with CD signal		

Function	Nome	Datailed waremater description	Default	Modi
code	Name	Detailed parameter description	value	fy
	Speed	0: PG card		
P20.15	measurement	1: local; realized by HDIA and HDIB; supports	0	0
	mode	incremental 24V encoder only		
	Frequency-divisi	0–255		
P20.16	on coefficient	When this parameter is set to 0 or 1, frequency	0	0
	on coemcient	division of 1:1 is implemented.		
		0x0000–0xffff		
		Bit0: Enable/disable encoder input filter		
		0: No filter		
		1: Filter		
		Bit1: Encoder signal filter mode (set Bit0 or Bit2 to 1)		
		0: Self-adaptive filter		
		1: Use P20.18 filter parameters		
		Bit2: Enable/disable encoder frequency-division		
		output filter		
		0: No filter		
	Pulse filer processing	1: Filter		
P20.17		Bit3: Reserved	0x0011	0
		Bit4: Enable/disable pulse reference filter		
		0: No filter		
		1: Filter		
		Bit5: Pulse reference filter mode (valid when Bit4 is		
		set to 1)		
		0: Self-adaptive filter		
		1: Use P20.19 filter parameters		
		Bit6: Frequency-divided output source setting		
		0: Encoder signals		
		1: Pulse reference signals		
		Bits7–15: Reserved		
		0–63		
P20.18	Encoder pulse	The filtering time is P20.18×0.25 µs. The value 0 or	10	0
F20.16	filter width	1 indicates 0.25 µs.	10	
		0–63		-
P20.19	Pulse reference		10	0
FZU.19	filter width	The filtering time is P20.18×0.25 µs. The value 0 or 1 lindicates 0.25 µs.	10	
	Pulse number of	indicates 0.25 μs.		
P20.20		0–65535	1024	0
	pulse reference			
P20.21	Enable angle	0–1	0	0
	compensation of			1

Function	Name	Detailed parameter description	Default	
code			value	fy
	synchronous motor			
P20.22	Switch-over frequency threshold of speed measurement mode	0–630.00Hz Note: This parameter is valid only when P20.12 is set to 0.	1.00Hz	0
P20.23-	Reserved	0–65535	0	0
P20.24	variables	0 00000		
P21 grou	p Position contr	rol		
P21.00	Positioning mode	Ones: Control mode selection 0: Speed control 1: Position control Tens: Position command source 0: Pulse string 1: Digital position 2: Positioning of photoelectric switch during stop Hundreds: Position feedback source (reserved, fixed to channel P) 0: PG1 1: PG2 Thousands: servo mode Bit0: Position deviation mode 0: No deviation 1: With deviation Bit1: Enable/disable servo 0: Disable (The servo can be enabled by terminals.) 1: Enable Bit2: (reserved) Note: In the pulse string or spindle positioning mode, the inverter enters the servo operation mode when there is a valid servo enabling signal. If there is no servo enabling signal, the inverter enter the servo operation mode only after it receives a forward running or reverse running command.	0x0000	0
P21.01	Pulse command mode	Ones: Pulse mode 0: A/B quadrature pulse; A precedes B 1: A: PULSE; B: SIGN	0x0000	0

Function			Default	Modi
code	Name	Detailed parameter description	value	fy
		If channel B is of low electric level, the edge counts		
		up; if channel B is of high electric level, the edge		
		counts down.		
		2: A: Positive pulse		
		Channel A is positive pulse; channel B needs no		
		wiring		
		3: A\B dual-channel pulse; channel A pulse edge		
		counts up, channel B pulse edge counts down		
		Tens: Pulse direction		
		Bit0: Set pulse direction		
		0: Forward		
		1: Reverse		
		Bit1: Set pulse direction by running direction		
		0: Disable, and BIT0 is valid;		
		1: Enable		
		Hundreds: Pulse/direction frequency-doubling		
		selection (reserved)		
		0: No frequency-doubling		
		1: Frequency-doubling		
		Thousands: Pulse control selection		
		Bit0: Pulse filter selection		
		0: Inertia filter		
		1: Average moving filter		
		Bit1: Overspeed control		
		0: No control		
		1: Control		
P21.02	APR gain 1	The two automatic position regulator (APR) gains	20.0	0
		are switched based on the switching mode set in		
		P21.04. When the spindle orientation function is		
		used, the gains are switched automatically,		
P21.03	APR gain 2	regardless of the setting of P21.04. P21.03 is used	30.0	0
		for dynamic running, and P21.02 is used for		
		maintaining the locked state.		
		Setting range: 0.0–400.0		
		This parameter is used to set the APR gain switching		
	Switching mode	mode. To use torque command-based switching, you		
P21.04	of position loop	need to set P21.05; and to use speed	0	0
	gain	command-based switching, you need to set P21.06.		
		0: No switching		

Function code	Name	Detailed parameter description	Default value	Modi fy
		2: Torque command		
		3: Speed command		
		3–5: Reserved		
P21.05	Torque command level during position gain switch-over	0.0–100.0% (rated motor torque)	10.0%	0
P21.06	Speed command level during position gain switch-over	0.0-100.0% (rated motor speed)	10.0%	0
P21.07	Smooth filter coefficient during gain switch-over	The smooth filter coefficient during position gain switch-over. Setting range: 0–15	5	0
P21.08	Output limit of position controller	The output limit of position regulator, if the limit value is 0, position regulator will be invalid, and no position control can be performed, however, speed control is available. Setting range: 0.0–100.0% (Max. output frequency P00.03)	20.0%	0
P21.09	Completion range of positioning	When the position deviation is less than P21.09, and the duration is larger than P21.10, positioning completion signal will be outputted. Setting range: 0–1000	10	0
P21.10	Detection time for positioning completion	0.0–1000.0ms	10.0ms	0
P21.11	Numerator of position command ratio	Electronic gear ratio, used to adjust the corresponding relation between position command and actual running displacement. Setting range: 1–65535	1000	0
P21.12	Denominator of position command ratio	Setting range: 1–65535	1000	0
P21.13	Position feedforward gain	0.00–120.00% For pulse string reference only (position control)	100.00	0
P21.14	Position feedforward filter	0.0–3200.0ms For pulse string reference only (position control)	3.0ms	0

Function			Default	Modi
code	Name	Detailed parameter description	value	fy
		Bit10-11: Reserved		
		Bit12: Positioning curve selection (reserved)		
		0: Straight line		
		1: S curve		
		Set digital positioning position;		
P21.17	Position digital	Actual position=P21.17×P21.11/P21.12	0	0
	reference	0–65535		
		0: Set by P21.19		
		1: Set by Al1		
	Positioning	2: Set by Al2		
P21.18	speed setup	3: Set by Al3	0	0
	selection	4: Set by high speed pulse HDIA		
		5: Set by high speed pulse HDIB		
	Positioning			
P21.19	speed digits	0–100.0% max. frequency	20.0%	0
	Acceleration time	Set the acceleration/deceleration time of positioning		
P21.20	of positioning	process.	3.00s	0
		Acceleration time of positioning means the time		
	Deceleration time of positioning	needed for the inverter to accelerate from 0Hz to		
		Max. output frequency (P00.03).		
		Deceleration time of positioning means the time		
P21.21		needed for the inverter to decelerate from Max.	3.00s	0
		output frequency (P00.03) to 0hz.		
		Setting range of P21.20: 0.01–300.00s		
		Setting range of P21.21: 0.01–300.00s		
		Set the hold time of waiting when target positioning		
P21.22	Hold time of	position is reached.	0.100s	0
	positioning arrival	Setting range: 0.000–60.000s		
	Home search			
P21.23	speed	0.00–50.00Hz	2.00Hz	0
	Home position			
P21.24	offset	0–65535	0	0
		The hold time of positioning completion signal, this		
1	Hold time of	parameter is also valid for positioning completion		_
P21.25	positioning	signal of spindle orientation.	0.200s	0
	completion signal	Setting range: 0.000–60.000s		
	Pulse			
P21.26	superposition	0–65535	0	0
	value			

Function code	Name	Detailed parameter description	Default value	Modi fy
	Pulse			
P21.27	superposition	0–6553.5	8.0	0
	speed			
	Acceleration/dec			
D04.00	eleration time	000 0 2000 0-	F 00	
P21.28	after disabling	000.0–3000.0s	5.0s	0
	pulse			
	Speed	It is the filter time constant detected by nulse string		
	feedforward filter	It is the filter time constant detected by pulse string		
P21.29	time constant	when the speed reference source is set to pulse	10.0ms	0
	(pulse string	string (P0.06=12 or P0.07=12).		
	speed mode)	Setting range: 0–3200.0ms		
	Numerator of the			
P21.30	2 nd command	1–65535	1000	0
	ratio			
P21.31-	Reserved	0–65535	0	0
P21.33	variables	0-05555	U	
P22 grou	p Spindle positi	oning		
		Bit0: Enable spindle positioning		
		0: Disable		
		1: Enable		
		Bit1: Select spindle positioning reference point		
		0: Z pulse input		
		1: S2/S3/S4 terminal input		
		Bit2: Search for reference point		
		0: Search the reference point only once		
	Spindle	1: Search the reference point every time		
P22.00	positioning mode	Bit3: Enable reference point calibration	0	0
F22.00	selection	0: Disable	U	
	Selection	1: Enable		
		Bit4: Positioning mode selection 1		
		0: Set direction positioning		
		1: Near-by direction positioning		
		Bit5: Positioning mode selection 2	1	
		0: Forward positioning		
		1: Reverse positioning		
		Bit6: Zeroing command selection		
		0: Electric level mode		

Function			Default	Modi
code	Name	Detailed parameter description	value	fy
		1: Pulse mode		
		Bit7: Reference point calibration mode		
		0: Calibrate at the first time		
		1: Calibrate in real time		
		Bit8: Action selection after zeroing signal		
		cancellation (electric level type)		
		0: Switch to speed mode		
		1: Position lock mode		
		Bit9: Positioning completion signal selection		
		0: Electric level signal		
		1: Pulse signal		
		Bit10: Z pulse signal source		
		0: Motor		
		1: Spindle		
		Bit11–15: Reserved		
		During spindle orientation, the speed of the position		
D00.04	Speed of spindle	point of orientation will be searched, and then it will	40.0011	
P22.01	orientation	switch over to position control orientation.	10.00Hz	0
		Setting range: 0.00–100.00Hz		
		Deceleration time of spindle orientation.		
	Deceleration time	Spindle orientation deceleration time means the time		
P22.02	of spindle	needed for the inverter to decelerate from Max.	3.0s	0
	orientation	output frequency (P00.03) to 0Hz.		
		Setting range: 0.0–100.0s		
	0 : " .	Users can select the zeroing positions of four		
P22.03	Spindle zeroing	spindles by terminals (function code 46, 47).	0	0
	position 0	Setting range: 0-39999		
P22.04	Spindle zeroing	Sotting range: 0, 20000	0	0
P22.04	position 1	Setting range: 0–39999	0	0
D00.05	Spindle zeroing	0.44	0	
P22.05	position 2	Setting range: 0–39999	0	0
500.00	Spindle zeroing	0.000		
P22.06	position 3	Setting range: 0–39999	0	0
	Spindle	Users can select seven spindle scale-division values		
P22.07	scale-division	by terminals (function code 48, 49 and 50).	15.00	0
	angle 1	Setting range: 0.00–359.99		
	Spindle			
P22.08	scale-division	Setting range: 0.00–359.99	30.00	0
	angle 2			
		ı		

Function code	Name	Detailed parameter description	Default value	Modi fy
P22.09	Spindle scale-division angle 3	Setting range: 0.00–359.99	45.00	0
P22.10	Spindle scale-division angle 4	Setting range: 0.00–359.99	60.00	0
P22.11	Spindle scale-division angle 5	Setting range: 0.00–359.99	90.00	0
P22.12	Spindle scale-division angle 6	Setting range: 0.00–359.99	120.00	0
P22.13	Spindle scale-division angle 7	Setting range: 0.00–359.99	180.00	0
P22.14	Spindle drive ratio	This function code sets the reduction ratio of the spindle and the mounting shaft of the encoder. Setting range: 0.000–30.000	1.000	0
P22.15	Zero-point communication setup of spindle	P22.15 sets spindle zero-point offset, if the selected spindle zero point is P22.03, the final spindle zero point will be the sum of P22.03 and P22.15. Setting range: 0–39999	0	0
P22.16	Reserved variables	0–65535	0	0
P22.17	Reserved variables	0–65535	0	0
P22.18	Rigid tapping selection	Ones: Enable/disable 0: Disable 1: Enable Tens: Analog port selection 0: Invalid 1: Al1 2: Al2 3: Al3	0x00	0
P22.19	Analog filter time of rigid tapping	0.0ms–1000.0ms	1.0ms	0
P22.20	Max. frequency of rigid tapping	0.00–400.00Hz	50.00Hz	0

Function code	Name	Detailed parameter description	Default value	Modi fy
Jour	Corresponding frequency of		Value	·y
P22.21	analog zero drift of rigid tapping	0.00–10.00Hz	0.00Hz	0
P22.22	Reserved variables	0–1	0	0
P22.23- P22.24	Reserved variables	0–65535	0	0
P23 grou		l of motor 2		
	Speed loop	P23.00-P23.05 fit for vector control mode only.		
P23.00	proportional gain	Below switch-over frequency 1 (P23.02), the speed loop PI parameters are P23.00 and P23.01. Above	20.0	0
P23.01	Speed loop integral time 1	switch-over frequency 2 (P23.05), the speed loop PI parameters are P23.03 and P23.04; in between	0.200s	0
P23.02	Switch over low point frequency	them, the PI parameters are obtained by linear variation between two groups of parameters, as	5.00Hz	0
P23.03	Speed loop proportional gain 2	shown in the figure below. Pl parameters (P23.00,P23.01)	20.0	0
P23.04	Speed loop integral time 2		0.200s	0
P23.05	Switch over high point frequency	The speed loop dynamic response characteristics of vector control can be adjusted by setting the proportional coefficient and integral time of speed regulator. Increase proportional gain or decrease integral time can accelerate dynamic response of speed loop, however, if the proportional gain is too large or integral time is too small, system oscillation and large overshoot may occur; if proportional gain is too small, stable oscillation or speed offset may occur. Speed loop PI parameter is closely related to the system inertia, users should make adjustment according to different load characteristics based on the default PI parameter to fulfill different needs. Setting range of P23.00: 0.0–200.0	10.00Hz	0

Function			Default	Modi
code	Name	Detailed parameter description	value	fy
		Setting range of P23.01: 0.000–10.000s		
		Setting range of P23.02: 0.00Hz–P23.05		
		Setting range of P23.03: 0.0–200.0		
		Setting range of P23.04: 0.000–10.000s		
		Setting range of P23.05: P23.02–P00.03 (Max.		
		output frequency)		
P23.06	Speed loop output filter	0-8 (corresponds to 0-2^8/10ms)	0	0
	Slip			
	compensation			
P23.07	coefficient of	Slip compensation coefficient is used to adjust the	100%	0
	vector control	slip frequency of vector control to improve system		
	(motoring)	speed control precision. Users can effectively control		
	Slip	the static error of speed by adjusting this parameter		
	compensation	properly.		
P23.08	coefficient of	Setting range: 50–200%	100%	0
	vector control			
	(generating)			
	Current loop	Note:		
P23.09	proportional	1. These two parameters are used to adjust PI	1000	0
	coefficient P	parameters of current loop; it affects dynamic		
		response speed and control precision of the system		
		directly. The default value needs no adjustment		
		under common conditions;		
	Current loop	2. Fit for SVC mode 0 (P00.00=0) and VC mode		
P23.10	integral	(P00.00=3);	1000	0
	coefficient I	3. The value of this function code will be updated		
		automatically after parameter autotuning of		
		synchronous motor is done.		
		Setting range: 0–65535		
P23.11	Speed loop	0.00–10.00s	0.00s	0
1 20.11	differential gain	0.00	0.000	Ŭ
	Proportional	Under VC mode (P00.00=3), below current loop		
P23.12	coefficient of	high-frequency switch-over threshold (P23.14),	1000	0
1 20.12	high-frequency	current loop PI parameters are P23.09 and P23.10;	.000	
	current loop	above current loop high-frequency switch-over		
	Integral	threshold, current loop PI parameters are P23.12		
P23.13	coefficient of	and P23.13.	1000	0
	high-frequency	Setting range of P23.12: 0–20000		

Function code	Name	Detailed parameter description	Default value	Modi fy
code	current loop	Setting range of P23.13: 0–20000	value	ıy
P23.14	High-frequency switch-over threshold of current loop	Setting range of P23.14: 0.0–100.0% (relative to max. frequency)	100.0%	0
P23.15- P23.19	Reserved variables	0–65535	0	•
P24 grou	p Encoder of m	otor 2		
P24.00	Encoder type display	0: Incremental encoder 1: Resolver-type encoder 2: Sin/Cos encoder 3: Endat absolute encoder	0	•
P24.01	Encoder pulse number	Number of pulses generated when the encoder revolves for one circle. Setting range: 0–60000	1024	0
P24.02	Encoder direction	Ones: AB direction 0: Forward 1: Reverse Tens: Z pulse direction (reserved) 0: Forward 1: Reverse Hundreds: CD/UVW pole signal direction 0: Forward 1: Reverse	0x000	0
P24.03	Detection time of encoder offline fault	The detection time of encoder offline fault. Setting range: 0.0–10.0s	1.0s	0
P24.04	Detection time of encoder reversal fault	Detection time of encoder reversal fault. Setting range: 0.0–100.0s	0.8s	0
P24.05	Filter times of encoder detection	Setting range: 0x00–0x99 Ones: Low-speed filter times, corresponds to 2^(0–9)x125us. Tens: High-speed filter times; corresponds to 2^(0–9)x125us.	0x33	0
P24.06	Speed ratio between encoder mounting shaft	Users need to set this parameter when the encoder is not installed on the motor shaft and the drive ratio is not 1.	1.000	0

Function code	Name	Detailed parameter description	Default value	Modi fy
	and motor	Setting range: 0.001–65.535		
P24.07	Control parameters of synchronous motor	Bit0: Enable Z pulse calibration Bit1: Enable encoder angle calibration Bit2: Enable SVC speed measurement Bit3: Select resolver speed measurement mode Bit4: Z pulse capture mode Bit5: Do not detect encoder initial angle in v/f control Bit6: Enable CD signal calibration Bit7: Disable sin/cos sub-division speed measurement Bit8: Do not detect encoder fault during autotuning Bit9: Enable Z pulse detection optimization Bit10: Enable initial Z pulse calibration optimization Bit12: Clear Z pulse arrival signal after stop	0x3	0
P24.08	Enable Z pulse offline detection	0x00–0x11 Ones: Z pulse Reserved Tens: UVW pulse 0: Do not detect 1: Enable	0x10	0
P24.09	Initial angle of Z	Relative electric angle of encoder Z pulse and motor pole position. Setting range: 0.00–359.99	0.00	0
P24.10	Initial angle of the pole	Relative electric angle of encoder position and motor pole position. Setting range: 0.00–359.99	0.00	0
P24.11	Autotuning of initial angle of pole	 0–3 1: Rotary autotuning (DC brake) 2: Static autotuning (suitable for resolver-type encoder, sin/cos with CD signal feedback) 3: Rotary autotuning (initial angle identification) 	0	0
P24.12	Speed measurement optimization selection	0: No optimization 1: Optimization mode 1 2: Optimization mode 2	1	0
P24.13	CD signal zero offset gain	0–65535	0	0
P24.14	Encoder type	Ones: Incremental encoder	0x00	0

Function			Default	Modi
code	Name	Detailed parameter description	value	fy
	selection	0: without UVW		
		1: with UVW		
		Tens: Sin/Cos encoder		
		0: without CD signal		
		1: with CD signal		
	Speed	0: PG card		
P24.15	measurement	1: local; realized by HDIA and HDIB; supports	0	0
	mode	incremental 24V encoder only		
	_	0–255		
	Frequency-	When this parameter is set to 0 or 1,		
P24.16	division	frequency division of 1:1 is	0	0
	coefficient	implemented.		
		0x0000_0xffff		
		Bit0: Enable/disable encoder input filter		
	Pulse filer	0: No filter		
		1: Filter		
		Bit1: Encoder signal filter mode (set Bit0 or Bit2 to 1)		
		0: Self-adaptive filter		
		1: Use P20.18 filter parameters		
		Bit2: Enable/disable encoder frequency-division		
		output filter		
		0: No filter		
		1: Filter		
P24.17		Bit3: Reserved	0x0011	0
	processing	Bit4: Enable/disable pulse reference filter		
		0: No filter		
		1: Filter		
		Bit5: Pulse reference filter mode (valid when Bit4 is		
		set to 1)		
		0: Self-adaptive filter		
		1: Use P24.19 filter parameters		
		Bit6: Frequency-divided output source setting		
		0: Encoder signals		
		1: Pulse reference signals		
		Bits7–15: Reserved		
		0–63		
P24.18	Encoder pulse	The filtering time is P24.18×0.25 µs. The value 0 or 1	10	0
	filter width	indicates 0.25 μs.		
P24.19	Pulse reference	0–63	10	0
	l			l

Function code	Name	Detailed parameter description	Default value	Modi fy
	filter width	The filtering time is P24.19×0.25 μs. The value 0 or 1 indicates 0.25 μs.		
P24.20	Pulse number of pulse reference	0–65535	1024	0
P24.21	Enable angle compensation of synchronous motor	0–1	0	0
P24.22	Switch-over frequency threshold of speed measurement mode	0–630.00Hz	1.00Hz	0
P24.23-	Reserved	0–65535	0	0
P24.24 P25 grou	variables	card input functions		
r 23 grou	HDI3 input type	0: HDI3 is high-speed pulse input		
P25.00	selection	1: HDI3 is digital input	0	0
P25.01	S5 terminal function		0	0
P25.02	S6 terminal function		0	0
P25.03	S7 terminal function		0	0
P25.04	S8 terminal function	The same with P05 group	0	0
P25.05	S9 terminal function		0	0
P25.06	S10 terminal function		0	0
P25.07	HDI3 terminal function		0	0
P25.08	Input terminal polarity of extension card	0x00-0x7F	0x00	0
P25.09	Virtual terminal setup of	0x000–0x7F (0: disable, 1: enable) BIT0: S5 virtual terminal	0x00	0

extension card extension card BIT1: S6 virtual terminal BIT2: S7 virtual terminal BIT3: S8 virtual terminal BIT4: S9 virtual terminal BIT5: S10 virtual terminal BIT5: S10 virtual terminal BIT6: HDI3 virtual terminal BIT6: HDI3 virtual terminal BIT6: HDI3 virtual terminal Switch-on delay P25.11 P25.12 S5 terminal switch-on delay P25.13 S6 switch-off delay P25.14 S7 switch-on delay P25.15 S8 switch-on delay P25.16 S8 terminal switch-on delay P25.17 S7 switch-on delay P25.18 S8 terminal switch-on delay P25.19 S8 switch-on delay P25.20 S9 terminal switch-on delay P25.21 S9 switch-ond delay P25.22 S9 terminal switch-on delay P25.24 S9 terminal switch-on delay P25.25 S9 terminal switch-on delay P25.26 S9 terminal switch-on delay P25.27 S9 terminal switch-on delay P25.28 S9 terminal switch-on delay P25.29 S9 terminal switch-on delay P25.20 S9 terminal switch-on delay P25.21 S9 terminal switch-on delay P25.22 S9 terminal switch-on delay P25.24 Lower limit value of Al3 These function codes define corresponding delay of the programmable input terminals during level variation from switch-on to switch-off. Si electrical level Si valid invalid valid/// valid////////////////////////////////////	Function	Name	Detailed parameter description	Default	Modi
BIT2: S7 virtual terminal BIT3: S8 virtual terminal BIT4: S9 virtual terminal BIT5: S10 virtual terminal Switch-on delay P25.11 BS s switch-off delay P25.12 S7 switch-off delay P25.13 S8 terminal switch-on delay P25.14 S8 terminal switch-on delay P25.15 S8 switch-off delay P25.16 S8 switch-off delay P25.20 S9 terminal switch-on delay P25.21 S9 switch-off delay P25.22 S10 terminal switch-on delay P25.23 S10 terminal switch-on delay P25.24 Lower limit value of Al3 These function codes define torresponding delay of the programmable input terminals during level variation from switch-on to switch-off. Si electrical level Si valid invalid varial valid varial valid varial valid valid varial valid	code	Nume	betailed parameter description	value	fy
BIT3: S8 virtual terminal BIT4: S9 virtual terminal BIT5: S10 virtual terminal BIT6: S10 virtual terminal BIT6: S10 virtual terminal Switch-on delay P25.11 HDI3 terminal Switch-on delay P25.12 S5 terminal Switch-on delay P25.14 S6 terminal Switch-on delay P25.15 S6 switch-off delay P25.16 S7 terminal Switch-on delay P25.17 S7 switch-off delay P25.18 S8 terminal Switch-on delay P25.19 S8 switch-onf delay P25.20 S9 terminal Switch-on delay P25.21 S9 switch-off delay P25.22 S9 switch-off delay P25.23 S10 switch-onf delay P25.24 Lower limit value P25.25 Corresponding P25.26 Corresponding P25.27 These function codes define corresponding delay of the programmable input terminals during level variation from switch-on to switch-off . Si electrical level Si valid invalid valid valid		extension card	BIT1: S6 virtual terminal		
BIT4: S9 virtual terminal BIT5: S10 virtual terminal BIT6: HDI3 virtual terminal BIT6: HDI3 virtual terminal switch-on delay P25.11 HDI3 terminal switch-on delay P25.12 S5 terminal switch-on delay P25.13 S6 terminal switch-on delay P25.14 S6 terminal switch-on delay P25.15 Gelay P25.16 S7 terminal switch-on delay P25.16 S7 switch-off delay P25.17 S7 switch-off delay P25.18 S8 terminal switch-on delay P25.19 S8 terminal switch-on delay P25.20 S9 terminal switch-on delay P25.21 S9 switch-off delay P25.22 S10 terminal switch-on delay P25.23 S10 switch-off delay P25.24 Lower limit value of Al3 Corresponding P25.24 Corresponding P25.25 analog input. When the galago input voltage P25.26 analog input. When the galago input voltage P25.27 analog input. When the galago input voltage P25.21 analog input. When the galago input voltage P25.22 analog input. When the galago input voltage P25.24 analog input. When the galago input voltage P25.24 analog input. When the galago input voltage P25.24 analog input. When the galago input voltage P25.25 analog input. When the galago input voltage P25.26 analog input. When the galago input voltage			BIT2: S7 virtual terminal		
BIT5: \$10 virtual terminal			BIT3: S8 virtual terminal		
P25.10			BIT4: S9 virtual terminal		
P25.10			BIT5: S10 virtual terminal		
P25.10 switch-on delay P25.11 HDI3 terminal switch-off delay P25.12 S5 terminal switch-on delay P25.13 S5 switch-off delay P25.14 S6 terminal switch-on delay P25.15 S6 switch-off delay P25.16 S7 terminal switch-on delay P25.18 S8 terminal switch-on delay P25.19 S8 switch-off delay P25.19 S8 switch-off delay P25.20 S9 terminal switch-on delay P25.21 S9 switch-off delay P25.22 S9 switch-off delay P25.23 S10 terminal switch-on delay P25.24 Lower limit value of Al3 analog input. When the analog input voltage and corresponding set value of Corresponding analog input. When the analog input voltage and corresponding set value of Corresponding analog input. When the analog input voltage			BIT6: HDI3 virtual terminal		
P25.11 HDI3 terminal switch-off delay P25.12 S5 terminal switch-on delay P25.13 S6 terminal switch-on delay P25.14 S6 terminal switch-ondelay P25.15 S6 switch-off delay P25.16 S7 terminal switch-on delay P25.16 S7 terminal switch-on delay P25.17 S7 switch-off delay P25.18 S8 terminal switch-ondelay P25.19 S8 switch-off delay P25.20 S9 terminal switch-on delay P25.21 S9 switch-off delay P25.22 S9 terminal switch-ondelay P25.23 S10 terminal switch-ondelay P25.24 Lower limit value of Al3 Corresponding analog input. When the analog input voltage and corresponding set value of Corresponding analog input. When the analog input voltage and corresponding set value of Corresponding analog input. When the analog input voltage and corresponding set value of Corresponding analog input. When the analog input voltage and corresponding set value of Corresponding analog input.	D25 10	HDI3 terminal		0.0006	
P25.11 switch-off delay P25.12 S5 terminal switch-on delay P25.13 S5 switch-off delay P25.14 S6 terminal switch-on delay P25.15 S6 switch-off delay P25.16 S7 terminal switch-on delay P25.17 S7 switch-off delay P25.18 S8 terminal switch-on delay P25.19 S8 switch-off delay P25.19 S8 switch-off delay P25.20 S9 terminal switch-on delay P25.21 S9 switch-off delay P25.22 S10 terminal switch-on delay P25.24 Lower limit value of Al3 analog input, When the analog input voltage and corresponding set value of Corresponding analog input, When the analog input voltage	P25.10	switch-on delay		0.0008	0
Solution	DOE 44	HDI3 terminal		0.000=	
P25.12 switch-ondelay P25.13 S5 switch-off delay P25.14 S6 terminal switch-on delay P25.15 S6 switch-off delay P25.16 S7 terminal switch-on delay P25.17 S7 switch-off delay P25.18 S8 terminal switch-on delay P25.18 S8 terminal switch-on delay P25.19 S8 switch-off delay P25.20 S9 terminal switch-on delay P25.21 S9 switch-off delay P25.22 S10 terminal switch-on delay P25.23 S10 switch-off delay P25.24 Lower limit value of Al3 P25.24 Corresponding analog input woltage and corresponding set value of analog input woltage and correspondin	P25.11	switch-off delay		0.0008	0
Switch-on delay P25.13 S5 switch-off delay P25.14 S6 terminal switch-on delay P25.15 S6 switch-off delay P25.16 S7 terminal switch-on delay P25.17 S7 switch-off delay P25.17 S7 switch-off delay P25.18 S8 terminal switch-on delay S8 terminal switch-on delay P25.19 S8 switch-off delay S8 switch-off delay S8 switch-off delay P25.20 S9 terminal switch-on delay P25.21 S9 switch-off delay P25.22 S10 terminal switch-on delay P25.23 S10 switch-off delay P25.24 Lower limit value of Al3 Corresponding analog input voltage and corresponding set value of analog input voltage	D05.40	S5 terminal		0.000-)
P25.14 S6 terminal switch-on delay P25.15 S6 switch-off delay variation from switch-on to switch-off switch-on delay variation from switch-on to switch-off delay variation from switch-on to switch-off switch-on delay S8 terminal switch-on delay S8 terminal switch-on delay S9 terminal switch-on delay P25.19 S9 switch-off delay S9 terminal switch-on delay S10 terminal s	P25.12	switch-on delay		0.0008	O
P25.14 S6 terminal switch-on delay P25.15 S6 switch-off delay P25.16 S7 terminal switch-on delay variation from switch-on to switch-off. P25.17 S7 switch-off delay P25.18 S8 terminal switch-on delay P25.19 S8 switch-off delay P25.20 S9 terminal switch-on delay P25.21 S9 switch-off delay P25.22 S10 terminal switch-on delay P25.23 S10 switch-off delay P25.24 Lower limit value of Al3 Corresponding analog input, When the analog input voltage	Do	S5 switch-off)
P25.14 switch-on delay P25.15 S6 switch-off delay P25.16 S7 terminal switch-on delay P25.17 S7 switch-off delay P25.18 S8 terminal switch-on delay P25.19 S8 switch-off delay P25.20 S9 terminal switch-on delay P25.21 S9 switch-off delay P25.22 S10 terminal switch-on delay P25.23 S10 switch-off delay P25.24 Lower limit value of Al3 analog input. When the analog input voltage and corresponding delay of the programmable input terminals during level 0.000s 0	P25.13	delay		0.000s	O
switch-on delay P25.15 S6 switch-off delay P25.16 S7 terminal switch-on delay P25.17 S7 switch-off delay P25.18 P25.18 S8 terminal switch-on delay P25.19 S8 switch-off delay P25.20 S9 terminal switch-on delay P25.21 Carresponding delay of the programmable input terminals during level variation from switch-on to switch-off switch-on to switch-on to switch-off of the programmable input terminals during level variation from switch-on to switch-onff of the programmable input terminals during level variation from switch-on to switch-onff of the programmable input terminals during level variation from switch-on to switch-onff of the programmable input terminals during level variation from switch-on to switch-onff of the programmable input terminals during level variation from switch-on to switch-onff of the programmable input terminals during level variation from switch-on to switch-on to switch-on to switch-onf of the programmable input terminals during level variation from switch-on to switch-onf of the programmable input terminals during level variation from switch-on to switch-on to switch-onf of the programmable input terminals during level variation from switch-on to switch-onf of the programmable input terminals during level variation from switch-on to switch-onf of the programmable input terminals during level variation from switch-on to switch-onf of the programmable input terminals during level variation from switch-onf of the programmable input terminals during level variation from switch-onf of variation from switch-on to switch-on for variation from switch-on to switch-onf of variation from		S6 terminal			
P25.15 delay the programmable input terminals during level 0.000s 0	P25.14	switch-on delay		0.000s	O
P25.16 S7 terminal switch-on delay Variation from switch-on to switch-off Si electrical level Si valid invalid Valid invalid O.000s O.00		S6 switch-off	These function codes define corresponding delay of		
P25.16 switch-on delay P25.17 S7 switch-off delay P25.18 S8 terminal switch-on delay P25.19 S8 switch-off delay P25.20 S9 terminal switch-on delay P25.21 S9 switch-off delay P25.22 S10 terminal switch-on delay P25.23 S10 switch-off delay P25.24 Corresponding analog input, When the analog input voltage	P25.15	delay	the programmable input terminals during level	0.000s	O
Switch-on delay Si electrical level Si valid invalid valid valid invalid 0.000s O		S7 terminal	variation from switch-on to switch-off .		
P25.17 delay P25.18 S8 terminal switch-on delay P25.19 S9 terminal switch-on delay P25.20 S9 switch-off delay P25.21 S10 terminal switch-on delay P25.22 S10 terminal switch-on delay P25.23 Comparison of Al3 P25.24 Corresponding analog input, When the analog input voltage and corresponding analog input, when the analog input voltage and corresponding analog input, when the analog input voltage and corresponding analog input voltage and corresponding input voltage and corresponding input voltage analog	P25.16	switch-on delay	Si electrical level	0.000s	0
P25.18 S8 terminal switch-on delay Setting range: 0.000–50.000s P25.19 S8 switch-off delay S9 terminal switch-on delay S9 switch-off delay S9 switch-off delay S10 terminal switch-on delay S10 terminal switch-on delay S10 switch-off delay S	Do	S7 switch-off	Si valid invalid //// valid////////////////////////////////////		
P25.18 S8 terminal switch-on delay Setting range: 0.000–50.000s P25.19 S8 switch-off delay S9 terminal switch-on delay S9 switch-onf delay S9 switch-off delay S9 switch-off delay S10 terminal switch-on delay S10 switch-off delay S10 switch	P25.17	delay	Switch-on Switch-off	0.000s	O
Switch-on delay Setting range: 0.000–50.000s		S8 terminal	delay delay		
P25.19 S8 switch-off delay P25.20 S9 terminal switch-on delay P25.21 S9 switch-off delay P25.22 S10 terminal switch-on delay P25.22 S10 switch-off delay P25.23 Course ponding analog input, When the analog input voltage and corresponding analog input voltage	P25.18	switch-on delay	Setting range: 0.000–50.000s	0.000s	0
P25.20 S9 terminal switch-on delay P25.21 S9 switch-off delay P25.22 S10 terminal switch-on delay P25.23 S10 switch-off delay P25.24 Lower limit value of Al3 analog input, When the analog input voltage and corresponding analog input, when the analog input voltage and corresponding analog input voltage and corresponding analog input voltage and corresponding analog input voltage analog		S8 switch-off	County range: 0.000 co.occo		
P25.20 switch-on delay P25.21 Sy switch-off delay P25.22 S10 terminal switch-on delay P25.23 S10 switch-off delay P25.24 Lower limit value of Al3 analog input, When the analog input voltage and corresponding analog input, when the analog input voltage and corresponding analog input voltage and corresponding analog input voltage and corresponding analog input voltage analog input voltage	P25.19	delay		0.000s	O
Switch-on delay S9 switch-off delay 0.000s O		S9 terminal			
P25.21 delay P25.22 S10 terminal switch-on delay P25.23 S10 switch-off delay P25.24 Lower limit value of Al3 analog input, When the analog input voltage and corresponding analog input, when the analog input voltage and corresponding input voltage analog input voltage analog input voltage analog input voltage analog input voltage	P25.20	switch-on delay		0.000s	O
P25.22 S10 terminal switch-on delay P25.23 S10 switch-off delay P25.24 Lower limit value of Al3 analog input, When the analog input voltage and corresponding analog input, when the analog input voltage and corresponding analog input voltage analog input voltage analog input voltage analog input voltage		S9 switch-off			
P25.22 switch-on delay P25.23 S10 switch-off delay P25.24 Lower limit value of Al3 analog input. When the analog input voltage Corresponding analog input, When the analog input voltage	P25.21	delay		0.000s	O
P25.23 Switch-off delay P25.24 Lower limit value of Al3 analog input, When the analog input voltage Corresponding analog input, When the analog input voltage		S10 terminal			
P25.23 S10 switch-off delay Lower limit value of Al3 Corresponding analog input. When the analog input voltage	P25.22			0.000s	0
P25.24 Lower limit value of Al3 analog input, When the analog input voltage					_
P25.24 Lower limit value of Al3 These function codes define the relation between analog input voltage and corresponding set value of Corresponding analog input. When the analog input voltage	P25.23	delay		0.000s	0
P25.24 of Al3 analog input voltage and corresponding set value of Corresponding analog input. When the analog input voltage			These function codes define the relation between		
Corresponding analog input. When the analog input voltage	P25.24			0.00V	0
P25 25 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1			1		
setting of lower exceeds the range of max./min. input, the max. input	P25.25			0.0%	0

Function code	Name	Detailed parameter description	Default value	Modi fy
Code	limit of AI3	or min. input will be adopted during calculation.	Value	ıy
P25.26	Upper limit value of Al3	When analog input is current input, 0–20mA current corresponds to 0–10V voltage.	10.00V	0
P25.27	Corresponding setting of upper limit of Al3	In different application cases, 100% of the analog setting corresponds to different nominal values. The figure below illustrates several settings. A Corresponding	100.0%	0
P25.28	Input filter time of AI3	100% setting	0.030s	0
P25.29	Lower limit value of AI4	0 AI	0.00V	0
P25.30	Corresponding setting of lower limit of Al4	20mA /AI3/AI4 -100%	0.0%	0
P25.31	Upper limit value of AI4	Input filter time: Adjust the sensitivity of analog input, increase this value properly can enhance the	10.00V	0
P25.32	Corresponding setting of upper limit of Al4	anti-interference capacity of analog variables; however, it will also degrade the sensitivity of analog input.	100.0%	0
P25.33	Input filter time of AI4	Note: Al3 and Al4 can support 0–10V/0–20mA input, when Al3 and Al4 select 0–20mA input, the corresponding voltage of 20mA is 10V; Setting range of P25.24: 0.00V–P25.26 Setting range of P25.25: -100.0%—100.0% Setting range of P25.26: P25.24—10.00V Setting range of P25.27: -100.0%—100.0% Setting range of P25.28: 0.000s—10.000s Setting range of P25.29: 0.00V–P25.31 Setting range of P25.30: -100.0%—100.0% Setting range of P25.31: P25.29—10.00V Setting range of P25.32: -100.0%—100.0% Setting range of P25.33: 0.000s—100.0%	0.030s	0
P25.34	HDI3 high-speed pulse input function	0: Set input via frequency 1: Count	0	0
P25.35	Lower limit frequency of HDI3	0.000 KHz – P25.37	0.000 KHz	0
P25.36	Corresponding	-100.0%–100.0%	0.0%	0

Function code	Name	Detailed parameter description	Default value	Modi fy
	setting of lower			
	limit frequency of			
	HDI3			
Do	Upper limit	200 00 000000	50.000	
P25.37	frequency of HDI3	P25.35 –50.000KHz	KHz	0
	Corresponding			
	setting of upper			
P25.38	limit frequency of	-100.0%—100.0%	100.0%	0
	HDI3			
P25.39	HDI3 frequency	0.000s-10.000s	0.030s	0
1 20.00	input filter time	0.0003-10.0003	0.0003	
	Al3 input signal	Range: 0–1		
P25.40	type	0: Voltage type	0	0
		1: Current type		
P25.41	Al4 input signal	Range: 0–1 0: Voltage type	0	0
1 23.41	type	1: Current type	U	
P25.42-	Reserved			
P25.45	variables	0–65535	0	0
P26 grou	p Output function	ons of extension I/O card		
D00.00	HDO2 output	0: Open collector high-speed pulse output		
P26.00	type	1: Open collector output	0	0
P26.01	HDO2 output		0	0
1 20.01	selection		-	Ü
P26.02	Y2 output		0	0
	selection			
P26.03	Y3 output		0	0
	selection			
P26.04	Relay RO3 output selection	The same with P06.01	0	0
	Relay RO4			
P26.05	output selection		0	0
D00.00	Relay RO5		0	
P26.06	output selection		0	0
P26.07	Relay RO6		0	0
F20.07	output selection		U	

Function code	Name	Detailed parameter description	Default value	Modi fy
	Relay RO7			
P26.08	output selection		0	0
Doc 00	Relay RO8			
P26.09	output selection		0	0
D00 40	Relay RO9		0	0
P26.10	output selection		0	O
P26.11	Relay RO10		0	0
7 20.11	output selection		0	U
P26.12	Output terminal polarity of extension card	0x0000–0x7FF RO10, RO9RO3, HDO2,Y3, Y2 in sequence	0x000	0
P26.13	HDO2 switch-on delay		0.000s	0
P26.14	HDO2 switch-off delay		0.000s	0
P26.15	Y2 switch-on delay		0.000s	0
P26.16	Y2 switch-off delay		0.000s	0
P26.17	Y3 switch-on delay	This function code defines the corresponding delay	0.000s	0
P26.18	Y3 switch-off delay	of the level variation from switch-on to switch-off.	0.000s	0
P26.19	Relay RO3 switch-on delay	Y valid	0.000s	0
P26.20	Relay RO3 switch-off delay	delay delay Setting range: 0.000–50.000s	0.000s	0
P26.21	Relay RO4 switch-on delay	Note: P26.13 and P26.14 are valid only when P26.00 is set to 1.	0.000s	0
P26.22	Relay RO4 switch-off delay		0.000s	0
P26.23	Relay RO5 switch-on delay		0.000s	0
P26.24	Relay RO5 switch-off delay		0.000s	0
P26.25	Relay RO6 switch-on delay		0.000s	0
P26.26	Relay RO6		0.000s	0

Function	News	Detailed account of the state of	Default	Modi
code	Name	Detailed parameter description	value	fy
	switch-off delay			
D00.07	Relay RO7		0.000-	
P26.27	switch-on delay		0.000s	0
P26.28	Relay RO7		0.000=	0
P20.28	switch-off delay		0.000s	U
P26.29	Relay RO8		0.000s	0
F 20.29	switch-on delay		0.0003	U
P26.30	Relay RO8		0.000s	0
1 20.00	switch-off delay		0.0003	
P26.31	Relay RO9		0.000s	0
1 20.01	switch-on delay		0.0003	
P26.32	Relay RO9		0.000s	0
. 20.02	switch-off delay		0.000	
P26.33	Relay RO10		0.000s	0
1 20.00	switch-on delay		0.0000	
P26.34	Relay RO10		0.000s	0
	switch-off delay		0.000	Ŭ
P26.35	AO2 output		0	0
	selection			
P26.36	AO3 output	The same with P06.14	0	0
	selection			
P26.37	Reserved		0	0
	variables			
P26.38	Lower limit of		0.0%	0
	AO2 output			
500.00	Corresponding		0.001/	
P26.39	AO2 output of	Above function codes define the relation between	0.00V	0
	lower limit	output value and analog output. When the output		
P26.40	Upper limit of	value exceeds the set max./min. output range, the	100.0%	0
	AO2 output	upper/low limit of output will be adopted during		
P26.41	Corresponding	calculation.	10.00V	0
P20.41	AO2 output of	When analog output is current output, 1mA	10.000	
	upper limit AO2 output filter	corresponds to 0.5V voltage. In different		
P26.42	time	applications, 100% of output value corresponds to different analog outputs.	0.000s	0
	Lower limit of			
P26.43	AO3 output		0.0%	0
P26.44	Corresponding		0.00V	0

Function			Default	Modi
code	Name	Detailed parameter description	value	fy
	AO3 output of	AO 10V (20mA)		
	lower limit			
D00 45	Upper limit of		100.00/	0
P26.45	AO3 output		100.0%	O
	Corresponding			
P26.46	AO3 output of	0.0%	10.00V	0
	upper limit	Setting range of P26.38: -100.0%–P26.40		
		Setting range of P26.39: 0.00V–10.00V		
		Setting range of P26.40: P26.38–100.0%		
		Setting range of P26.41: 0.00V–10.00V		
		Setting range of P26.42: 0.000s–10.000s		
P26.47	AO3 output filter	Setting range of P26.43: -100.0%—P26.45	0.000s	0
	time	Setting range of P26.44: 0.00V–10.00V		
		Setting range of P26.45: P26.43–100.0%		
		Setting range of P26.46: 0.00V–10.00V		
		Setting range of P26.47: 0.000s–10.000s		
P26.48-	Reserved	Setting range of 1 20.47. 0.0005-10.0005		
P26.52	variables	0–65535	0	0
P28 grou		control functions		
0 g. ou		0: The master/slave control is invalid	0	0
P28.00	Master/slave	1: This machine is a master	O	•
1 20.00	mode selection	2: This machine is a slave		
	Master/slave	2. The mashine is a slave	0	0
P28.01	communication	0: CAN	· ·	
. 20.0	data selection	1: Reserved		
	uata coloculori	Ones: Master/slave running mode selection	0x001	0
		0: Master/slave mode 0		
		(The master and slave adopt speed control and		
		maintains the power balance by droop control)		
		1: Master/slave mode 1		
		(The master and slave must be in the same type of		
P28.02	Master/slave	vector control mode. The master is speed control,		
	control mode	and the slave will be forced to be in the torque		
		control mode.		
		2: Master/slave mode 2		
		Start in the slave first speed mode (master/slave		
		mode 0) and then switch to torque mode at a certain		
		frequency point (master/slave mode 1)		

Function	Name	Detailed parameter description	Default value	Modi fy
code		Tens: Slave start command source selection	value	ıy
		0: Follow the master to start		
		1: Determined by P00.01		
		Hundreds: Slave transmitting/master receiving data		
		enable		
		0: Enable		
		1: Disable		
P28.03	Slave speed gain	0.0–500.0%	100.0%	0
P28.04	Slave torque gain	0.0–500.0%	100.0%	0
P28.05	Master/slave		5.00Hz	0
	mode 2 speed			
	mode / torque	0.00–10.00Hz		
	mode switching			
	frequency point			
P28.06	Number of slaves	0–15	1	0
P28.07-	Reserved	0.05505	0	
P28.29	variables	0–65535	0	0
P90 grou	p Customized fu	unction group 1		
P90.00-	Reserved	0.05505	0	
P90.39	variables	0–65535	0	0
P91 grou	p Customized fu	unction group 2		
P91.00-	Reserved	0–65535	0	0
P91.39	variables	0-00000		
P92 grou	p Customized fu	unction group 3		
P92.00-	Reserved	0–65535	0	0
P92.39	variables	0-00000		
P93 grou	p Customized fu	unction group 4		
P93.00-	Reserved	0–65535	0	0
P93.39	variables	0-0000	0	

Chapter 7 Troubleshooting

7.1 What this chapter contains

The chapter tells users how to reset faults and check faults history. A complete list of alarms and fault information as well as possible causes and corrective measures are presented in this chapter.



Only well-trained and qualified professionals are allowed to carry out the work described in this chapter. Operations should be carried out according to the instructions presented in Safety precautions.

7.2 Indications of alarms and faults

The fault is indicated by indicators (refer to the "Keypad operation process"). When TRIP indicator is on, the alarm or fault code displayed in the keypad indicates the inverter is in exception state. This chapter covers most of the alarms and faults, and their possible causes and corrective measures, if users cannot figure out the alarm or fault causes, contact local INVT office.

7.3 Fault reset

Users can reset the inverter via STOP/RST key on the keypad, digital inputs, or by cutting off the inverter power. After faults are removed, the motor can be start again.

7.4 Fault history

P07.27–P07.32 record the six latest fault types; P07.33–P07.40, P07.41–P07.48, and P07.49–P07.56 record the running data of the inverter when the latest three faults occurred.

7.5 Inverter faults and solutions

When fault occurred, process the fault as shown below.

- 1. When inverter fault occurred, confirm whether keypad display is improper? If yes, contact INVT;
- If keypad works properly, check the function codes in P07 group to confirm the corresponding fault record parameters, and determine the real state when current fault occurred through parameters;
- 3. Check the table below to see whether corresponding exception states exist based on the corresponding corrective measures;
- 4. Rule out the faults or ask for help from professionals;
- 5. After confirming faults are removed, reset the fault and start running.

7.5.1 Details of faults and solutions

Fault code	Fault type	Possible cause	Corrective measures
OUt1	Inverter unit	Acceleration is too fast;	Increase acceleration time;
OULI	Phase-U protection	IGBT module is damaged;	Replace the power unit;
OUt2	Inverter unit	Misacts caused by	Check drive wires;
0012	Phase-V protection	interference; drive wires are	Check whether there is strong
OUt3	Inverter unit	poorly connected;	interference surrounds the
0013	Phase-W protection	To-ground short circuit	peripheral equipment

Fault code	Fault type	Possible cause	Corrective measures
		occurs	
OV1	Over-voltage during acceleration	Exception occurred to input	Check input power; Check whether load
OV2	Over-voltage during deceleration	voltage; Large energy feedback;	deceleration time is too short; or the motor starts during
OV3	Over-voltage during constant speed running	Lack of brake units; Dynamic brake is not enabled	rotating; Install dynamic brake units; Check the setup of related function codes
OC1	Over-current during acceleration	A landing in the fact	Increase acceleration /deceleration time;
OC2	Over-current during deceleration	Acceleration is too fast; Grid voltage is too low;	Check input power; Select the inverter with larger
ОСЗ	Over-current during constant speed running	Inverter power is too small; Load transient or exception occurred; To-ground short circuit or output phase loss occur; Strong external interference sources; Overvoltage stall protection is not enabled	power; Check if the load is short circuited (to-ground short circuit or line-to-line short circuit) or the rotation is not smooth; Check the output wiring; Check if there is strong interference; Check the setup of related function codes.
UV	Bus undervoltage fault	Grid voltage is too low; Overvoltage stall protection is not enabled	Check grid input power; Check the setup of related function codes
OL1	Motor overload	Grid voltage is too low; Rated motor current is set improperly; Motor stall or load jumps violently	Check grid voltage; Reset rated motor current; Check the load and adjust torque boost
OL2	Inverter overload	Acceleration is too fast; The motor in rotating is restarted; Grid voltage is too low; Load is too large; Power is too small;	Increase acceleration time; Avoid restart after stop; Check grid voltage; Select the inverter with larger power; Select proper motor
SPI	Phase loss on input	Phase loss or violent	Check the input power;

Fault	Fault type	Possible cause	Corrective measures
code	T dun type	T COOLDIO GUUCO	Contouro modedico
	side	fluctuation occurred to R, S	Check installation wiring
		and T input	
SPO	Phase loss on output side	Phase loss occurred to U, V, W output (or the three phases of motor is asymmetrical)	Check the output wiring; Check the motor and cable
OH1	Overheat of rectifier module	Air duct is blocked or fan is damaged;	Ventilate the air duct or replace
OH2	Overheat of inverter module	Ambient temperature is too high; Long-time overload running	the fan; Lower the ambient temperature
EF	External fault	SI external fault input terminal acts	Check external device input
CE	485 communication fault	Baud rate is set improperly; Communication line fault; Communication address error; Communication suffers from strong interference	Set proper baud rate; Check the wiring of communication interfaces; Set proper communication address; Replace or change the wiring to enhance anti-interference capacity
ItE	Current detection fault	Poor contact of the connector of control board; Hall component is damaged; Exception occurred to amplification circuit	Check the connector and re-plug; Replace the hall component; Replace the main control board
tE	Motor autotuning fault	Motor capacity does not match with the inverter capacity, this fault may occur easily if the difference between them is exceeds five power classes; Motor parameter is set improperly; The parameters gained from autotuning deviate sharply from the standard parameters; Autotuning timeout	Change the inverter model, or adopt V/F mode for control; Set proper motor type and nameplate parameters; Empty the motor load and carry out autotuning again; Check motor wiring and parameter setup; Check whether upper limit frequency is larger than 2/3 of the rated frequency

Fault code	Fault type	Possible cause	Corrective measures
EEP	EEPROM fault	R/W error occurred to the control parameters; EEPROM is damaged	Press STOP/RST to reset; Replace the main control board
PIDE	PID feedback offline fault	PID feedback offline; PID feedback source disappears;	Check PID feedback signal wires; Check PID feedback source
bCE	Brake unit fault	Brake circuit fault or brake tube is damaged; The resistance of external brake resistor is too small	Check the brake unit, replace with new brake tubes; Increase brake resistance
END	Running time is up	The actual running time of the inverter is larger than the set running time	Ask help from the supplier, adjust the set running time
OL3	Electronic overload fault	The inverter releases overload pre-alarm based on the set value	Check the load and overload pre-alarm threshold
PCE	Keypad communication fault	The keypad wire is poorly contacted or disconnected; The keypad wire is too long and suffers strong interference; Circuit fault occurred to the keypad or communication part of the main board	Check the keypad wires to confirm whether fault exists; Check the surroundings to rule out interference source; Replace the hardware and ask for maintenance service
UPE	Parameter upload error	The keypad wire is poorly contacted or disconnected; The keypad wire is too long and suffers strong interference; Circuit fault occurred to the keypad or communication part of the main board	Check the surroundings to rule out interference source; Replace the hardware and ask for maintenance service; Replace the hardware and ask for maintenance service
DNE	Parameter download error	The keypad wire is poorly contacted or disconnected; The keypad wire is too long and suffers strong interference; Data storage error occurred to the keypad	Check the surroundings to rule out interference source; Replace the hardware and ask for maintenance service; Re-backup keypad data

Fault code	Fault type	Possible cause	Corrective measures	
Oouc		Inverter output is short	Check whether motor wiring is	
		connected to the ground;	proper;	
	To-ground short	Current detection circuit is	Replace the hall component;	
ETH1	circuit fault 1	faulty;	Replace the main control	
		Actual motor power setup	board;	
		deviates sharply from the	Reset the motor parameters	
		inverter power	properly	
		Inverter output is short	Check whether motor wiring is	
		connected to ground;	proper;	
	To-ground short	Current detection circuit is	Replace the hall component;	
ETH2	circuit fault 1	faulty;	Replace the main control	
		Actual motor power setup	board;	
		deviates sharply from the	Reset the motor parameters	
		inverter power	properly	
			Check the load to ensure it is	
	Speed deviation	Load is too heavy, or stall	proper, increase the detection	
dEu	fault	occurred	time;	
			Check whether control	
			parameters are set properly	
	Maladjustment fault	Control parameters of	Check the load to ensure it is	
		synchronous motor is set	proper,	
		improperly;	Check whether load is proper;	
STo		The parameter gained from	Check whether control	
		autotuning is inaccurate;	parameters are set correctly;	
		The inverter is not	Increase maladjustment	
		connected to motor	detection time	
	Electronic underload	The inverter performs	Check the load and overload	
LL	fault	underload pre-alarm based	pre-alarm threshold	
	radit	on the set value	pro diam impondia	
		Encoder line sequence is		
ENC10	Encoder offline fault	wrong, or signal wires are	Check the encoder wiring	
		poorly connected		
	Encoder reversal	The encoder speed signal is		
ENC1D	fault	contrary to the motor running	Reset encoder direction	
	iauii	direction		
ENC1Z	Encoder Z pulse	Z signal wires are	Chock the wiring of 7 signal	
ENCIZ	offline fault	disconnected	Check the wiring of Z signal	
OT	Motor	Motor over-temperature	Check the wiring of motor	
ОТ	over-temperature	input terminal is valid;	over-temperature input terminal	

Fault code	Fault type	Possible cause	Corrective measures	
Code	fault	Exception occurred to t temperature detection Exception occurred to resistor; Long-time overload running	(terminal function 57); Check whether temperature sensor is proper; Check the motor and perform maintenance on the motor	
		or exception occurred Safe torque off function is		
STO	Safe torque off	enabled by external forces	/	
STL1	Exception occurred to safe circuit of channel H1	The wiring of STO is improper; Fault occurred to external switch of STO; Hardware fault occurred to safety circuit of channel H1	Check whether terminal wiring of STO is proper and firm enough; Check whether external switch of STO can work properly; Replace the control board	
STL2	Exception occurred to channel H2 safe circuit	The wiring of STO is improper; Fault occurred to external switch of STO; Hardware fault occurred to safety circuit of channel H2	Check whether terminal wiring of STO is proper and firm enough; Check whether external switch of STO can work properly; Replace the control board	
STL3	Exception occurred to channel H1 and channel H2	Hardware fault occurred to STO circuit	Replace the control board	
CrCE	Safety code FLASH CRC check fault	Control board is faulty	Replace the control board	
E-Err	Repetitive extension card type	The two inserted extension cards are of the same type	Users should not insert two cards with the same type; check the type of extension card, and remove one card after power down	
ENCUV	Encoder UVW loss fault	No electric level variation occurred to UVW signal	Check the wiring of UVW; Encoder is damaged	
F1-Er	Failed to identify the extension card in card slot 1	There is data transmission in interfaces of card slot 1, however, it cannot read the card type	Confirm whether the extension card inserted can be supported; Stabilize the extension card interfaces after power down, and confirm whether fault still occurs at next power-on;	

Fault	Fault type	Possible cause	Corrective measures
code			Check whether the insertion port is damaged, if yes, replace the insertion port after power down
F2-Er	Failed to identify the extension card in card slot 2	There is data transmission in interfaces of card slot 2, however, it cannot read the card type	Confirm whether the extension card inserted can be supported; Stabilize the extension card interfaces after power down, and confirm whether fault still occurs at next power-on; Check whether the insertion port is damaged, if yes, replace the insertion port after power down
F3-Er	Failed to identify the the extension card in card slot 3	There is data transmission in interfaces of card slot 3, however, it cannot read the card type	Confirm whether the extension card inserted can be supported; Stabilize the extension card interfaces after power down, and confirm whether fault still occurs at next power-on; Check whether the insertion port is damaged, if yes, replace the insertion port after power down
C1-Er	Communication timeout occurred to the extension card in card slot 1	There is no data transmission in interfaces of card slot 1	Confirm whether the extension card inserted can be supported; Stabilize the extension card interfaces after power down, and confirm whether fault still occurs at next power-on; Check whether the insertion port is damaged, if yes, replace the insertion port after power down
C2-Er	Communication timeout occurred to the extension card in card slot 2	There is no data transmission in interfaces of card slot 2	Confirm whether the extension card inserted can be supported; Stabilize the extension card interfaces after power down, and confirm whether fault still

Fault code	Fault type Possible cause		Corrective measures	
Jour			occurs at next power-on; Check whether the insertion port is damaged, if yes, replace the insertion port after power down	
C3-Er	Communication timeout occurred to the extension card in card slot 3	There is no data transmission in interfaces of card slot 3	Confirm whether the extension card inserted can be supported; Stabilize the extension card interfaces after power down, and confirm whether fault still occurs at next power-on; Check whether the insertion port is damaged, if yes, replace the insertion port after power down	
E-DP	Profibus card communication timeout fault	There is no data transmission between the communication card and the host computer (or PLC)	Check whether the communication card wiring is loose or dropped	
E-NET	Ethernet card communication timeout fault	There is no data transmission between the communication card and the host computer	Check whether the communication card wiring is loose or dropped	
E-CAN	CANopen card communication timeout fault	There is no data transmission between the communication card and the host computer (or PLC)	Check whether the communication card wiring is loose or dropped	
E-PN	Profinet card communication timeout fault	There is no data transmission between the communication card and the host computer (or PLC)	Check whether the communication card wiring is loose or dropped	
E-CAT	EtherCat card communication timeout fault	There is no data transmission between the communication card and the host computer (or PLC)	Check whether the communication card wiring is loose or dropped	
E-BAC	BACNet card communication timeout fault	There is no data transmission between the communication card and the host computer (or PLC)	Check whether the communication card wiring is loose or dropped	


Fault code	Fault type	Possible cause	Corrective measures
E-DEV	DeviceNET card communication timeout fault	There is no data transmission between the communication card and the host computer (or PLC)	Check whether the communication card wiring is loose or dropped
ESCAN	Can master/slave communication card communication timeout fault	There is no data transmission between the CAN master and slave communication cards	Check whether the communication card wiring is loose or dropped
S-Err	Master-slave synchronous CAN slave fault	Fault occurred to one of the CAN slave inverters	Detect the CAN slave inverter and analyze the corresponding fault cause of the inverter

7.5.2 Other state


Displayed code	State type	Possible cause	Solution
PoFF	System power failure	The system is powered off or the bus voltage is too low.	Check the grid conditions.

7.6 Analysis on common faults


7.6.1 Motor fails to work




7.6.2 Motor vibrates




7.6.3 Overvoltage




7.6.4 Undervoltage




7.6.5 Unusual heating of motor




7.6.6 Inverter overheating



7.6.7 Motor stalls during ACC



7.6.8 Overcurrent



7.7 Countermeasures on common interference

7.7.1 Interference on meter switches and sensors

Interference phenomenon

Pressure, temperature, displacement, and other signals of a sensor are collected and displayed by a human-machine interaction device. The values are incorrectly displayed as follows after the inverter is started:

- 1. The upper or lower limit is wrongly displayed, for example, 999 or -999.
- 2. The display of values jumps (usually occurring on pressure transmitters).
- The display of values is stable, but there is a large deviation, for example, the temperature is dozens of degrees higher than the common temperature (usually occurring on thermocouples).
- 4. A signal collected by a sensor is not displayed but functions as a drive system running feedback signal. For example, an inverter is expected to decelerate when the upper pressure limit of the compressor is reached, but in actual running, it starts to decelerate before the upper pressure limit is reached.
- After an inverter is started, the display of all kinds of meters (such as frequency meter and current meter) that are connected to the analog output (AO) terminal of the inverter is severely affected, displaying the values incorrectly.
- Proximity switches are used in the system. After an inverter is started, the indicator of a proximity switch flickers, and the output level flips.

Solution

- Check and ensure that the feedback cable of the sensor is 20 cm or farther away from the motor cable
- 2. Check and ensure that the ground wire of the motor is connected to the PE terminal of the inverter (if the ground wire of the motor has been connected to the ground block, you need to use a multimeter to measure and ensure that the resistance between the ground block and PE terminal is lower than 1.5Ω).
- 3. Try to add a safety capacitor of 0.1 μ F to the signal end of the feedback signal terminal of the sensor.
- Try to add a safety capacitor of 0.1 μF to the power end of the sensor meter (pay attention to the voltage of the power supply and the voltage endurance of the capacitor).
- 5. For interference on meters connected to the AO terminal of an inverter, if AO uses current signals of 0 to 20 mA, add a capacitor of 0.47 μ F between the AO and GND terminals; and if AO uses voltage signals of 0 to 10 V, add a capacitor of 0.1 μ F between the AO and GND terminals.

Note:

1. When a decoupling capacitor is required, add it to the terminal of the device connected to the sensor. For example, if a thermocouple is to transmit signals of 0 to 20 mA to a temperature meter,

the capacitor needs to be added on the terminal of the temperature meter.; if an electronic ruler is to transmit signals of 0 to 30 V to a PLC signal terminal, the capacitor needs to be added on the terminal of the PLC.

If a large number of meters or sensors are disturbed. It is recommended that you configure an external C2 filter on the input power end of the inverter. For models of filters, see section D.7.

7.7.2 Interference on communication

Interference phenomenon

The interference described in this section on 485 communication mainly includes communication delay, out of sync, occasional power-off, or complete power-off that occurs after an inverter is started.

If the communication cannot be implemented properly, regardless of whether the inverter is running, the exception is not necessarily caused by interference. You can find out the causes as follows:

- 1. Check whether the 485 communication bus is disconnected or in poor contact.
- 2. Check whether the two ends of line A or B are connected reversely.
- Check whether the communication protocol (such as the baud rate, data bits, and check bit) of the inverter is consistent with that of the upper computer.

If you are sure that communication exceptions are caused by interference, you can resolve the problem through the following measures:

- 1. Simple inspection.
- 2. Arrange the communication cables and motor cables in different cable trays.
- In multi-inverter application scenarios, adopt the chrysanthemum connection mode to connect the communication cables between inverters, which can improve the anti-interference capability.
- 4. In multi-inverter application scenarios, check and ensure that the driving capacity of the master is sufficient.
- In the connection of multiple inverters, you need to configure one 120 Ω terminal resistor on each end.

Solution

- Check and ensure that the ground wire of the motor is connected to the PE terminal of the inverter (if the ground wire of the motor has been connected to the ground block, you need to use a multimeter to measure and ensure that the resistance between the ground block and PE terminal is lower than 1.5 Ω).
- Do not connect the inverter and motor to the same ground terminal as the upper computer. It is recommended that you connect the inverter and motor to the power ground, and connect the upper computer separately to a ground stud.
- 3. Try to short the signal reference ground terminal (GND) of the inverter with that of the upper computer controller to ensure that ground potential of the communication chip on the control board of the inverter is consistent with that of the communication chip of the upper computer.

- 4. Try to short GND of the inverter to its ground terminal (PE).
- 5. Try to add a safety capacitor of 0.1 μF on the power terminal of the upper computer (PLC, HMI, and touch screen). During this process, pay attention to the voltage of the power supply and the voltage endurance capability of the capacitor. Alternatively, you can use a magnet ring (Fe-based nanocrystalline magnet rings are recommended). Put the power L/N line or +/- line of the upper computer through the magnet ring in the same direction and wind 8 coils around the magnet ring.

7.7.3 Failure to stop and indicator shimmering due to motor cable coupling Interference phenomenon

Failure to stop

In an inverter system where an S terminal is used to control the start and stop, the motor cable and control cable are arranged in the same cable tray. After the system is started properly, the S terminal cannot be used to stop the inverter.

2. Indicator shimmering

After an inverter is started, the relay indicator, power distribution box indicator, PLC indicator, and indication buzzer shimmers, blinks, or emits unusual sounds unexpectedly.

Solution

- Check and ensure that the exception signal cable is arranged 20 cm or farther away from the motor cable.
- 2. Add a safety capacitor of 0.1 µF between the digital input terminal (S) and the COM terminal.
- Connect the digital input terminal (S) that controls the start and stop to other idle digital input terminals in parallel. For example, if S1 is used to control the start and stop and S4 is idle, you can try to connect connect S1 to S4 in parallel.

Note: If the controller (such as PLC) in the system controls more than 5 inverters at the same time through digital input terminals (S), this scheme is not available.

7.7.4 Leakage current and interference on RCD

Inverters output high-frequency PWM voltage to drive motors. In this process, the distributed capacitance between the internal IGBT of an inverter and the heat sink and that between the stator and rotor of a motor may inevitably cause the inverter to generate high-frequency leakage current to the ground. A residual current operated protective device (RCD) is used to detect the power-frequency leakage current when a grounding fault occurs on a circuit. The application of an inverter may cause misoperation of a RCD.

- 1. Rules for selecting RCDs
- (1) Inverter systems are special. In these systems, it is required that the rated residual current of common RCDs at all levels is larger than 200 mA, and the inverters are grounded reliably.
- (2) For RCDs, the time limit of an action needs to be longer than that of a next action, and the time difference between two actions need to be longer than 20 ms. For example, 1s, 0.5s, and 0.2s.
- (3) For circuits in inverter systems, electromagnetic RCDs are recommended. Electromagnetic

RCDs have strong anti-interference capability, and thus can prevent the impact of high-frequency leakage current.

Electronic RCD	Electromagnetic RCD
	Requiring highly sensitive, accurate, and
	stable zero-phase sequence current
Low cost, high sensitivity, small in volume,	transformer, using permalloy
susceptible to voltage fluctuation of the grid	high-permeability materials, complex process,
and ambient temperature, weak	high cost, not susceptible to voltage
anti-interference capability	fluctuation of the power supply and ambient
	temperature, strong anti- interference
	capability

- 2. Solution to RCD misoperation (handling the inverter)
- 1. Try to remove the jumper cap at "EMC/J10" on the middle casing of the inverter.
- 2. Try to reduce the carrier frequency to 1.5 kHz (P00.14=1.5).
- 3. Try to modify the modulation mode to "3PH modulation and 2PH modulation" (P8.40=0).
- 3. Solution to RCD misoperation (handling the system power distribution)
- (1) Check and ensure that the power cable is not soaking in water.
- (2) Check and ensure that the cables are not damaged or spliced.
- (3) Check and ensure that no secondary grounding is performed on the neutral wire.
- (4) Check and ensure that the main power cable terminal is in good contact with the air switch or contactor (all screws are tightened).
- (5) Check 1PH powered devices, and ensure that no earth lines are used as neutral wires by these devices.
- (6) Do not use shielded cables as inverter power cables and motor cables.

7.7.5 Live device chassis

Phenomenon

After an inverter is started, there is sensible voltage on the chassis, and you may feel an electric shock when touching the chassis. The chassis, however, is not live (or the voltage is far lower than the human safety voltage) when the inverter is powered on but not running.

Solution

- If there is power distribution grounding or ground stud on the site, ground the cabinet chassis of the drive system through the power ground or stud.
- If there is no grounding on the site, you need to connect the motor chassis to the ground terminal PE of the inverter, and ensure that the jumper at "EMC/J10" on the middle casing of the inverter is shorted.

Chapter 8 Maintenance and hardware fault diagnosis

8.1 What this chapter contains

This chapter describes how to carry out preventive maintenance on Goodrive350 series inverters.

8.2 Periodical inspection

Little maintenance is required when inverters are installed in environments that meet requirements. The following table describes the routine maintenance periods recommended by INVT.

Subject		Item	Method	Criterion
Ambient environment		Check the temperature, and humidity, and whether there is vibration, dust, gas, oil spray, and water droplets in the environment.	Visual inspection, and use instruments for measurement.	The requirements stated in this manual are met.
Ambie	nt environment	Check whether there are foreign matters, such as tools, or dangerous substances placed nearby.	Visual inspection	There are no tools or dangerous substances placed nearby.
	Voltage	Check the voltage of the main circuit and control circuit.	Use multimeters or other instruments for measurement.	The requirements stated in this manual are met.
		Check the display of information.	Visual inspection	The characters are displayed properly.
Keypad		Check whether characters are not completely displayed.	Visual inspection	The requirements stated in this manual are met.
		Check whether the bolts loose or come off.	Screw them up.	No exception occurs.
Main circuit Common		Check whether the machine is deformed, cracked, or damaged, or their color changes due to overheating and aging.	Visual inspection	No exception occurs.
		Check whether there are stains and dust attached.	Visual inspection	No exception occurs. Note: Discoloration of copper bars does not mean that they cannot work properly.

Subject	Item	Method	Criterion
Conductor and	Check whether the conductors are deformed or their color change due to overheat.	Visual inspection	No exception occurs.
wire	Check whether the wire sheaths are cracked or their color changes.	Visual inspection	No exception occurs.
Terminal block	Check whether there is damage.	Visual inspection	No exception occurs.
	Check whether there is electrolyte leakage, discoloration, cracks, and chassis expansion.	Visual inspection	No exception occurs.
Filter capacitor	Check whether the safety valves are released.	Determine the service life based on the maintenance information, or measure them through electrostatic capacity.	No exception occurs.
	Check whether the electrostatic capacity is measured as required.	Use instruments to measure the capacity.	Electrostatic capacity ≥ initial value × 0.85
	Check whether there is displacement caused due to overheat.	Olfactory and visual inspection	No exception occurs.
Resistor	Check whether the resistors are disconnected.	Visual inspection, or remove one end of the connection cable and use a multimeter for measurement.	Resistance range: ±10% (of the standard resistance)
Transformer and reactor	Check whether there is unusual vibration sounds or smells.	Auditory, olfactory, and visual inspection	No exception occurs.
Electromagnetic contactor and	Check whether there are vibration sounds in the workshop.	Auditory inspection	No exception occurs.
relay	Check whether the contacts	Visual inspection	No exception

Subject		Item	Method	Criterion
		are in good contact.		occurs.
		Check whether the screws and connectors loose.	Screw them up.	No exception occurs.
		Check whether there is unusual smell or discoloration.	Olfactory and visual inspection	No exception occurs.
Control	Control PCB, connector	Check whether there are cracks, damage, deformation, or rust.	Visual inspection	No exception occurs.
		Check whether there is electrolyte leakage or deformation.	Visual inspection, and determine the service life based on the maintenance information.	No exception occurs.
		Check whether there are unusual sounds or vibration.	Auditory and visual inspection, and turn the fan blades with your hand.	The rotation is smooth.
	Cooling fan	Check whether the bolts loose.	Screw them up.	No exception occurs.
Cooling system		Check whether there is decoloration caused due to overheat.	Visual inspection, and determine the service life based on the maintenance information.	No exception occurs.
	Ventilation duct	Check whether there are foreign matters blocking or attached to the cooling fan, air inlets, or air outlets.	Visual inspection	No exception occurs.

For more details about maintenance, contact the local INVT office, or visit our website http://www.invt.com.cn, and choose **Service and Support > Online Service**.

8.3 Cooling fan

The service life of the cooling fan of the inverter is more than 25,000 hours. The actual service life of the cooling fan is related to the use of the inverter and the temperature in the ambient environment.

You can view the running duration of the inverter through P07.14 (Accumulated running time).

The increase of the bearing noise indicates a fan fault. If the inverter is applied in a key position, replace the fan once the fan starts to generate unusual noise. You can purchase spare parts of fans from INVT.

Cooling fan replacement



- Read the safety precautions carefully and follow the instructions to perform operations. Otherwise, physical injuries or damage to the device may be caused.
- Stop the device, disconnect the AC power supply, and wait for a time no shorter than the waiting time designated on the inverter.
- Open the cable clamp to loose the fan cable (for inverters of 380 V, 1.5 to 30 kW, the middle casing needs to be removed).
- 3. Remove the fan cable.
- 4. Remove the fan with a screwdriver.
- 5. Install a new fan in the inverter in the reverse steps. Assemble the inverter. Ensure that the air direction of the fan is consistent with that of the inverter, as shown in the following figure.




Fig 8.1 Fan maintenance for inverters of 7.5 kW or higher

6. Power on the inverter.

8.4 Capacitor

8.4.1 Capacitor reforming

If the inverter has been left unused for a long time, you need to follow the instructions to reform the DC bus capacitor before using it. The storage time is calculated from the date the inverter is delivered.

Storage time	Operation principle	
Less than 1 year	No charging operation is required.	
1 to 2 years	The inverter needs to be powered on for 1 hour before the first running command.	
2 to 3 years	Use a voltage controlled power supply to charge the inverter:	

Storage time	Operation principle		
	Charge the inverter at 25% of the rated voltage for 30 minutes, and		
	then charge it at 50% of the rated voltage for 30 minutes, at 75% for		
	another 30 minutes, and finally charge it at 100% of the rated voltage		
	for 30 minutes.		
	Use a voltage controlled power supply to charge the inverter:		
More than 3 years	Charge the inverter at 25% of the rated voltage for 2 hours, and then		
	charge it at 50% of the rated voltage for 2 hours, at 75% for another 2		
	hours, and finally charge it at 100% of the rated voltage for 2 hours.		

The method for using a voltage controlled power supply to charge the inverter is described as follows:

The selection of a voltage controlled power supply depends on the power supply of the inverter. For inverters with an incoming voltage of 1PH/3PH 230 V AC, you can use a 230 V AC/2 A voltage regulator. Both 1PH and 3PH inverters can be charged with a 1PH voltage controlled power supply (connect L+ to R, and N to S or T). All the DC bus capacitors share one rectifier, and therefore they are all charged.

For inverters of a high voltage class, ensure that the voltage requirement (for example, 380 V) is met during charging. Capacitor changing requires little current, and therefore you can use a small-capacity power supply (2 A is sufficient).

The method for using a resistor (incandescent lamp) to charge the drive is described as follows:

If you directly connect the drive device to a power supply to charge the DC bus capacitor, it needs to be charged for a minimum of 60 minutes. The charging operation must be performed at a normal indoor temperature without load, and you must connect a resistor in series mode in the 3PH circuit of the power supply.

For a 380 V drive device, use a resistor of 1 k Ω /100W. If the voltage of the power supply is no higher than 380 V, you can also use an incandescent lamp of 100W. If an incandescent lamp is used, it may go off or the light may become very weak.




Fig 8.2 Charging circuit example of driving devices of 380 V

8.4.2 Electrolytic capacitor replacement



Read the safety precautions carefully and follow the instructions to perform operations. Otherwise, physical injuries or damage to the device may be caused.

The electrolytic capacitor of an inverter must be replaced if it has been used for more than 35,000 hours. For details about the replacement, contact the local INVT office.

8.5 Power cable



- Read the safety precautions carefully and follow the instructions to perform operations. Otherwise, physical injuries or damage to the device may be caused.
- Stop the inverter, disconnect the power supply, and wait for a time no shorter than the waiting time designated on the inverter.
- 2. Check the connection of the power cables. Ensure that they are firmly connected.
- 3. Power on the inverter.

Chapter 9 Communication protocol

9.1 What this chapter contains

This chapter describes the communication protocol of Goodrive350 series products.

Goodrive350 series inverters provide RS485 communication interfaces and adopt the master-slave communication based on the international standard Modbus communication protocol. You can implement centralized control (setting commands for controlling the inverter, modifying the running frequency and related function code parameters, and monitoring the working state and fault information of the inverter) through PC/PLC, upper control computer, or other devices to meet specific application requirements.

9.2 Modbus protocol introduction

Modbus is a software protocol, a common language used in electronic controllers. By using this protocol, a controller can communicate with other devices through transmission lines. It is a general industrial standard. With this standard, control devices produced by different manufacturers can be connected to form an industrial network and be monitored in a centralized way.

The Modbus protocol provides two transmission modes, namely American Standard Code for Information Interchange (ASCII) and remote terminal units (RTU). On one Modbus network, all the device transmission modes, baud rates, data bits, check bits, end bits, and other basic parameters must be set consistently.

A Modbus network is a control network with one master and multiple slaves, that is, on one Modbus network, there is only one device serving as the master, and other devices are the slaves. The master can communicate with one slave or broadcast messages to all the slaves. For separate access commands, a slave needs to return a response. For broadcasted information, slaves do not need to return responses.

9.3 Application of Modbus

Goodrive350 series inverters use the RTU mode provided by the Modbus protocol, and RS485 interfaces are used.

9.3.1 RS485

RS485 interfaces work in half-duplex mode and transmit data signals in the differential transmission way, which is also referred to as balanced transmission. An RS485 interface uses a twisted pair, where one wire is defined as A (+), and the other B (-). Generally, if the positive electrical level between the transmission drives A and B ranges from +2 V to +6 V, the logic is "1"; and if it ranges from -2 V to -6 V, the logic is "0".

The 485+ terminal on the terminal block of the inverter corresponds to A, and 485- corresponds to B.

The communication baud rate (P14.01) indicates the number of bits transmitted in a second, and the unit is bit/s (bps). A higher baud rate indicates faster transmission and poorer anti-interference capability. When a twisted pair of 0.56 mm (24 AWG) is used, the maximum transmission distance varies according to the baud rate, as described in the following table.

Baud rate (bps)	Max. transmission distance	Baud rate (bps)	
2400	1800 m	9600	800 m
4800	1200 m	19200	600 m

When RS485 interfaces are used for long-distance communication, it is recommended that you use shielded cables, and use the shield layer as the ground wires.

When there are fewer devices and the transmission distance is short, the whole network works well without terminal load resistors. The performance, however, degrades as the distance increases. Therefore, it is recommended that you use a 120 Ω terminal resistor when the transmission distance is long.

9.3.1.1 Application to one inverter

Fig 9.1 is the Modbus wiring diagram of one inverter and a PC. Generally, PCs do not provide RS485 interfaces, so you need to convert an RS232 interface or USB port of a PC to an RS485 interface. Connect end A of the RS485 interface to the 485+ port on the terminal block of the inverter, and connect end B to the 485- port. It is recommended that you use shielded twisted pairs. When an RS232-RS485 converter is used, the cable used to connect the RS232 interface of the PC and the converter cannot be longer than 15 m. Use a short cable when possible. It is recommended that you insert the converter directly into the PC. Similarly, when a USB-RS485 converter is used, use a short cable when possible.




Fig 9.1 Wiring of RS485 applied to one inverter

9.3.1.2 Application to multiple inverters

In practical application to multiple inverters, chrysanthemum connection and star connection are commonly used.

According to the requirements of the RS485 industrial bus standards, all the devices need to be connected in chrysanthemum mode with one 120 Ω terminal resistor on each end, as shown in Fig 9.2. Fig 9.3 is the simplified wiring diagram, and Fig 9.4 is the practical application diagram.




Fig 9.2 On-site chrysanthemum connection diagram




Fig 9.3 Simplified chrysanthemum connection diagram




Fig 9.4 Practical application diagram of chrysanthemum connection

Fig 9.5 shows the start connection diagram. When this connection mode is adopted, the two devices that are farthest away from each other on the line must be connected with a terminal resistor (in Fig 9.5, the two devices are devices 1# and 15#).




Fig 9.5 Star connection

Use shielded cable, if possible, in multi-device connection. The baud rates, data bit check settings, and other basic parameters of all the devices on the RS485 line must be set consistently, and

addresses cannot be repeated.

9.3.2 RTU mode

9.3.2.1 RTU communication frame structure

When a controller is set to use the RTU communication mode on a Modbus network, every byte (8 bits) in the message includes 2 hexadecimal characters (each includes 4 bits). Compared with the ASCII mode, the RTU mode can transmit more data with the same baud rate.

Code system

- 1 start bit
- 7 or 8 data bits; the minimum valid bit is transmitted first. Each frame domain of 8 bits includes 2 hexadecimal characters (0–9, A–F).
- 1 odd/even check bit; this bit is not provided if no check is needed.
- 1 end bit (with check performed), 2 bits (without check)

Error detection domain

Cyclic redundancy check (CRC)

The following table describes the data format.

11-bit character frame (Bits 1 to 8 are data bits)


Start bit BIT1 BIT2 BIT3 BIT4	BIT5 BIT6 BIT7	BIT8 Check bit End bit
-------------------------------	----------------	------------------------

10-bit character frame (Bits 1 to 7 are data bits)

Start bit	BIT1	BIT2	BIT3	BIT4	BIT5	BIT6	BIT7	Check bit	End bit	
-----------	------	------	------	------	------	------	------	--------------	---------	--

In a character frame, only the data bits carry information. The start bit, check bit, and end bit are used to facilitate the transmission of the data bits to the destination device. In practical applications, you must set the data bits, parity check bits, and end bits consistently.

In RTU mode, the transmission of a new frame always starts from an idle time (the transmission time of 3.5 bytes). On a network where the transmission rate is calculated based on the baud rate, the transmission time of 3.5 bytes can be easily obtained. After the idle time ends, the data domains are transmitted in the following sequence: slave address, operation command code, data, and CRC check character. Each byte transmitted in each domain includes 2 hexadecimal characters (0–9, A–F). The network devices always monitor the communication bus. After receiving the first domain (address information), each network device identifies the byte. After the last byte is transmitted, a similar transmission interval (the transmission time of 3.5 bytes) is used to indicate that the transmission of the frame ends. Then, the transmission of a new frame starts.



The information of a frame must be transmitted in a continuous data flow. If there is an interval greater than the transmission time of 1.5 bytes before the transmission of the entire frame is complete, the receiving device deletes the incomplete information, and mistakes the subsequent byte for the address domain of a new frame. Similarly, if the transmission interval between two frames is shorter than the transmission time of 3.5 bytes, the receiving device mistakes it for the data of the last frame. The CRC check value is incorrect due to the disorder of the frames, and thus a communication fault occurs.

The following table describes the standard structure of an RTU frame.

START (frame header)	T1-T2-T3-T4 (transmission time of 3.5 bytes)
ADDD (classes address describ)	Communication address: 0–247 (decimal system) (0 is the
ADDR (slave address domain)	broadcast address)
CNAD (function domain)	03H: read slave parameters
CMD (function domain)	06H: write slave parameters
DATA (N-1)	
	Data of 2×N bytes, main content of the communication as well
DATA (0)	as the core of data exchanging
(data domain)	
CRC CHK (LSBs)	Datastian value ODO (40 hits)
CRC CHK high bit (MSBs)	Detection value: CRC (16 bits)
END (frame tail)	T1-T2-T3-T4 (transmission time of 3.5 bytes)

9.3.2.2 RTU communication frame error check modes

During the transmission of data, errors may occur due to various factors. Without check, the data receiving device cannot identify data errors and may make a wrong response. The wrong response may cause severe problems. Therefore, the data must be checked.

The check is implemented as follows: The transmitter calculates the to-be-transmitted data based on a specific algorithm to obtain a result, adds the result to the rear of the message, and transmits them together. After receiving the message, the receiver calculates the data based on the same algorithm to obtain a result, and compares the result with that transmitted by the transmitter. If the results are the same, the message is correct. Otherwise, the message is considered wrong.

The error check of a frame includes two parts, namely, bit check on individual bytes (that is, odd/even check using the check bit in the character frame), and whole data check (CRC check).

Bit check on individual bytes (odd/even check)

You can select the bit check mode as required, or you can choose not to perform the check, which will affect the check bit setting of each byte.

Definition of even check: Before the data is transmitted, an even check bit is added to indicate whether the number of "1" in the to-be-transmitted data is odd or even. If it is even, the check bit is set to "0"; and if it is odd, the check bit is set to "1".

Definition of odd check: Before the data is transmitted, an odd check bit is added to indicate whether the number of "1" in the to-be-transmitted data is odd or even. If it is odd, the check bit is set to "0"; and if it is even, the check bit is set to "1".

For example, the data bits to be transmitted are "11001110", including five "1". If the even check is applied, the even check bit is set to "1"; and if the odd check is applied, the odd check bit is set to "0". During the transmission of the data, the odd/even check bit is calculated and placed in the check bit of the frame. The receiving device performs the odd/even check after receiving the data. If it finds that the odd/even parity of the data is inconsistent with the preset information, it determines that a communication error occurs.

CRC check mode

A frame in the RTU format includes an error detection domain based on the CRC calculation. The CRC domain checks all the content of the frame. The CRC domain consists of two bytes, including 16 binary bits. It is calculated by the transmitter and added to the frame. The receiver calculates the CRC of the received frame, and compares the result with the value in the received CRC domain. If the two CRC values are not equal to each other, errors occur in the transmission.

During CRC, 0xFFFF is stored first, and then a process is invoked to process a minimum of 6 contiguous bytes in the frame based on the content in the current register. CRC is valid only for the 8-bit data in each character. It is invalid for the start, end, and check bits.

During the generation of the CRC values, the "exclusive or" (XOR) operation is performed on the each 8-bit character and the content in the register. The result is placed in the bits from the least significant bit (LSB) to the most significant bit (MSB), and 0 is placed in the MSB. Then, LSB is detected. If LSB is 1, the XOR operation is performed on the current value in the register and the preset value. If LSB is 0, no operation is performed. This process is repeated 8 times. After the last bit (8th bit) is detected and processed, the XOR operation is performed on the next 8-bit byte and the current content in the register. The final values in the register are the CRC values obtained after operations are performed on all the bytes in the frame.

The calculation adopts the international standard CRC check rule. You can refer to the related standard CRC algorithm to compile the CRC calculation program as required.

The following is a simple CRC calculation function for your reference (using the C programming language):

```
unsigned int crc_cal_value(unsigned charxdata_value,unsigned char data_length) {
    int i;
    unsigned int crc_value=0xffff;
    while(data_length--)
```

In the ladder logic, CKSM uses the table look-up method to calculate the CRC value according to the content in the frame. The program of this method is simple, and the calculation is fast, but the ROM space occupied is large. Use this program with caution in scenarios where there are space occupation limits on programs.

9.4 RTU command code and communication data

9.4.1 Command code: 03H, reading N words (continuously reading a maximum of 16 words)

The command code 03H is used by the master to read data from the inverter. The quantity of data to be read depends on the "data quantity" in the command. A maximum of 16 pieces of data can be read. The addresses of the read parameters must be contiguous. Each piece of data occupies 2 bytes, that is, one word. The command format is presented using the hexadecimal system (a number followed by "H" indicates a hexadecimal value). One hexadecimal value occupies one byte.

The 03H command is used to read information including the parameters and operation state of the inverter.

For example, starting from the data address of 0004H, to read two contiguous pieces of data (that is, to read content from the data addresses 0004H and 0005H), the structure of the frame is described in the following table.

START	T1-T2-T3-T4 (transmission time of 3.5 bytes)	
ADDR (address)	01H	
CMD (command code)	03H	
Most significant byte (MSB) of	OOH	
the start address	00Н	
Least significant byte (LSB) of	-	
the start address	04H	

MSB of data quantity	00H	
LSB of data quantity	02H	
LSB of CRC	85H	
MSB of CRC	CAH	
END T1-T2-T3-T4 (transmission time of 3.5 bytes)		

The value in START and END is "T1-T2-T3-T4 (transmission time of 3.5 bytes)", indicating that the RS485 needs to stay idle for at least the transmission time of 3.5 bytes. An idle time is required to distinguish on message from another to ensure that the two messages are not regarded as one.

The value of ADDR is 01H, indicating that the command is transmitted to the inverter whose address is 01H. The ADDR information occupies one byte.

The value of CMD is 03H, indicating that the command is used to read data from the inverter. The CMD information occupies one byte.

"Start address" indicates that data reading is started from this address. It occupies two bytes, with the MSB on the left and LSB on the right.

"Data quantity" indicates the quantity of data to be read (unit: word).

The value of "Start address" is 0004H, and that of "Data quantity" is 0002H, indicating that data is to be read from the data addresses of 0004H and 0005H.

CRC check occupies two bytes, with the LSB on the left, and MSB on the right.

RTU slave response (transmitted by the inverter to the master)

START	T1-T2-T3-T4 (transmission time of 3.5 bytes)	
ADDR	01H	
CMD	03H	
Number of bytes	04H	
MSB of data in 0004H	13H	
LSB of data in 0004H	88H	
MSB of data in 0005H	00H	
LSB of data in 0005H	00H	
LSB of CRC	7EH	
MSB of CRC	9DH	
END	T1-T2-T3-T4 (transmission time of 3.5 bytes)	

The definition of the response information is described as follows:

The value of ADDR is 01H, indicating that the message is transmitted by the inverter whose address is 01H. The ADDR information occupies one byte.

The value of CMD is 03H, indicating that the message is a response of the inverter to the 03H command of the master for reading data. The CMD information occupies one byte.

"Number of bytes" indicates the number of bytes between a byte (not included) and the CRC byte (not

included). The value 04 indicates that there are four bytes of data between "Number of bytes" and "LSB of CRC", that is, "MSB of data in 0004H", "LSB of data in 0004H", "MSB of data in 0005H", and "LSB of data in 0005H".

A piece of data is two bytes, with the MSB on the left and LSB on the right. From the response, we can see that the data in 0004H is 1388H, and that in 0005H is 0000H.

CRC check occupies two bytes, with the LSB on the left, and MSB on the right.

9.4.2 Command code: 06H, writing a word

This command is used by the master to write data to the inverter. One command can be used to write only one piece of data. It is used to modify the parameters and operation mode of the inverter.

For example, to write 5000 (1388H) to 0004H of the inverter whose address is 02H, the structure of the frame is described in the following table.

RTU master command (transmitted by the master to the inverter)

START	T1-T2-T3-T4 (transmission time of 3.5 bytes)
ADDR	02H
CMD	06H
MSB of data writing address	00H
LSB of data writing address	04H
MSB of to-be-written data	13H
LSB of to-be-written data	88H
LSB of CRC	C5H
MSB of CRC 6EH	
END T1-T2-T3-T4 (transmission time of 3.5	

RTU slave response (transmitted by the inverter to the master)

START	T1-T2-T3-T4 (transmission time of 3.5 bytes)		
ADDR	02H		
CMD	06H		
MSB of data writing address	00H		
LSB of data writing address	04H		
MSB of to-be-written data	13H		
LSB of to-be-written data	88H		
LSB of CRC	C5H		
MSB of CRC	6EH		
END T1-T2-T3-T4 (transmission time of 3.			

Note: The sections 9.2 and 9.3 mainly describes the command formats. For the detailed application, see the examples in section 9.4.8.

9.4.3 Command code: 08H, diagnosis

Sub-function code description

Sub-function code	Description	
0000	Return data based on query requests	

For example, to query about the circuit detection information about the inverter whose address is 01H, the query and return strings are the same, and the format is described in the following tables.

RTU master command

START	T1-T2-T3-T4 (transmission time of 3.5 bytes)		
ADDR	01H		
CMD	08H		
MSB of the sub-function code 00H			
LSB of the sub-function code	00H		
MSB of data	12H		
LSB of data ABH			
LSB of CRC CHK	ADH		
MSB of CRC CHK 14H			
END T1-T2-T3-T4 (transmission time of 3.5 b			

RTU slave response

START	T1-T2-T3-T4 (transmission time of 3.5 bytes)	
ADDR	01H	
CMD	08H	
MSB of the sub-function code	00H	
LSB of the sub-function code	00H	
MSB of data	12H	
LSB of data	ABH	
LSB of CRC CHK	ADH	
MSB of CRC CHK	14H	
END	T1-T2-T3-T4 (transmission time of 3.5 bytes)	

9.4.4 Command code: 10H, continuous writing

The command code 10H is used by the master to write data to the inverter. The quantity of data to be written is determined by "Data quantity", and a maximum of 16 pieces of data can be written.

For example, to write 5000 (1388H) and 50 (0032H) respectively to 0004H and 0005H of the inverter whose slave address is 02H, the structure of the frame is described in the following table.

RTU master command (transmitted by the master to the inverter)

START	T1-T2-T3-T4 (transmission time of 3.5 bytes)	
ADDR	02H	
CMD	10H	
MSB of data writing address	00H	
LSB of data writing address	04H	
MSB of data quantity	00H	

LSB of data quantity	02H		
Number of bytes	04H		
MSB of data to be written to 0004H	13H		
LSB of data to be written to 0004H	88H		
MSB of data to be written to 0005H	00H		
LSB of data to be written to 0005H	32H		
LSB of CRC	C5H		
MSB of CRC	6EH		
END	T1-T2-T3-T4 (transmission time of 3.5 bytes)		

RTU slave response (transmitted by the inverter to the master)

START	T1-T2-T3-T4 (transmission time of 3.5 bytes)		
ADDR	02H		
CMD	10H		
MSB of data writing address	00H		
LSB of data writing address	04H		
MSB of data quantity	00H		
LSB of data quantity	у 02Н		
LSB of CRC	C5H		
MSB of CRC 6EH			
END	T1-T2-T3-T4 (transmission time of 3.5 bytes)		

9.4.5 Data address definition

This section describes the address definition of communication data. The addresses are used for controlling the running, obtaining the state information, and setting related function parameters of the inverter.

9.4.5.1 Function code address representation rules

The address of a function code consists of two bytes, with the MSB on the left and LSB on the right. The MSB ranges from 00 to ffH, and the LSB also ranges from 00 to ffH. The MSB is the hexadecimal form of the group number before the dot mark, and LSB is that of the number behind the dot mark. Take P05.06 as an example, the group number is 05, that is, the MSB of the parameter address is the hexadecimal form of 05; and the number behind the dot mark is 06, that is, the LSB is the hexadecimal form of 06. Therefore, the function code address is 0506H in the hexadecimal form. For P10.01, the parameter address is 0A01H.

Function code	Name	Detailed parameter description	Setting range	Default value	Modify
P10.00	Simple PLC mode	0: Stop after running once 1: Keep running in the final value after running once 2: Cyclic running	0-2	0	0
P10.01	Simple PLC memory	No memory after power down Hemory after power down	0-1	0	0

Function code	Name	Detailed parameter description	Setting range	Default value	Modify
	selection				

Note:

- The parameters in the P99 group are set by the manufacturer. They cannot be read or modified.
 Some parameters cannot be modified when the inverter is running; some cannot be modified regardless of the state of the inverter. Pay attention to the setting range, unit, and related description of a parameter when modifying it.
- 2. The service life of the Electrically Erasable Programmable Read-Only Memory (EEPROM) may be reduced if it is frequently used for storage. For users, some function codes do not need to be stored during communication. The application requirements can be met by modifying the value of the on-chip RAM, that is, modifying the MSB of the corresponding function code address from 0 to 1. For example, if P00.07 is not to be stored in the EEPROM, you need only to modify the value of the RAM, that is, set the address to 8007H. The address can be used only for writing data to the on-chip RAM, and it is invalid when used for reading data.

9.4.5.2 Description of other function code addresses

In addition to modifying the parameters of the inverter, the master can also control the inverter, such as start and stop it, and monitor the operation state of the inverter. The following table describes other function parameters.

Function	Address	Data description	R/W
		0001H: Forward running	
		0002H: Reverse running	
		0003H: Forward jogging	
Communication-based	2000H	0004H: Reverse jogging	DAM
control command	2000H	0005H: Stop	R/VV
		0006H: Coast to stop (emergency stop)	R/W
		0007H: Fault reset	
		0008H: Jogging to stop	
	2001H	Communication-based frequency setting (0-	
		Fmax, unit: 0.01 Hz)	R/W
	2002H	PID setting, range (0-1000, 1000 corresponding	17/44
		to 100.0%)	
Communication-based	ed 2003H	PID feedback, range (0–1000, 1000	R/W
value setting		corresponding to 100.0%)	1000
value setting		Torque setting (-3000-+3000, 1000	
	2004H	corresponding to 100.0% of the rated current of	R/W
		the motor)	
	2005H	Setting of the upper limit of the forward running	R/W
	200011	frequency (0-Fmax, unit: 0.01 Hz)	17/77

Function	Address	Data description	R/W	
	2006H	Setting of the upper limit of the reverse running	R/W	
		frequency (0–Fmax, unit: 0.01 Hz)		
		Upper limit of the electromotion torque (0–3000,	R/W	
	2007H	2007H 1000 corresponding to 100.0% of the rated		
		current of the inverter)		
	000011	Upper limit of the brake torque (0–3000, 1000	D.444	
	2008H	corresponding to 100.0% of the rated current of	R/W	
		the motor)		
		Special control command word: Bit0-1: =00: Motor 1 =01: Motor 2		
		=10: Motor 3 =11: Motor 4		
		Bit2: =1 Torque control disabled =0: Torque		
		control cannot be disabled		
	2009H	Bit3: =1 Power consumption reset to 0	R/W	
		=0: Power consumption not reset		
		Bit4: =1 Pre-excitation =0: Pre-excitation		
		disabled		
		Bit5: =1 DC brake =0: DC brake disabled		
		Virtual input terminal command, range: 0x000-		
200AH		0x1FF	R/W	
	200BH	Virtual output terminal command, range: 0x00-	R/W	
	200611	0x0F	IX/VV	
		Voltage setting (used when V/F separation is		
	200CH	implemented)	R/W	
	200011	(0-1000, 1000 corresponding to 100.0% of the	IN/VV	
		rated voltage of the motor)		
	200DH	AO output setting 1 (-1000-+1000, 1000	R/W	
		corresponding to 100.0%)		
	200EH	AO output setting 2 (-1000-+1000, 1000	R/W	
		corresponding to 100.0%)		
		0001H: Forward running		
Inverter state word 1		0002H: Reverse running		
	2100H	0003H: Stopped	R	
	1	0004H: Faulty		
		0005H: POFF		
		0006H: Pre-excited		
		Bit0: =0: Not ready to run =1: Ready to run		
Inverter state word 2	2101H	Bi1–2: =00: Motor 1 =01: Motor 2	R	
	1	=10: Motor 3 =11: Motor 4		

Function	Address	Data description	1	R/W
		Bit3: =0: Asynchronous	machine =1:	
		Synchronous machine		
		Bit4: =0: No overload alarm =1: C		
		Bit5-Bit6: =00: Keypad-based	control =01:	
		Terminal-based control		
		=10: Communication-based contr	ol	
Inverter fault code	2102H	See the description of fault types.		R
Inverter identification code	2103H	GD350x0109		R
Running frequency	3000H	0-Fmax (unit: 0.01Hz)		R
Set frequency	3001H	0-Fmax (unit: 0.01Hz)		R
Bus voltage	3002H	0.0-2000.0 V (unit: 0.1V)		R
Output voltage	3003H	0–1200V (unit: 1V)		R
Output current	3004H	0.0-3000.0A (unit: 0.1A)		R
Rotating speed	3005H	0-65535 (unit: 1RPM)		R
Ouptut power	3006H	-300.0-+300.0% (unit: 0.1%)		R
Output torque	3007H	-250.0-+250.0% (unit: 0.1%)		R
Closed-loop setting	3008H	-100.0-+100.0% (unit: 0.1%)		R
Closed-loop feedback	3009H	-100.0-+100.0% (unit: 0.1%)		R
Input state	300AH	000–1FF		R
Output state	300BH	000–1FF	Compatible	R
Analog input 1	300CH	0.00-10.00V (unit: 0.01V)	with CHF100A	R
Analog input 2	300DH	0.00-10.00V (unit: 0.01V)	and CHV100	R
Analog input 3	300EH	-10.00–10.00V (unit: 0.01V)	communication	R
Analog input 4	300FH		addresses	R
Read input of high-speed pulse 1	3010H	0.00-50.00kHz (unit: 0.01Hz)		R
Read input of	3011H			R
high-speed pulse 2	301111			K
Read current step of	3012H	0–15		R
multi-step speed	301211	0-13] [Γ
External length	3013H	0–65535] [R
External count value	3014H	0–65535] [R
Torque setting	3015H	-300.0-+300.0% (unit: 0.1%)] [R
Identification code	3016H] [R
Fault code	5000H			R

The Read/Write (R/W) characteristics indicate whether a function can be read and written. For example, "Communication-based control command" can be written, and therefore the command code 6H is used to control the inverter. The R characteristic indicates that a function can only be read, and

W indicates that a function can only be written.

Note: Some parameters in the preceding table are valid only after they are enabled. Take the running and stop operations as examples, you need to set "Running command channel" (P00.01) to "Communication", and set "Communication running command channel" (P00.02) to the Modbus communication channel. For another example, when modifying "PID setting", you need to set "PID reference source" (P09.00) to Modbus communication.

The following table describes the encoding rules of device codes (corresponding to the identification code 2103H of the inverter).

8 MSBs	Meaning	8 LSBs Meaning	
	01 GD	0x08	GD35 vector inverter
01		0x09	GD35-H1 vector inverter
		0x0a	GD300 vector inverter
		0xa0	GD350 vector inverter

9.4.6 Fieldbus scale

In practical applications, communication data is represented in the hexadecimal form, but hexadecimal values cannot represent decimals. For example, 50.12 Hz cannot be represented in the hexadecimal form. In such cases, we can multiply 50.12 by 100 to obtain an integer 5012, and then 50.12 can be represented as 1394H (5012 in the decimal form) in the hexadecimal form.

In the process of multiplying a non-integer by a multiple to obtain an integer, the multiple is referred to as a fieldbus scale.

The fieldbus scale depends on the number of decimals in the value specified in "Detailed parameter description" or "Default value". If there are n decimals in the value, the fieldbus scale m is the nth-power of 10. Take the following table as an example, m is 10.

Function code	Name	Detailed parameter description	Default value	
P01.20	Wake-up-from-sleep delay	0.0-3600.0s (valid when P01.19 is 2)	0.0s	
P01.21	Restart after power cut	0: Restart is disabled	0	
F 01.21	ixesian anel power cut	1: Restart is enabled	l 0	

The value specified in "Detailed parameter description" or "Default value" contains one decimal, so the fieldbus scale is 10. If the value received by the upper computer is 50, the value of "Wake-up-from-sleep delay" of the inverter is 5.0 (5.0=50/10).

To set the "Wake-up-from-sleep delay" to 5.0s through Modbus communication, you need first to multiply 5.0 by 10 according to the scale to obtain an integer 50, that is, 32H in the hexadecimal form, and then transmit the following write command:

 01
 06
 01 14
 00 32
 49 E7

 Inverter address address address
 Write command address address
 Parameter data
 CRC

After receiving the command, the inverter converts 50 into 5.0 based on the fieldbus scale, and then sets "Wake-up-from-sleep delay" to 5.0s.

For another example, after the upper computer transmits the "Wake-up-from-sleep delay" parameter read command, the master receives the following response from the inverter:

<u>01</u>	<u>03</u>	<u>02</u>	<u>00 32</u>	<u>39 91</u>
Inverter	Read	2-byte	Parameter	CRC
address	command	data	data	

The parameter data is 0032H, that is, 50, so 5.0 is obtained based on the fieldbus scale (50/10=5.0). In this case, the master identifies that the "Wake-up-from-sleep delay" is 5.0s.

9.4.7 Error message response

Operation errors may occur in communication-based control. For example, some parameters can only be read, but a write command is transmitted. In this case, the inverter returns an error message response.

Error message responses are transmitted by the inverter to the master. The following table describes the codes and definitions of the error message responses.

Code	Name	Definition
01H	Invalid command	The command code received by the upper computer is not allowed to be executed. The possible causes are as follows: • The function code is applicable only on new devices and is not implemented on this device. • The slave is in the faulty state when processing this request.
02H	Invalid data address	For the inverter, the data address in the request of the upper computer is not allowed. In particular, the combination of the register address and the number of the to-be-transmitted bytes is invalid.
03H	Invalid data bit	The received data domain contains a value that is not allowed. The value indicates the error of the remaining structure in the combined request. Note: It does not mean that the data item submitted for storage in the register includes a value unexpected by the program.
04H	Operation failure	The parameter is set to an invalid value in the write operation. For example, a function input terminal cannot be set repeatedly.
05H	Password error	The password entered in the password verification address is different from that set in P03.00.
06H	Data frame error	The length of the data frame transmitted by the upper computer is incorrect, or in the RTU format, the value of the CRC check bit is inconsistent with the CRC value calculated by the lower computer

Code	Name	Definition
07H	Parameter read-only	The parameter to be modified in the write operation of the upper computer is a read-only parameter.
08H	Parameter cannot be modified in running	The parameter to be modified in the write operation of the upper computer cannot be modified during the running of the inverter.
09H	Password protection	A user password is set, and the upper computer does not provide the password to unlock the system when performing a read or write operation. The error of "system locked" is reported.

When returning a response, the device uses a function code domain and fault address to indicate whether it is a normal response (no error) or exception response (some errors occur). In a normal response, the device returns the corresponding function code and data address or sub-function code. In an exception response, the device returns a code that is equal to a normal code, but the first bit is logic 1.

For example, if the master device transmits a request message to a slave device for reading a group of function code address data, the code is generated as follows:

0 0 0 0 0 1 1 (03H in the hexadecimal form)

For a normal response, the same code is returned.

For an exception response, the following code is returned:

1 0 0 0 0 0 1 1 (83H in the hexadecimal form)

In addition to the modification of the code, the slave returns a byte of exception code that describes the cause of the exception. After receiving the exception response, the typical processing of the master device is to transmit the request message again or modify the command based on the fault information.

For example, to set the "Running command channel" (P00.01, the parameter address is 0001H) of the inverter whose address is 01H to 03, the command is as follows:

<u>01</u>	<u>06</u>	<u>00 01</u>	<u>00 03</u>	<u>98 0B</u>
Inverter address	Write command	Parameter address	Parameter data	CRC

But the setting range of the "Running command channel" is 0 to 2. The value 3 exceeds the setting range. In this case, the inverter returns an error message response as shown in the following:

<u>01</u>	<u>86</u>	<u>04</u>	<u>43 A3</u>
Inverter	Exception	Error code	CRC
address	response code	ì	

The exception response code 86H (generated based on the MSB "1" of the write command 06H) indicates that it is an exception response to the write command (06H). The error code is 04H. From

the preceding table, we can see that it indicates the error "Operation failure", which means "The parameter is set to an invalid value in the write operation".

9.4.8 Read/Write operation example

For the formats of the read and write commands, see sections 9.4.1 and 9.4.2.

9.4.8.1 Read command 03H examples

Example 1: Read state word 1 of the inverter whose address is 01H. From the table of other function parameters, we can see that the parameter address of state word 1 of the inverter is 2100H.

The read command transmitted to the inverter is as follows:

<u>01</u>	<u>03</u>	<u>21 00</u>	<u>00 01</u>	<u>8E 36</u>
Inverter address	Read command	Parameter address	Data quantity	CRC

Assume that the following response is returned:

<u>01</u>	<u>03</u>	<u>02</u>	<u>00 03</u>	<u>F8 45</u>
Inverter address	Read command	Number of bytes	Data content	CRC

The data content returned by the inverter is 0003H, which indicates that the inverter is in the stopped state.

Example 2: View information about the inverter whose address is 03H, including "Type of current fault" (P07.27) to "Type of last but four fault" (P07.32) of which the parameter addresses are 071BH to 0720H (contiguous 6 parameter addresses starting from 071BH).

The command transmitted to the inverter is as follows:

<u>03</u>	<u>03</u>	<u>07 1B</u>	<u>00 06</u>	B5 59
Inverter address	Read command	Start address	6 parameters in total	CRC

Assume that the following response is returned:

03	03 OC	00 23	00 23	00 23	00 23	00 23	00 23	5F D2
Inverter	Read Number o		Type of last fault	Type of last	Type of last but two fault	Type of last but three fault	Type of last	CRC

From the returned data, we can see that all the fault types are 0023H, that is, 35 in the decimal form, which means the maladjustment fault (STo)

9.4.8.2 Write command 06H examples

Example 1: Set the inverter whose address is 03H to be forward running. Refer to the table of other function parameters, the address of "Communication-based control command" is 2000H, and 0001H indicates forward running, as shown in the following figure.

Function	Address	Data description	R/W
	<	0001H: Forward running	
		0002H: Reverse running	
		0003H: Forward jogging	
Communication-based	2000H	0004H: Reverse jogging	DAM
control command		0005H: Stop	R/W
		0006H: Coast to stop (emergency stop)	
		0007H: Fault reset	
		0008H: Jogging to stop	

The command transmitted by the master is as follows:

<u>03</u>	<u>06</u>	<u>20 00</u>	<u>00 01</u>	<u>42 28</u>
Inverter address	Write command	Parameter address	Forward running	CRC

If the operation is successful, the following response is returned (same as the command transmitted by the master):

<u>03</u>	<u>06</u>	<u>20 00</u>	<u>00 01</u>	<u>42 28</u>
Inverter address	Write command	Parameter address	Forward running	CRC

Example 2: Set the "Max. output frequency" of the inverter whose address is 03H to 100 Hz.

Function code	Name	Detailed parameter description	Default value	Modi fy
P00.03	Max. output frequency	Used to set the maximum output frequency of the inverter. It is the basis of frequency setup and the acceleration/deceleration. Setting ranges Max (P00.04, 10.00) –630.00Hz	50.00Hz) ©

From the number of decimals, we can see that the fieldbus scale of the "Max. output frequency" (P00.03) is 100. Multiply 100 Hz by 100. The value 10000 is obtained, and it is 2710H in the hexadecimal form.

The command transmitted by the master is as follows:

<u>03</u>	<u>06</u>	<u>00 03</u>	<u>27 10</u>	<u>62 14</u>
Inverter	Write command	Parameter address	Parameter data	CRC

If the operation is successful, the following response is returned (same as the command transmitted by the master):

030600 0327 1062 14Inverter addressWrite command addressParameter dataCRC

Note: In the preceding command description, spaces are added to a command just for explanatory purposes. In practical applications, no space is required in the commands.

9.4.8.3 Continuously write command 10H examples

Example 1: Set the inverter whose address is 01H to be forward running at the frequency of 10 Hz. Refer to the table of other function parameters, the address of "Communication-based control command" is 2000H, 0001H indicates forward running, and the address of "Communication-based value setting" is 2001H, as shown in the following figure. 10 Hz is 03E8H in the hexadecimal form.

Function	Address	Data description	R/W
		0001H: Forward running	
		0002H: Reverse running	
		0003H: Forward jogging	R/W
Communication-based	000011	0004H: Reverse jogging	
control command	2000H	0005H: Stop	
		0006H: Coast to stop (emergency stop)	
		0007H: Fault reset	
		0008H: Jogging to stop	
	000411	Communication-based frequency setting (0-	
Communication-based	2001H	Fmax, unit: 0.01 Hz)	D.444
value setting	200211	PID setting, range (0–1000, 1000 corresponding	R/W
	2002H	to 100.0%)	

In the actual operation, set P00.01 to 2 and P00.06 to 8.

The command transmitted by the master is as follows:

ı	<u>01</u>	<u>10</u>	<u> 20 00</u>	<u>00 02</u>	<u>04</u>	<u>00 01</u>	<u>03 E8</u>	<u>3B 10</u>
	nverter ddress	Continuous write	Parameter address	Parameter quantity	Number of bytes	Froward running	10 Hz	CRC
		command						

If the operation is successful, the following response is returned:

<u>01</u>	<u>10</u>	<u>20 00</u>	<u>00 02</u>	<u>4A 08</u>
Inverter address	Continuous write	Parameter address	Parameter quantity	CRC
	command			

Example 2: Set "Acceleration time" of the inverter whose address is 01H to 10s, and "Deceleration time" to 20s.

Function code	Name	Detailed parameter description	Default value	Modi fy
P00.11	Acceleration time 1	Acceleration time is the time needed for accelerating from 0Hz to Max. output frequency (P00.03).	Depend on model	0
P00.12	Deceleration time 1	Deceleration time is the time needed from decelerating from Max. output frequency (P00.03) to 0Hz. Goodrive350 series inverter defines four groups of acceleration and deceleration time, which can be selected via multi-function digital input terminals (P05 group). The acceleration/deceleration time of the inverter is the first group by default. Setting range of P00.11 and P00.12: 0.0–3600.0s	Depend on model	0

The address of P00.11 is 000B, 10s is 0064H in the hexadecimal form, and 20s is 00C8H in the hexadecimal form.

The command transmitted by the master is as follows:

<u>01</u>	<u>10</u>	<u>00 0B</u>	<u>00 02</u>	<u>04</u>	<u>00 64</u>	<u>00 C8</u>	F2 55
Inverter address	Continuous write	Parameter address	Parameter quantity	Number of bytes	10s	20s	CRC
	command						

If the operation is successful, the following response is returned:

<u>01</u>	<u>10</u>	<u>00 0B</u>	<u>00 02</u>	<u>30 0A</u>
Inverter address	Continuous write	Parameter address	Parameter quantity	CRC
	command			

Note: In the preceding command description, spaces are added to a command just for explanatory purposes. In practical applications, no space is required in the commands.

9.4.8.4 Modbus communication commissioning example

A PC is used as the host, an RS232-RS485 converter is used for signal conversion, and the PC serial port used by the converter is COM1 (an RS232 port). The upper computer commissioning software is the serial port commissioning assistant Commix, which can be downloaded from the Internet. Download a version that can automatically execute the CRC check function. The following figure shows the interface of Commix.



First, set the serial port to **COM1**. Then, set the baud rate consistently with P14.01. The data bits, check bits, and end bits must be set consistently with P14.02. If the RTU mode is selected, you need to select the hexadecimal form **Input HEX**. To set the software to automatically execute the CRC function, you need to select **ModbusRTU**, select **CRC16 (MODBU SRTU)**, and set the start byte to **1**. After the auto CRC check function is enabled, do not enter CRC information in commands. Otherwise, command errors may occur due to repeated CRC check.

The commissioning command to set the inverter whose address is 03H to be forward running is as follows:

<u>03</u>	<u>06</u>	<u>20 00</u>	<u>00 01</u>	<u>42 28</u>
Inverter address	Write command	Parameter address	Forward running	CRC

Note:

- 1. Set the address (P14.00) of the inverter to 03.
- Set "Channel of running commands" (P00.01) to "Communication", and set "Communication channel of running commands" (P00.02) to the Modbus communication channel.
- Click Send. If the line configuration and settings are correct, a response transmitted by the inverter is received as follows:

<u>03</u>	<u>06</u>	<u>20 00</u>	<u>00 01</u>	<u>42 28</u>
Inverter	Write	Parameter address	Forward running	CRC

9.5 Common communication faults

Common communication faults include the following:

No response is returned.

The inverter returns an exception response.

Possible causes of no response include the following:

- The serial port is set incorrectly. For example, the converter uses the serial port COM1, but COM2 is selected for the communication.
- The settings of the baud rates, data bits, end bits, and check bits are inconsistent with those set on the inverter.
- The positive pole (+) and negative pole (-) of the RS485 bus are connected reversely.
- The resistor connected to 485 terminals on the terminal block of the inverter is set incorrectly.

Appendix A Extension cards

A.1 Model definition

Field identifier	Field description	Naming example	
1)	Product category	EC: Extension card	
2	Card category	PG: PG card PC: PLC programmable card IO: IO extension card TX: Communication extension card	
3	Technical version	Indicates the generation of a technical version by using odd numbers, for example, 1, 3, and 5 indicate the 1 st , 2 nd , and 3 rd generations of the technical version.	
4	Distinguishing code	01: Incremental PG card + frequency-divide output 02: Sine/Cosine PG card + pulse direction setting + frequency-divide output 03: UVW PG interface + pulse direction setting + frequency-divide output 04: Resolver PG interface + pulse direction setting + frequency-divide output 05: Incremental PG card + pulse direction setting + frequency-divide output 06: Absolute PG interface + pulse direction setting + frequency-divide output 07: Reserved 2	
(5)	Working power	00: Passive 05: 5V 12: 12–15 V 24: 24 V	

<u>EC</u> -	<u>PC</u>	<u>5</u>	<u>01</u>	-	<u>00</u>
\bigcirc	(2)	(3)	(4)		(5)

Field identifier	Field description	Naming example
1	Product category	EC: Extension card
2	Card category	IO: IO extension card
	Out a dategory	TX: Communication extension card

Field identifier	Field description	Naming example
		PG: PG card
		PC: PLC programmable card
3	Technical version	Indicates the generation of a technical version by using odd numbers, for example, 1, 3, and 5 indicate the 1 st , 2 nd , and 3 rd generations of the technical version.
4	Distinguishing code	01: 10 points, 6 inputs and 4 outputs (2 transistor outputs + 2 relay outputs) 02: 14 points, 8 inputs and 6 outputs (relay outputs)
		03: Reserved
5	Special requirement	Reserved

EC - TX 5 01

Field identifier	Field description	Naming example
1)	Product category	EC: Extension card
2	Card category	TX: Communication extension card PG: PG card PC: PLC programmable card IO: IO extension card
3	Technical version	Indicates the generation of a technical version by using odd numbers, for example, 1, 3, and 5 indicate the 1 st , 2 nd , and 3 rd generations of the technical version.
	Distinguishing code	01: Bluetooth communication card
		02: WIFI communication card
		03: PROFIBUS communication card
		05: Canopen communication card
(4)		06: DeviceNet communication card
4)		07: BACnet communication card
		08: EtherCat communication card
		09: PROFINET communication card
		10: Ethernet/IP communication card
		11: CAN master/slave control communication card

EC-10501-005

Field identifier	Field description	Naming example
1)	Product category	EC: Extension card
2	Card category	IO: IO extension card TX: Communication extension card PG: PG card PC: PLC programmable card
3	Technical version	Indicates the generation of a technical version by using odd numbers, for example, 1, 3, and 5 indicate the 1 st , 2 nd , and 3 rd generations of the technical version.
4	Distinguishing code	01: Multiple-function I/O extension card (4 digital inputs, 1 digital output, 1 analog input, 1 analog output, and 2 relay outputs) 02: Digital I/O card 03: Analog I/O card 04: Reserved 1 05: Reserved 2
(5)	Special requirement	

The following table describes extension cards that Goodrive350 series inverters support. The extension cards are optional and need to be purchased separately

Name	Model	Specification	
	50 10504 00		
		↑ 1 digital output	
IO extension card		↑ 1 analog input	
io extension card	EC-IO501-00	↑ 1 analog output	
		♦ 2 relay outputs: 1 double-contact output, and 1	
		single-contact output	
	EC-PC501-00	Adopting the global mainstream development	
		environment PLC, supporting multiple types of	
		programming languages, such as the instruction	
		language, structural text, function block diagram,	
		ladder diagram, continuous function chart, and	
Programmable extension card		sequential function chart	
		♦ Providing user program storage space of 128 kB,	
		and data storage space of 64 kB	
		♦ 6 digital inputs	
		♦ 2 relay outputs: 1 double-contact output, and 1	

Name	Model	Specification					
		single-contact output					
		 ♦ Supporting Bluetooth 4.0 ♦ With INVT's mobile phone APP, you can set the 					
Bluetooth communication card	EC-TX501-1 EC-TX501-2	parameters and monitor the states of the inverter through Bluetooth The maximum communication distance in open environments is 30 m. EC-TX501-1 is equipped with a built-in antenna and applicable to molded case machines. EC-TX501-2 is configured with an external sucker antenna and applicable to sheet metal machines.					
WIFI communication card	EC-TX502-1 EC-TX502-2	 ♦ Meeting IEEE802.11b/g/n ♦ With INVT's mobile phone APP, you can monitor the inverter locally or remotely through WIFI communication ♦ The maximum communication distance in open environments is 30 m. ♦ EC-TX501-1 is equipped with a built-in antenna and applicable to molded case machines. ♦ EC-TX501-2 is configured with an external sucker antenna and applicable to sheetmetal machines. 					
Ethernet communication card	EC-TX504	Supporting Ethernet communication with INVT's internal protocol Can be used in combination with INVT's upper computer monitoring software INVT Studio					
CANopen communication card	EC-TX505	 ♦ Based on the CAN2.0A physical layer ♦ Supporting the CANopen protocol 					
CAN master/slave control communication card	EC-TX511	 ♦ Based on the CAN2.0B physical layer ♦ Adopting INVT's master-slave control proprietary protocol 					
PROFIBUS-DP communication card	EC-TX503						
PROFINET communication card EC-TX509							
Multi-function incremental PG card	EC-PG505-12	 ♦ Applicable to OC encoders of 5 V or 12 V ♦ Applicable to push-pull encoders of 5 V or 12 V ♦ Applicable to differential encoders of 5 V ♦ Supporting the orthogonal input of A, B, and Z ♦ Supporting the frequency-divided output of A, B, and Z 					

Name	Model	Specification
		♦ Supporting pulse string setting
		♦ Applicable to 24V OC encoders
		♦ Applicable to 24 V push-pull encoders
24V incremental PG	FC-PG505-24	♦ Applicable to 5 V differential encoders
card	EC-PG505-24	
		♦ Supporting pulse string reference input
		♦ Applicable to differential encoders of 5 V
	EC-PG503-05	Supporting the orthogonal input of A, B, and Z
UVW incremental		
PG card		Supporting the frequency-divided output of A, B, and
		Z
		♦ Applicable to resolver encoders
Resolver PG card	EC-PG504-00	 Supporting frequency-divided output of
		resolver-simulated A, B, Z
		♦ Applicable to Sin/Cos encoders with or without CD
正余弦 PG 卡	EC-PG502	signals
Sin/Cos PG card	EU-PG302	



IO extension card EC-IO501-00



Programmable extension card EC-PC501-00



Bluetooth/WIFI communication card EC-TX501-1/502



Ethernet communication card EC-TX504



CANopen communication card EC-TX505/511



PROFIBUS-DP communication card EC-TX503



PROFINET communication card



Multi-function incremental PG card EC-PG505-12



24V incremental PG card EC-PG505-24



UVW incremental PG card EC-PG503-05



Resolver PG card EC-PG504-00



Sin/Cos PG card EC-PG502

A.2 Dimensions and installation

All extension cards are of the same dimensions (108 mm \times 39 mm) and can be installed in the same way.

Following the following operation principles when installing or removing an extension card:

1. Ensure that no power is applied before installing the extension card.

- 2. The extension card can be installed in any one of the SLOT1, SLOT2, and SLOT3 card slots.
- 3. Inverters of 5.5 kW or lower can be configured with two extension cards at the same time, and those of 7.5 kW or higher can be configured with three extension cards.
- 4. If interference occurs on the external wires after extension cards are installed, change their installation card slots flexibly to facilitate the wiring. For example, the connector of the connection cable of the DP card is large, so it is recommended to be installed in the SLOT1 card slot.
- 5. To ensure high anti-interference capability in closed-loop control, you need to use a shielding wire in the encoder cable and ground the two ends of the shielding wire, that is, connect the shielding layer to the housing of the motor on the motor side, and connect the shielding layer to the PE terminal on the PG card side.

Fig A.1 shows the installation diagram and an inverter with extension cards installed.




Fig A.1 Inverter of 7.5 kW or higher with extension cards installed




Fig A.2 Inverter of 5.5 kW or lower with extension cards installed

Extension card installation process:




Fig A.3 Extension card installation process diagram

A.3 Wiring

1. Ground a shielded cable as follows:




Fig A.4 Extension card grounding diagram

2. Wire an extension card as follows:





Fig A.5 Extension card wiring

A.4 IO extension card function description

A.4.1 IO extension card—EC-IO501-00



The terminals are arranged as follows:

CME and COM are shorted through J3 before delivery, and J5 is the jumper for selecting the output type (voltage or current) of AO2.

Al3	AO2	GND
-----	-----	-----

COM	CME	Y2	S5	
PW	+24V	S6	S7	S8

RO3A	4	RO3B		RC		
	R	O4A			RO	4C

Indicator definition

Indicator No.	Definition	Function
LED1	State indicator	This indicator is on when the extension card is establishing a connection with the control board; it blinks periodically after the extension card is properly connected to the control board (the period is 1s, on for 0.5s, and off for the other 0.5s); and it is off when the extension card is disconnected from the control board.
LED4	Power indicator	This indicator is on after the IO extension card is powered on by the control board.

The EC-IO501-00 extension card can be used in scenarios where the I/O interfaces of a Goodrive350 inverter cannot meet the application requirements. It can provide 4 digital inputs, 1 digital output, 1 analog input, 1 analog output, and two relay outputs. It is user-friendly, providing relay outputs through European-type screw terminals and other inputs and outputs through spring terminals.


EC-IO501-00 terminal function description

Category	Label	Name	Function description			
Power	PW	External power supply	The working power of digital input is provided by an external power supply. Voltage range: 12–24 V The terminals PW and +24V are shorted before delivery.			
Analog input/output	Al3—GND	Analog input 1	 Input range: 0–10 V, 0–20 mA Input impedance: 20 kΩ for voltage input; Ω for current input Set it to be voltage or current input through the corresponding function code. Resolution: When 10 V corresponds to 50 Hz, the minimum resolution is 5 mV. Deviation:±0.5%; input of 5 V or 10 mA or higher at the temperature of 25°C 			
	AO2—GND	Analog output 1	Output range: 0–10 V, 0–20 mA Whether it is voltage or current output is determined by J5.			

Category	Label	Name	Function description				
			3. Deviation ±0.5%; input of 5 V or 10 mA or				
			higher at the temperature of 25°C				
	S5—COM	Digital input 1	1. Internal impedance: 3.3 kΩ				
	S6—COM	Digital input 2	2. Power input range: 12–30 V				
Digital	S7—COM	Digital input 3	3. Bidirectional input terminal				
	S8—COM	Digital input 4	4. Max. input frequency: 1 kHz				
input/output			1. Switch capacity: 200 mA/30 V				
	Y2—CME	District autout	2. Output frequency range: 0–1 kHz				
		Digital output	3. The terminals CME and COM are				
			shorted through J3 before delivery.				
	R03A	NO contact of					
	RUSA	relay 3					
	R03B	NC contact of					
	KUSB	relay 3	1. Contact capacity: 3A/AC 250 V, 1 A/DC				
Relay	R03C	Common contact	30 V				
output	RUSC	of relay 3	2. Do not use them as high-frequency				
	R04A	NO contact of	digital outputs.				
	KU4A	relay 4					
	R04C	Common contact					
	KU4C	of relay 4					

A.5 PG extension card function description

A.5.1 Multi-function incremental PG card—EC-PG505-12



The terminals are arranged as follows:

The dual in-line package (DIP) switch SW1 is used to set the voltage class (5 V or 12 V) of the power supply of the encoder. The DIP switch can be operated with an auxiliary tool.

PE	AO+	BO+	ZO+	A1+	B1+	Z1+	A2+	B2+	Z2+	PWR
GND	AO-	ВО-	ZO-	A1-	B1-	Z1-	A2-	B2-	Z2-	PGND


Indicator No.	Definition	Function
LED1	State indicator	This indicator is on when the extension card is establishing a connection with the control board; it blinks periodically after the extension card is properly connected to the control board (the period is 1s, on for 0.5s, and off for the other 0.5s); and it is off when the extension card is disconnected from the control board.
LED2 Disconnection indicator		This indicator is off when A1 and B1 of the encoder is disconnected; and it is on when the pulses are normal.
LED3	Power indicator	This indicator is on after the control board feeds power to the PG card.

The EC-PG505-12 extension card can be used in combination with multiple types of incremental encoders through different modes of wiring. It is user-friendly, adopting spring terminals.


EC-PG505-12 terminal function description

Label	Name	Function description			
PWR		Voltage: 5 V/12 V ±5%			
PGND	Encoder power	Max. output: 150 mA Select the voltage class through the DIP switch SW1 based on the voltage class of the used encoder.			
A1+					
A1-		1. Supporting push-pull interfaces of 5 V/12 V			
B1+		2. Supporting open collector interfaces of 5 V/12 V			
B1-	Encoder interface	3. Supporting differential interfaces of 5 V			
Z1+		4. Response frequency: 200 kHz			
Z1-					
A2+					
A2-					
B2+	5 1	Supporting the same signal types as the			
B2-	Pulse setting	encoder signal types			
Z2+		2. Response frequency: 200 kHz			
Z2-					
AO+					
AO-		4.5%			
BO+	Frequency-divided	1. Differential output of 5 V			
ВО-	output	2. Supporting frequency division of 1–255, which			
ZO+		can be set through P20.16 or P24.16			
ZO-					


The following figure shows the external wiring of the extension card used in combination with an open collector encoder. A pull-up resistor is configured inside the PG card.




The following figure shows the external wiring of the extension card used in combination with a push-pull encoder.



The following figure shows the external wiring of the extension card used in combination with a differential encoder.



A.5.2 UVW incremental PG card—EC-PG503-05



The terminals are arranged as follows:

					A2+	A2-	B2+	B2-	Z2+	Z2-
PE	AO+	BO+	ZO+	A1+	B1+	Z1+	U+	V+	W+	PWR
GND	AO-	ВО-	ZO-	A1-	B1-	Z1-	U-	V-	W-	PGND

Indicator definition

Indicator No.	Definition	Function
LED1	State indicator	This indicator is on when the extension card is establishing a connection with the control board; it blinks periodically after the extension card is properly connected to the control board (the period is 1s, on for 0.5s, and off for the other 0.5s); and it is off when the extension card is disconnected from the control board.
LED2	Disconnection indicator	This indicator is off when A1 and B1 of the encoder is disconnected; and it is on when the pulses are normal.
LED3	Power indicator	This indicator is on after the control board feeds power to the PG card.


The EC-PG503-05 extension card supports the input of absolute position signals and integrates the advantages of absolute and incremental encoders. It is user-friendly, adopting spring terminals.

EC-PG503-05 terminal function description


Label	Name	Function description		
PWR	Franks names	Voltage: 5 V±5%		
PGND	Encoder power	Max. current: 200 mA		
A1+				
A1-				
B1+	Encodor interface	Differential incremental PG interface of 5 V		
B1-	Encoder interface	2. Response frequency: 400 kHz		
Z1+				
Z1-				
A2+				
A2-				
B2+	Dula a assista	1. Differential input of 5 V		
B2-	Pulse setting	2. Response frequency: 200 kHz		
Z2+				
Z2-				
AO+	Frequency-divided	1. Differential output of 5 V		
AO-	output	2. Supporting frequency division of 1–255, which		

Label	Name	Function description
BO+		can be set through P20.16 or P24.16
BO-		
ZO+		
ZO-		
U+		
U-		
V+	UVW encoder interface	1. Absolute position (UVW information) of the
V-		hybrid encoder, differential input of 5 V 2. Response frequency: 40 kHz
W+		2. Response nequency. 40 MHz
W-		

The following figure shows the external wiring of the EC-PG503-05 extension card.



A.5.3 Resolver PG card—EC-PG504-00



Indicator definition

PΕ

GND

Indicator No.	Definition	Function
LED1	State indicator	This indicator is on when the extension card is establishing a connection with the control board; it blinks periodically after the extension card is properly connected to the control board (the period is 1s, on for 0.5s, and off for the other 0.5s); and it is off when the extension card is disconnected from the control board.
LED2	Disconnection indicator	This indicator is off when the encoder is disconnected; it is on when the encoder signals are normal; and it blinks when the encoder signals are not stable.
LED3	Power indicator	This indicator is on after the control board feeds power to the PG card.


The EC-PG504-00 extension card can be used in combination with a resolver of excitation voltage 7 Vrms. It is user-friendly, adopting spring terminals.

EC-PG504-00 terminal function description


Label	Name	Function description		
SI+				
SI-				
CO+	Encoder signal input	Recommended resolver transformation ratio: 0.5		
CO-				
EX+	For and an assistation	1. Factory setting of excitation: 10 kHz		
EX-	Encoder excitation signal	Supporting resolvers with an excitation voltage of 7 Vrms		
A2+	Pulse setting	1. Differential input of 5 V		

Label	Name	Function description
A2-		2. Response frequency: 200 kHz
B2+		
B2-		
Z2+		
Z2-		
AO+		1. Differential output of 5 V
AO-	Frequency-divided output	Frequency-divided output of resolver simulated
BO+		A1, B1, and Z1, which is equal to an incremental
BO-		PG card of 1024 pps.
ZO+		3. Supporting frequency division of 1–255, which
ZO-		can be set through P20.16 or P24.16 4. Max. output frequency: 200 kHz

The following figure shows the external wiring of the EC-PG504-00 extension card.



A5.4 24 V multi-function incremental PG card——EC-PG505-24



The terminals are arranged as follows:

PE	AO	ВО	A1+	B1+	Z1+	A2+	B2+	Z2+	PWR
GND	AGND	ZO	A1-	B1-	Z1-	A2-	B2-	Z2-	AGND

Definitions of indicators

Indicator No.	Definition	Function
LED1	State indicator	This indicator is on when the extension card is establishing a connection with the control board; it blinks periodically after the extension card is properly connected to the control board (the period is 1s, on for 0.5s, and off for the other 0.5s); and it is off when the extension card is disconnected from the control board.
LED2	Disconnection indicator	This indicator is off when A1 and B1 of the encoder are disconnected; it is on when the encoder pulses are normal; and it blinks when an exception occurs in the communication between the encoder and control board.
LED3	Power indicator	This indicator is on after the control board feeds power to the PG card.


EC-PG505-24 can work in combination with multiple types of incremental encoders through various external wiring modes. It is user-friendly, adopting spring terminals.

EC-PG505-24 terminal function description


Label	Name	Function description
PWR	Encoder power	Voltage: 24 V ± 5%
PGND	supply	Max. output current: 150 mA
A1+		
A1-		4.0
B1+	Encoder interface	1. Supporting 24 V push-pull interfaces
B1-		2. Supporting 24 V open collector interfaces
Z1+		3. Frequency response: 200 kHz
Z1-		

Label	Name	Function description
A2+		
A2-		
B2+	Pulse reference	Supporting interfaces whose signal type is the
B2-		same as the encoder
Z2+		2. Frequency response: 200 kHz
Z2-		
AO		Open-drain collector output
во	Frequency-divided	2. Supporting frequency division of 1–255, which
ZO	output	can be set through P20.16 or P24.16


The following figure shows the external wiring of the PG card when it is used in combination with an open-drain collector encoder. A pull-up resistor is configured in the PG card.



The following figure shows the external wiring of the PG card when it is used in combination with a push-pull encoder.



A5.5 Sin/Cos PG card——EC-PG502



The terminals are arrange as follows:

PE	AO+	BO+	ZO+	A1+	B1+	Z1+	A2+	B2+	Z2+	PWR
GND	AO-	во-	ZO-	A1-	B1-	Z1-	A2-	B2-	Z2-	GND
			•		•	•	C1+	C1-	D1+	D1-

Definitions of indicators


Indicator No.	Definition	Function
LED1	State indicator	This indicator is on when the extension card is establishing a connection with the control board; it blinks periodically after the extension card is properly connected to the control board (the period is 1s, on for 0.5s, and off for the other 0.5s); and it is off when the extension card is disconnected from the control

Indicator No.	Definition	Function
		board.
LED2	Power indicator	This indicator is on after the control board feeds power to the PG card.
LED3	Disconnection indicator	This indicator is off when A1 and B1 of the encoder are disconnected; it blinks when C1 and D1 of the encoder are disconnected; and it is on the encoder signals are normal.


EC-PG502 terminal function description

Label	Name	Function description
PWR	Fd	Voltage: 5 V ± 5%
PGND	Encoder power	Max. output current: 150 mA
A1+		
A1-		
B1+		
B1-		1. Supporting Sin/Cos encoders
R1+	Encoder interface	2. SINA/SINB/SINC/SIND 0.6–1.2Vpp; SINR 0.2–
R1-	Encoder Interrace	0.85Vpp
C1+		Max. frequency response of A/B signals: 200 kHz Max. frequency response of C/D signals: 1 kHz
C1-		Max. frequency response of G/D signals. TkHz
D1+		
D1-		
A2+		
A2-		
B2+	Pulse reference	Supporting interfaces whose signal type is the
B2-	Pulse reference	same as the encoder
Z2+		2. Frequency response: 200 kHz
Z2-		
AO+		
AO-		1. Differential output of 5 V
BO+	Frequency-divided	2. Supporting frequency division of 2 ^N , which can be
BO-	output	set through P20.16 or P24.16; Max. output
ZO+		frequency: 200 kHz
ZO-		

The following figure shows the external wiring of the PG card when it is used in combination with an encoder without CD signals.



The following figure shows the external wiring of the PG card when it is used in combination with an encoder with CD signals.



A.6 Communication card function description

A.6.1 Bluetooth communication card—EC-TX501 and WIFI communication card—EC-TX502




Definitions of indicators and function buttons:

Indicator No.	Definition	Function
LED1/LED3	Bluetooth/WIFI state indicator	LED1 is on when the extension card is establishing a connection with the control board; LED1 blinks periodically after the extension card is properly connected to the control board (the period is 1s, on for 0.5s, and off for the other 0.5s); and LED1 is off when the extension card is disconnected from the control board.
LED2	Bluetooth communication state indicator	This indicator is on when Bluetooth communication is online and data exchange can be performed. It is off when Bluetooth communication is not in the online state.
LED5	Power indicator	This indicator is on after the control board feeds power to the Bluetooth card.
SW1	WIFI factory reset button	It is restored to default values and returned to the local monitoring mode.
SW2	WIFI hardware reset button	It is used to reboot the extension card.

The wireless communication card is especially useful for scenarios where you cannot directly use the keypad to operate the inverter due to the restriction of the installation space. With a mobile phone APP, you can operate the inverter in a maximum distance of 30 m. You can choose a PCB antenna or an external sucker antenna. If the inverter is located in an open space and is a molded case machine, you can use a built-in PCB antenna; and if it is a sheetmetal machine and located in a metal cabinet, you need to use an external sucker antenna.


When installing a sucker antenna, install a wireless communication card on the inverter first, and then lead the SMA connector of the sucker antenna into the inverter and screw it to CN2, as shown in the following figure. Place the antenna base on the chassis and expose the upper part. Try to keep it unblocked.



The wireless communication card must be used with the INVT Inverter APP. Scan the QR code of the inverter nameplate to download it. For details, refer to the wireless communication card manual provided with the extension card. The main interface is shown as follows.



A.6.2 CANopen communication card—EC-TX505 and CAN master/slave control communication card EC-TX511



The EC-TX505 communication card is user-friendly, adopting spring terminals.

3-pin spring terminal	Pin	Function	Description
1 2 3	1	CANH	CANopen bus high level signal
	2	CANG	CANopen bus shielding
	3	CANL	CANopen bus low level signal

Terminal resistor switch function description


Terminal resistor switch	Position	Function	Description
	1.04	eft OFF	CAN_H and CAN_L are not
	Left		connected to a terminal resistor.
	D	ON	CAN_H and CAN_L are connected to
	Right		a terminal resistor of 120 Ω.

Indicator No.	Definition	Function
		This indicator is on when the extension card is
		establishing a connection with the control board;
		it blinks periodically after the extension card is
LED1	State indicator	properly connected to the control board (the
		period is 1s, on for 0.5s, and off for the other
		0.5s); and it is off when the extension card is
		disconnected from the control board.
LED4	Power indicator	This indicator is on after the control board feeds
LED4	Power indicator	power to the communication card.
		This indicator is on when the communication
LED5	Running indicator	card is in the working state.
		It is off when a fault occurs. Check whether the
		reset pin of the communication card and the
		power supply are properly connected.

Indicator No.	Definition	Function
		It blinks when the communication card is in the
		pre-operation state.
		It blinks once when the communication card is in
		the stopped state.
		This indicator is on when the CAN controller bus
		is off or a fault occurs on the inverter.
		It is off when the communication card is in the
LED6	Error indicator	working state.
		It blinks when the address setting is incorrect.
		It blinks once when a received frame is missed
		or an error occurs during frame receiving.

For details about the operation, see the *Goodrive350 Series Inverter Communication Extension Card Operation Manual*.


A.6.3 Ethernet communication card—EC-TX504




The EC-TX504 communication card adopts standard RJ45 terminals.

Indicator No.	Definition	Function
	State indicator	This indicator is on when the extension card is
		establishing a connection with the control board;
LED1		it blinks periodically after the extension card is
		properly connected to the control board (the
		period is 1s, on for 0.5s, and off for the other
		0.5s); and it is off when the extension card is
		disconnected from the control board.
LED4	Power indicator	This indicator is on after the control board feeds
		power to the communication card.

A.6.4 PROFIBUS-DP communication card—EC-TX503



CN1 is a 9-pin D-type connector, as shown in the following figure.



Connector pin		Description
1	-	Unused
2	-	Unused
3	B-Line	Data+ (twisted pair 1)
4	RTS	Request sending
5	GND_BUS	Isolation ground
6	+5V BUS	Isolated power supply of 5 V DC
7	-	Unused
8	A-Line	Data- (twisted pair 2)
9	-	Unused
Housing	SHLD	PROFIBUS cable shielding line

+5V and GND_BUS are bus terminators. Some devices, such as the optical transceiver (RS485), may need to obtain power through these pins.


On some devices, the transmission and receiving directions are determined by RTS. In normal applications, only A-Line, B-Line, and the shield layer need to be used.

Indicator No.	Definition	Function
LED1	State indicator	This indicator is on when the extension card is establishing a connection with the control board; it blinks periodically after the extension card is properly connected to the control board (the
		period is 1s, on for 0.5s, and off for the other

Indicator No.	Definition	Function
		0.5s); and it is off when the extension card is
		disconnected from the control board.
		This indicator is on when the communication
		card is online and data exchange can be
LED2	Online indicator	performed.
		It is off when the communication card is not in
		the online state.
		This indicator is on when the communication
		card is offline and data exchange cannot be
		performed.
		It blinks when the communication card is not in
		the offline state.
		It blinks at the frequency of 1 Hz when a
		configuration error occurs: The length of the user
	Offline/Fault indicator	parameter data set during the initialization of the
		communication card is different from that during
LED3		the network configuration.
		It blinks at the frequency of 2 Hz when user
		parameter data is incorrect: The length or
		content of the user parameter data set during
		the initialization of the communication card is
		different from that during the network
		configuration.
		It blinks at the frequency of 4 Hz when an error
		occurs in the ASIC initialization of PROFIBUS
		communication.
		It is off when the diagnosis function is disabled.
LED4	Power indicator	This indicator is on after the control board feeds
	i ower maleator	power to the communication card.

For details about the operation, see the *Goodrive350 Series Inverter Communication Extension Card Operation Manual.*

A.6.5 PROFINET communication card—EC- TX509



The terminal CN2 adopts a standard RJ45 interface, where CN2 is the dual RJ45 interface, and these two RJ45 interfaces are not distinguished from each other and can be interchangeably inserted. They are arranged as follows:

Pin	Name	Description
1	n/c	Not connected
2	n/c	Not connected
3	RX-	Receive Data-
4	n/c	Not connected
5	n/c	Not connected
6	RX+	Receive Data+
7	TX-	Transmit Data-
8	TX+	Transmit Data+

Definition of the state indicator


The PROFINET communication card has 9 indicators, of which LED1 is the power indicator, LED2–5 are the communication state indicators of the communication card, and LED6–9 are the state indicators of the network port.

LED	Color	State	Description
LED1	Green		3.3V power indicator
		On	No network connection
			The connection to the network cable
LED2		Dlinkin	between the Profinet controller is OK,
	Red	Blinking	but the communication is not
(Bus state indicator)			established.
		Off	Communication with the Profinet
		Oil	controller has been established
LED3	Craan	On	Profinet diagnosis exists
(System fault indicator)	Green	Off	No Profinet diagnosis
1504	Green	On	TPS-1 protocol stack has started
LED4		Blinking	TPS-1 waits for MCU initialization
(Slave ready indicator)		Off	TPS-1 protocol stack does not start
LED5			Manufacturer-specific - depending on
(Maintenance state	Green		the characteristics of the device
indicator)			the characteristics of the device
			PROFINET communication card and
LED6/7		On	PC/PLC have been connected via a
(Network port state	Green		network cable
indicator)	indicator)		PROFINET communication card and
		Off	PC/PLC have not been connected yet
LED8/9	Green	Blinking	PROFINET communication card and

LED	Color	State Description	
(Network port		PC/PLC are communicating	
communication		0"	PROFINET communication card and
indicator)		Off	PC/PLC are not yet communicating

Electrical connection:


The Profinet communication card adopts a standard RJ45 interface, which can be used in a linear network topology and a star network topology. The linear network topology electrical connection diagram is shown below.



Linear network topology electrical connection diagram


Note: For the star network topology, users need to prepare Profinet switches.

The star network topology electrical connection diagram is shown below:



A.7 Programmable extension card function description

A.7.1 Programmable extension card—EC-PC501-00



The terminals are arranged as follows:

SW1 is the start/stop switch of the programmable extension card. CN6 is the program download port,

and you can connect to a computer by using a standard USB cable. COM and CME are shorted through J1 before delivery.

PY1	PY2	CME	COM
-----	-----	-----	-----

COM	PS1	PS2	PS3	
PW	+24V	PS4	PS5	PS6

PRO1A F		PRO1B	PRO1C	
	PRO2	Α		PRO2C

Indicator definition

Indicator No.	Definition	Function
LED3	State indicator	This indicator is on when the extension card is establishing a connection with the control board; it blinks periodically after the extension card is properly connected to the control board (the period is 1s, on for 0.5s, and off for the other 0.5s); and it is off when the extension card is disconnected from the control board.
LED4	PLC running state indicator	This indicator is on when the DIP switch is turned to RUN (run the PLC); and it is off when the switch is turned to STOP (stop the PLC).
LED5	Power indicator	This indicator is on after the control board feeds power to the communication card.

The EC-PC501-00 programmable extension card can replace some micro PLC applications. It adopts the global mainstream development environment PLC, supporting six types of programming languages, namely the instruction language (IL), structural text (ST), function block diagram (FBD), ladder diagram (LD), continuous function chart (CFC), and sequential function chart (SFC). It provides a user program storage space of 128 kB and data storage space of 64 kB, which facilitates customers' secondary development and meets the customization requirements.

The EC-PC501-00 programmable extension card provides 6 digital inputs, 2 digital outputs, and 2 relay outputs. It is user-friendly, providing relay outputs through European-type screw terminals and other inputs and outputs through spring terminals.

EC-PC501-00 terminal function description

Category	Label	Name	Function description	
Power	PW	External power	The working power of digital input is provided by an external power supply. Voltage range: 12–24 V The terminals PW and +24V are shorted before delivery.	
Digital	PS1—COM	Digital input 1	1. Internal impedance: 3.3 kΩ	
input/output	PS2—COM	Digital input 2	2. Allowable voltage input: 12–30 V	

Category	Label	Name	Function description
	PS3—COM	Digital input 3	3. Bidirectional terminal
	PS4—COM	Digital input 4	4. Max. input frequency: 1 kHz
	PS5—COM	Digital input 5	
	PS6—COM	Digital input 6	
	PY1—CME	Digital output 1	1. Switch capacity: 200 mA/30 V
			2. Output frequency range: 0-1 kHz
	PY2—CME	Digital output 2	3. The terminals CME and COM are
			shorted through J1 before delivery.
	PR01A	NO contact of	
	FRUIA	relay 1	
	PR01B	NC contact of	
	FRUID	relay 1	1. Contact capacity: 3A/AC 250 V, 1 A/DC
Relay	PR01C	Common contact	30 V
output	PROTE	of relay 1	2. Do not use them as high-frequency
	PR02A	NO contact of	digital outputs.
	PRUZA	relay 2	
	PR02C	Common contact	
	FRU2C	of relay 2	

For details about the operation of programmable extension cards, see the *Goodrive350 Series Inverter Communication Extension Card Operation Manual*.

Appendix B Technical data

B.1 What this chapter contains

This chapter describes the technical data of the inverter and its compliance to CE and other quality certification systems.

B.2 Derated application

B.2.1 Capacity

Choose an inverter based on the rated current and power of the motor. To endure the rated power of the motor, the rated output current of the inverter must be larger or equal to the rated current of the motor. The rated power of the inverter must be higher or equal to that of the motor.

Note:


- The maximum allowable shaft power of the motor is limited to 1.5 times the rated power of the motor. If the limit is exceeded, the inverter automatically restricts the torque and current of the motor. This function effectively protect the input shaft against overload.
- 2. The rated capacity is the capacity at the ambient temperature of 40°C.
- You need to check and ensure that the power flowing through the common DC connection in the common DC system does not exceed the rated power of the motor.

B.2.2 Derating

If the ambient temperature on the site where the inverter is installed exceeds 40°C, the altitude exceeds 1000 m, or the switching frequency is changed from 4 kHz to 8, 12, or 15 kHz, the inverter needs to be derated.

B.2.2.1 Derating due to temperature


When the temperature ranges from +40°C to +50°C, the rated output current is derated by 1% for each increased 1°C. For the actual derating, see the following figure.



Note: It is not recommended to use the inverter at a temperature higher than 50°C. If you do, you shall be held accountable for the consequences caused.

B.2.2.2 Derating due to altitude

When the altitude of the site where the inverter is installed is lower than 1000 m, the inverter can run at the rated power. If the altitude is higher than 1000 m, the allowable output power is derated. For details about the derating, see the following figure.



B.2.2.3 Derating due to carrier frequency

The power of Goodrive350 series inverters varies according to carrier frequencies. The rated power of an inverter is defined based on the carrier frequency set in factory. If the carrier frequency exceeds the factory setting, the power of the inverter is derated by 10% for each increased 1 kHz.

B.3 Grid specifications

Cuid voltage	AC 3PH 380V (-15%)-440V (+10%)
Grid voltage	AC 3PH 520V (-15%)-690V (+10%)
	According to the definition in IEC 60439-1, the maximum allowable
	short-circuit current at the incoming end is 100 kA. Therefore, the
Short-circuit capacity	inverter is applicable to scenarios where the transmitted current in
	the circuit is no larger than 100 kA when the inverter runs at the
	maximum rated voltage.
Frequency	50/60 Hz±5%, with a maximum change rate of 20%/s

B.4 Motor connection data

Motor type	asynchronous induction motor or permanent-magnet synchronous motor		
Voltage	0–U1 (rated voltage of the motor), 3PH symmetrical, Umax (rated voltage of the inverter) at the field-weakening point		
Short-circuit protection	The short-circuit protection for the motor output meets the requirements of IEC 61800-5-1.		
Frequency	0–400 Hz		
Frequency resolution	0.01 Hz		
Current	See the rated current.		
Power limit	1.5 times of the rated power of the motor		
Field-weakening point	10–400 Hz		
Carrier frequency	4, 8, 12, or 15 kHz		

B.4.1 EMC compatibility and motor cable length

The following table describes the maximum motor cable lengths that meet the requirements of the EU EMC directive (2004/108/EC) when the carrier frequency is 4 kHz.

All models (with external EMC filters)	Maximum motor cable length (m)
Environment category II (C3)	30
Environment category I (C2)	30

You can learn the maximum length of the motor cable through the running parameters of the inverter. To understand the accurate maximum cable length for using an external EMC filter, contact the local INVT office.

For description about the environments categories I (C2) and II (C3), see section "EMC regulations".

B.5 Application standards

The following table describes the standards that the inverters comply with.

EN/ISO 13849-1:2008	Safety of machinery—Safety-related parts of control systems—Part 1: General principles for design
IEC/EN 60204-1:2006	Safety of machinery—Electrical equipment of machines. Part 1: General requirements
IEC/EN 62061:2005	Safety of machinery—Safety-related functional safety of electrical, electronic, and programmable electronic control systems
IEC/EN 61800-3:2004	Adjustable speed electrical power drive systems—Part 3:EMC requirements and specific test methods
IEC/EN	Adjustable speed electrical power drive systems—Part 5-1: Safety
61800-5-1:2007	requirements—Electrical, thermal and energy
IEC/EN	Adjustable speed electrical power drive systems—Part 5-2: Safety
61800-5-2:2007	requirements—Function

B.5.1 CE marking

The CE marking on the name plate of an inverter indicates that the inverter is CE-compliant, meeting the regulations of the European low-voltage directive (2006/95/EC) and EMC directive (2004/108/EC).

B.5.2 EMC compliance declaration

European union (EU) stipulates that the electric and electrical devices sold in Europe cannot generate electromagnetic disturbance that exceeds the limits stipulated in related standards, and can work properly in environments with certain electromagnetic interference. The EMC product standard (EN 61800-3:2004) describes the EMC standards and specific test methods for adjustable speed electrical power drive systems. Products must strictly follow these EMC regulations.

B.6 EMC regulations

The EMC product standard (EN 61800-3:2004) describes the EMC requirements on inverters.

Application environment categories

Category I: Civilian environments, including application scenarios where inverters are directly connected to the civil power supply low-voltage grids without intermediate transformers

Category II: All environments except those in Category I.

Inverter categories

C1: Rated voltage lower than 1000 V, applied to environments of Category I.

C2: Rated voltage lower than 1000 V, non-plug, socket, or mobile devices; power drive systems that must be installed and operated by specialized personnel when applied to environments of Category I

Note: The EMC standard IEC/EN 61800-3 no longer restricts the power distribution of inverters, but it specifies their use, installation, and commissioning. Specialized personnel or organizations must have the necessary skills (including the EMC-related knowledge) for installing and/or performing commissioning on the electrical drive systems.

C3: Rated voltage lower than 1000 V, applied to environments of Category II. They cannot be applied to environments of Category I.

C4: Rated voltage higher than 1000 V, or rated current higher or equal to 400 A, applied to complex systems in environments of Category II.

B.6.1 Inverter category of C2

The induction disturbance limit meets the following stipulations:

- Select an optional EMC filter according to Appendix D and install it following the description in the EMC filter manual.
- 2. Select the motor and control cables according to the description in the manual.
- 3. Install the inverter according to the description in the manual.
- 4. For the maximum length of the motor cable when the switching frequency is 4 kHz, see section "EMC compatibility and motor cable length".



Currently in environments in China, the inverter may generate radio interference, you need to take measures to reduce the interference.

B.6.2 Inverter category of C3

The anti-interference performance of the inverter meets the requirements of environments Category II in the IEC/EN 61800-3 standard.

The induction disturbance limit meets the following stipulations:

- Select an optional EMC filter according to Appendix D and install it following the description in the EMC filter manual.
- 2. Select the motor and control cables according to the description in the manual.
- 3. Install the inverter according to the description in the manual.
- For the maximum length of the motor cable when the switching frequency is 4 kHz, see section "EMC compatibility and motor cable length".



Inverters of C3 category cannot be applied to civilian low-voltage common grids. When applied to such grids, the inverter may generate radio frequency electromagnetic interference.

Appendix C Dimension drawings

C.1 What this chapter contains

This chapter describes the dimension drawings of Goodrive350 series inverters. The dimension unit used in the drawings is mm.

C.2 Keypad structure

C.2.1 Structure diagram




Fig C.1 Keypad structure diagram

C.2.2 Keypad installation bracket

Note: When installing an external keypad, you can directly use threaded screws or a keypad bracket. For inverters of 380 V, 1.5 to 75 kW, you need to use optional keypad installation brackets. For those of 380 V, 90 to 500 kW and 660 V, 22 to 630 kW, you can use optional brackets or use the standard keypad brackets externally.




Fig C.2 Keypad installation bracket (optional) for inverters of 380 V, 1.5 to 500 kW and 660 V, 22 to 630 kW

C.3 Inverter structure




Fig C.3 Inverter structure diagram

C.4 Dimensions of Inverters of AC 3PH 380V (-15%)-440V (+10%)

C.4.1 Wall-mounting dimensions




Fig C.4 Wall-mounting diagram of inverters of 380 V, 1.5 to 37 kW




Fig C.5 Wall-mounting diagram of inverters of 380 V, 45 to 75 kW




Fig C.6 Wall-mounting diagram of inverters of 380 V, 90 to 110 kW




Fig C.7 Wall-mounting diagram of inverters of 380 V, 132 to 200 kW -321-




Fig C.8 Wall-mounting diagram of inverters of 380 V, 220 to 315 kW

Table C.1 Wall-mounting dimensions of 380 V inverters (unit: mm)

Inverter specification	W 1	W2	W3	H1	H2	D1	Installation hole diameter	Fixing screw
1.5kW-2.2kW	126	115	ı	186	175	185	5	M4
4kW-5.5kW	126	115	1	186	175	201	5	M4
7.5kW	146	131	ı	256	243.5	192	6	M5
11kW-15kW	170	151	ı	320	303.5	220	6	M5
18.5kW-22kW	200	185	-	340.6	328.6	208	6	M5
30kW-37kW	250	230	-	400	380	223	6	M5
45kW-75kW	282	160	226	560	542	258	9	M8
90kW-110kW	338	200	-	554	535	330	10	M8
132kW– 200kW	500	180	1	870	850	360	11	M10
220kW- 315kW	680	230	-	960	926	380	13	M12

C.4.2 Flange installation dimensions




Fig C.9 Flange installation diagram of inverters of 380 V, 1.5 to 75 kW




Fig C.10 Flange installation diagram of inverters of 380 V, 90 to 110 kW




Fig C.11 Flange installation diagram of inverters of 380 V, 132 to 200 kW

Table C.2 Flange installation dimensions of 380 V inverters (unit: mm)

Inverter specification	W1	W2	W3	W4	H1	H2	Н3	H4	D1	D2	Installation hole	Fixing screw
specification											diameter	
1.5kW-2.2kW	150.2	115	130	7.5	234	220	190	13.5	185	65.5	5	M4
4kW-5.5kW	150.2	115	130	7.5	234	220	190	13.5	201	83	5	M4
7.5kW	170.2	131	150	9.5	292	276	260	6	192	84.5	6	M5
11kW-15kW	191.2	151	174	11.5	370	351	324	12	220	113	6	M5
18.5kW-22kW	266	250	224	13	371	250	350.6	20.3	208	104	6	M5
30kW-37kW	316	300	274	13	430	300	410	55	223	118.3	6	M5
45kW-75kW	352	332	306	12	580	400	570	80	258	133.8	9	M8
90kW-110kW	418.5	389.5	361	14.2	600	370	559	108.5	330	149.5	10	M8
132kW-200kW	500	180	480	60	870	850	796	37	360	178.5	11	M10

C.4.3 Floor installation dimensions




Fig C.12 Floor installation diagram of inverters of 380 V, 220 to 315 kW




Fig C.13 Floor installation diagram of inverters of 380 V, 355 to 500 kW

Table C.3 Floor installation dimensions of 380 V inverters (unit: mm)

Inverter specification	W1	W2	W3	W4	H1	H2	D1	D2	Installation hole diameter	Fixing screw
220kW-315kW	750	230	714	680	1410	1390	380	150	13\12	M12/M10
355kW-500kW	620	230	572	-	1700	1678	560	240	22\12	M20/M10

C.5 Dimensions of Inverters of AC 3PH 520V (-15%)-690V (+10%)

C.5.1 Wall-mounting dimensions




Fig C.14 Wall-mounting diagram of inverters of 660 V, 22 to 132 kW



Fig C.16 Wall-mounting diagram of inverters of 660 V, 250 to 355 kW

Table C.4 Wall-mounting dimensions of 660 V inverters (unit: mm)

Inverter specification	W 1	W2	H1	H2	D1	Installation hole diameter	Fixing screw
22kW-45kW	270	130	555	540	325	7	M6
55kW-132kW	325	200	680	661	365	9.5	M8
160kW-220kW	500	180	870	850	360	11	M10
250kW-355kW	680	230	960	926	380	13	M12

C.5.2 Flange installation dimensions




Fig C.17 Flange installation diagram of inverters of 660 V, 22 to 132 kW




Fig C.18 Flange installation diagram of inverters of 660 V, 160 to 220 kW

Table C.5 Flange installation dimensions of 660 V inverters (unit: mm)

Inverter specification	W1	W2	W3	W4	H1	H2	НЗ	Н4	D1	D2	Installation hole diameter	Fixing screw
22kW-45kW	270	130	261	65.5	555	540	516	17	325	167	7	M6
55kW-132kW	325	200	317	58.5	680	661	626	23	363	182	9.5	M8
160kW-220kW	500	180	480	60	870	850	796	37	358	178.5	11	M10

C.5.3 Floor installation dimensions




Fig C.19 Floor installation diagram of inverters of 660 V, 250 to 355 kW




Fig C.20 Floor installation diagram of inverters of 660 V, 400 to 630 kW

Table C.6 Floor installation dimensions of 660 V inverters (unit: mm)

Inverter specification	W 1	W2	W3	W4	H1	H2	D1	D2	Installation hole diameter	Fixing screw
250kW-355kW	750	230	714	680	1410	1390	380	150	13\12	M12/M10
400kW-630kW	620	230	572	\	1700	1678	560	240	22\12	M20/M10


Appendix D Optional peripheral accessories

D.1 What this chapter contains

This chapter describes how to select optional accessories of Goodrive350 series inverters.

D.2 Wiring of peripheral accessories

The following figure shows the external wiring of a Goodrive350 series inverter.



Note:

- 1. Inverters of 380 V, 37 kW or lower are equipped with built-in brake units, and inverters of 45 kW to 110 kW can be configured with optional built-in brake units.
- 2. Inverters of 380 V, 18.5 kW to 110 kW are equipped with built-in DC reactors.
- P1 terminals are equipped only for inverters of 380 V, 132 kW or higher, which enable the inverters to be directly connected to external DC reactors.
- P1 terminals are equipped for all inverters of the 660 V series or higher, which enable the inverters to be directly connected to external DC reactors.
- The brake units INVT's DBU series standard brake units. For details, see the DBU operation manual.

Image	Name	Description
	Cable	Accessory for signal transmission
EET Verti	Breaker	Device for electric shock prevention and protection against short-to-ground that may cause current leakage and fire. Select residual-current circuit breakers (RCCBs) that are applicable to inverters and can restrict high-order harmonics, and of which the rated sensitive current for one inverter is larger than 30 mA.
	Input reactor	Accessories used to improve the current
	DC reactor	adjustment coefficient on the input side of the inverter, and thus restrict high-order harmonic currents. Inverters of 380 V, 132 kW or higher and 660 V series can be directly connected to external DC reactors.
600	Input filter	Accessory that restricts the electromagnetic interference generated by the inverter and transmitted to the public grid through the power cable. Try to install the input filter near the input terminal side of the inverter.
or O	Brake unit or brake resistor	Accessories used to consume the regenerative energy of the motor to reduce the deceleration time. Inverters of 380 V, 37 kW or lower need only to be configured with brake resistors, those of 380V, 132 kW or higher and 660 V series also need to be configured with brake units, and those of 380V, 45 kW to 110 kW can be configured with optional built-in brake units.
500	Output filter	Accessory used to restrict interference generated in the wiring area on the output side of the inverter. Try to install the output filter near the output terminal side of the inverter.
	Output reactor	Accessory used to lengthen the valid transmission distance of the inverter, which effectively restrict the transient high voltage generated during the switch-on and

Image	Name	Description
		switch-off of the IGBT module of the inverter.

D.3 Power supply

Refer to the electrical installation.



Ensure that the voltage class of the inverter is consistent with that of the grid.

D.4 Cables


D.4.1 Power cables

The sizes of the input power cables and motor cables must meet the local regulation.

- The input power cables and motor cables must be able to carry the corresponding load currents.
- The maximum temperature margin of the motor cables in continuous operation cannot be lower than 70°C.
- The conductivity of the PE grounding conductor is the same as that of the phase conductor, that
 is, the cross-sectional areas are the same.
- For details about the EMC requirements, see Appendix B "Technical data."

To meet the EMC requirements stipulated in the CE standards, you must use symmetrical shielded cables as motor cables (as shown in the following figure).


Four-core cables can be used as input cables, but symmetrical shielded cables are recommended. Compared with four-core cables, symmetrical shielded cables can reduce electromagnetic radiation as well as the current and loss of the motor cables.



Note: If the conductivity of the shield layer of the motor cables cannot meet the requirements, separate PE conductors must be used.

To protect the conductors, the cross-sectional area of the shielded cables must be the same as that of the phase conductors if the cable and conductor are made of materials of the same type. This reduces grounding resistance, and thus improves impedance continuity.


To effectively restrict the emission and conduction of radio frequency (RF) interference, the conductivity of the shielded cable must at least be 1/10 of the conductivity of the phase conductor. This requirement can be well met by a copper or aluminium shield layer. The following figure shows the minimum requirement on motor cables of an inverter. The cable must consist of a layer of spiral-shaped copper strips. The denser the shield layer is, the more effectively the electromagnetic interference is restricted.



Cross-section of the cable

D.4.2 Control cables

All analog control cables and cables used for frequency input must be shielded cables. Analog signal cables need to be double-shielded twisted-pair cables (as shown in figure a). Use one separate shielded twisted pair for each signal. Do not use the same ground wire for different analog signals.



Power cable arrangement

For low-voltage digital signals, double-shielded cables are recommended, but shielded or unshielded twisted pairs (as shown in figure b) also can be used. For frequency signals, however, only shielded cables can be used.

Relay cables need to be those with metal braided shield layers.

Keypads need to be connected by using network cables. In complicated electromagnetic environments, shielded network cables are recommended.

Note: Analog signals and digital signals cannot use the same cables, and their cables must be arranged separately.

Do not perform any voltage endurance or insulation resistance tests, such as high-voltage insulation tests or using a megameter to measure the insulation resistance, on the inverter or its components. Insulation and voltage endurance tests have been performed between the main circuit and chassis of each inverter before delivery. In addition, voltage limiting circuits that can automatically cut off the test voltage are configured inside the inverters.

Note: Check the insulation conditions of the input power cable of an inverter according to the local regulations before connecting it.

D.4.2.1 AC 3PH 380V (-15%)-440V (+10%)

	Recomm		Size o	of connecta	ble cable (r	nm²)	Terminal	Tighten
Inverter model	cable siz	e (mm²)	0120) sidus sid	····· <i>,</i>	screw	ing
involtor inouor	RST	PE	RST	P1, (+)	PB, (+), (-)	PE	specifica	•
	UVW		UVW	, ()	, (), ()		tion	(Nm)
GD350-1R5G-4	2.5	2.5	2.5–6	2.5–6	2.5–6	2.5–6	M4	1.2–1.5
GD350-2R2G-4	2.5	2.5	2.5–6	2.5–6	2.5–6	2.5–6	M4	1.2–1.5
GD350-004G-4	2.5	2.5	2.5–6	2.5–6	2.5–6	2.5–6	M4	1.2–1.5
GD350-5R5G-4	2.5	2.5	2.5–6	2.5–6	2.5–6	2.5–6	M4	1.2–1.5
GD350-7R5G-4	4	4	2.5–6	4–6	4–6	2.5–6	M4	1.2–1.5
GD350-011G-4	6	6	4–10	4–10	4–10	4–10	M5	2.3
GD350-015G-4	6	6	4–10	4–10	4–10	4–10	M5	2.3
GD350-018G-4	10	10	10–16	10–16	10–16	10–16	M5	2.3
GD350-022G-4	16	16	10–16	10–16	10–16	10–16	M5	2.3
GD350-030G-4	25	16	25–50	25–50	25–50	16–25	M6	2.5
GD350-037G-4	25	16	25–50	25–50	25–50	16–25	M6	2.5
GD350-045G-4	35	16	35–70	35–70	35–70	16–35	M8	10
GD350-055G-4	50	25	35–70	35–70	35–70	16–35	M8	10
GD350-075G-4	70	35	35–70	35–70	35–70	16–35	M8	10
GD350-090G-4	95	50	70–120	70–120	70–120	50–70	M12	35
GD350-110G-4	120	70	70–120	70–120	70–120	50–70	M12	35
GD350-132G-4	185	95	95–300	95–300	95–300	95–240		
GD350-160G-4	240	120	95–300	95–300	95–300	120–240		
GD350-185G-4	95×2P	95	95–150	70–150	70–150	35–95		
GD350-200G-4	95×2P	120	95×2P	95×2P	95×2P	120–240		
GD330-200G-4	9082F	120	-150×2P	-150×2P	-150x2P	120-240	Nuts are	
GD350-220G-4	150×2P	150	95×2P –	95×2P –	95×2P –	150–240	terminals	
	.00/12		150×2P	150×2P	150×2P		recommer you use a	
GD350-250G-4	95×4P	95×2P	95×4P	95×4P	95×4P	95×2P	or sle	
			-150×4P	-150×4P	-150×4P	-150×2P	0. 0.0	0.0.
GD350-280G-4	95×4P	95×2P	95×4P	95×4P	95×4P	95×2P		
			-150x4P 95x4P	-150×4P 95×4P	-150×4P 95×4P	-150×2P 95×2P		
GD350-315G-4	95×4P	95×4P	-150×4P	-150×4P	-150×4P	-150×2P		
OD050 0555 :	05 15	05 :5	95×4P	95×4P	95×4P	95×2P		
GD350-355G-4	95×4P	95×4P	-150×4P	-150×4P	-150×4P	-150×2P		

	Recomn		Size o	f connecta	ble cable (n	nm²)	Terminal screw	Tighten ing
Inverter model	RST UVW	PE	RST UVW	P1, (+)	PB, (+), (-)	PE	specifica tion	torque (Nm)
GD350-400G-4	150×4P	150×2P	95×4P –150×4P	95×4P –150×4P	95×4P -150×4P	95×2P –150×2P		
GD350-450G-4	150*4P	150*2P	95×4P -150×4P	95×4P -150×4P	95×4P -150×4P	95×2P -150×2P		
GD350-500G-4	150×4P	150×2P	95×4P -150×4P	95×4P -150×4P	95×4P -150×4P	95×2P -150×2P		

- Cables of the sizes recommended for the main circuit can be used in scenarios where the ambient temperature is lower than 40°C, the wiring distance is shorter than 100 m, and the current is the rated current.
- 2. The terminals P1, (+), and (-) are used to connect to DC reactors and brake accessories.

D.4.2.2 AC 3PH 520V (-15%)-690V (+10%)

Inverter model	Recommon cable (mi	size		connect	able cabl	e (mm²)	Terminal screw	Tightening torque	
	RST UVW	PE	RST UVW	P1, (+)	PB, (+), (-)	PE	specification	(Nm)	
GD350-022G-6	10	10	10–16	6–16	6–10	10–16	M8	9–11	
GD350-030G-6	10	10	10–16	6–16	6–10	10–16	M8	9–11	
GD350-037G-6	16	16	16–25	16–25	6–10	16–25	M8	9–11	
GD350-045G-6	16	16	16–25	16–35	16–25	16–25	M8	9–11	
GD350-055G-6	25	16	16–25	16–35	16–25	16–25	M10	18–23	
GD350-075G-6	35	16	35–50	25–50	25–50	16–50	M10	18–23	
GD350-090G-6	35	16	35–50	25–50	25–50	16–50	M10	18–23	
GD350-110G-6	50	25	50–95	50-95	25–95	25–95	M10	18–23	
GD350-132G-6	70	35	70–95	70–95	25–95	35–95	M10	18–23	
GD350-160G-6	95	50	95–150	95–150	25–150	50–150			
GD350-185G-6	95	50	95–150	95–150	25–150	50–150	Nuts are u	used as	
GD350-200G-6	120	70	120–300	120-300	35–300	70–240	terminals	so it is	
GD350-220G-6	185	95	120–300	120-300	35–300	95–240	recommende	ed that you	
GD350-250G-6	185	95	185–300	185–300	35–300	95–240	use a wrench or sleev		
GD350-280G-6	240	120	240–300	240–300	70–300	120–240			

Inverter model	cable			connect	able cable	e (mm²)	Terminal screw	Tightening torque
	RST UVW	PE	RST UVW	P1, (+)	PB, (+), (-)	PE	specification	(Nm)
GD350-315G-6	95×2P	120	95×2P- 150×2P		95×2P –150×2P	120–300		
GD350-355G-6	95×2P	150	95×2P- 150×2P	95×2P –150×2P	95×2P –150×2P	150–300		
GD350-400G-6	150×2P	150	150×2P- 300×2P		95×2P –150×2P	150–300		
GD350-450G-6	95×4P	95×2P	95×4P –150×4P	95×4P –150×4P	95×4P –150×4P	95×2P –150×2P		
GD350-500G-6	95×4P	95×2P	95×4P –150×4P	95×4P –150×4P	95×4P –150×4P	95×2P –150×2P		
GD350-560G-6	95×4P	95×4P	95×4P –150×4P	95×4P –150×4P	95×4P –150×4P	95×4P –150×4P		
GD350-630G-6	150×4P	150×2P	150×4P –300×4P	150×4P –300×4P	150×4P –300×4P	150×4P –240×4P		

- Cables of the sizes recommended for the main circuit can be used in scenarios where the ambient temperature is lower than 40°C, the wiring distance is shorter than 100 m, and the current is the rated current
- 2. The terminals P1, (+), and (-) are used to connect to DC reactors and brake accessories.


D.4.3 Cable arrangement

Motor cables must be arranged away from other cables. The motor cables of several inverters can be arranged in parallel. It is recommended that you arrange the motor cables, input power cables, and control cables separately in different trays. The output dU/dt of the inverters may increase electromagnetic interference on other cables. Do not arrange other cables and the motor cables in parallel.

If a control cable and power cable must cross each other, ensure that the angle between them is 90 degrees.

The cable trays must be connected properly and well grounded. Aluminum trays can implement local equipotential.

The following figure shows the cable arrangement distance requirements.



Cable arrangement distances

D.4.4 Insulation inspection

Check the motor and the insulation conditions of the motor cable before running the motor.

- Ensure that the motor cable is connected to the motor, and then remove the motor cable from the U, V, and W output terminals of the inverter.
- Use a megameter of 500 V DC to measure the insulation resistance between each phase conductor and the protection grounding conductor. For details about the insulation resistance of the motor, see the description provided by the manufacturer.

Note: The insulation resistance is reduced if it is damp inside the motor. If it may be damp, you need to dry the motor and then measure the insulation resistance again.

D.5 Breaker and electromagnetic contactor

You need to add a fuse to prevent overload.

You need to configure a manually manipulated molded case circuit breaker (MCCB) between the AC power supply and inverter. The breaker must be locked in the open state to facilitate installation and inspection. The capacity of the breaker needs to be 1.5 to 2 times the rated current of the inverter.



According to the working principle and structure of breakers, if the manufacturer's regulation is not followed, hot ionized gases may escape from the breaker enclosure when a short-circuit occurs. To ensure safe use, exercise extra caution when installing and placing the breaker. Follow the manufacturer's instructions.

To ensure safety, you can configure an electromagnetic contactor on the input side to control the switch-on and switch-off of the main circuit power, so that the input power supply of the inverter can be effectively cut off when a system fault occurs.

D.5.1 Breakers and electromagnetic contactors for AC 3PH 380V (-15%)-440V (+10%)

Inverter model	Fuse (A	Breaker (A)	Rated current of the contactor (A)
GD350-1R5G-4	1	16	10
GD350-2R2G-4	17.4	16	10
GD350-004G-4	30	25	16
GD350-5R5G-4	45	25	16
GD350-7R5G-4	60	40	25

Inverter model	Fuse (A	Breaker (A)	Rated current of the contactor (A)
GD350-011G-4	78	63	32
GD350-015G-4	105	63	50
GD350-018G-4	114	100	63
GD350-022G-4	138	100	80
GD350-030G-4	186	125	95
GD350-037G-4	228	160	120
GD350-045G-4	270	200	135
GD350-055G-4	315	200	170
GD350-075G-4	420	250	230
GD350-090G-4	480	315	280
GD350-110G-4	630	400	315
GD350-132G-4	720	400	380
GD350-160G-4	870	630	450
GD350-185G-4	1110	630	580
GD350-200G-4	1110	630	580
GD350-220G-4	1230	800	630
GD350-250G-4	1380	800	700
GD350-280G-4	1500	1000	780
GD350-315G-4	1740	1200	900
GD350-355G-4	1860	1280	960
GD350-400G-4	2010	1380	1035
GD350-450G-4	2445	1630	1222
GD350-500G-4	2505	1720	1290

Note: The accessory specifications described in the preceding table are ideal values. You can select accessories based on the actual market conditions, but try not to use those with lower values.

D.5.2 Breakers and electromagnetic contactors for AC 3PH 520V (-15%)-690V (+10%)

Inverter model	Fuse (A	Breaker (A)	Rated current of the contactor (A)
GD350-022G-6	105	63	50
GD350-030G-6	105	63	50
GD350-037G-6	114	100	63
GD350-045G-6	138	100	80
GD350-055G-6	186	125	95
GD350-075G-6	270	200	135
GD350-090G-6	270	200	135
GD350-110G-6	315	200	170
GD350-132G-6	420	250	230

Inverter model	Fuse (A	Breaker (A)	Rated current of the contactor (A)
GD350-160G-6	480	315	280
GD350-185G-6	480	315	280
GD350-200G-6	630	400	315
GD350-220G-6	720	400	380
GD350-250G-6	720	400	380
GD350-280G-6	870	630	450
GD350-315G-6	1110	630	580
GD350-350G-6	1110	630	580
GD350-400G-6	1230	800	630
GD350-450G-6	1470	960	735
GD350-500G-6	1500	1000	780
GD350-560G-6	1740	1200	900
GD350-630G-6	2010	1380	1035


Note: The accessory specifications described in the preceding table are ideal values. You can select accessories based on the actual market conditions, but try not to use those with lower values.

D.6 Reactors

When the voltage of the grid is high, the transient large current that flows into the input power circuit may damage rectifier components. You need to configure an AC reactor on the input side, which can also improve the current adjustment coefficient on the input side.

When the distance between the inverter and motor is longer than 50 m, the parasitic capacitance between the long cable and ground may cause large leakage current, and overcurrent protection of the inverter may be frequently triggered. To prevent this from happening and avoid damage to the motor insulator, compensation must be made by adding an output reactor. When an inverter is used to drive multiple motors, take the total length of the motor cables (that is, sum of the lengths of the motor cables) into account. When the total length is longer than 50 m, an output reactor must be added on the output side of the inverter. If the distance between the inverter and motor is 50 m to 100 m, select the reactor according to the following table. If the distance is longer than 100 m, contact INVT's technical support technicians.

DC reactors can be directly connected to inverters of 380 V, 132 kW or higher and the 660 V series. DC reactors can improve the power factor, avoid damage to bridge rectifiers caused due to large input current of the inverter when large-capacity transformers are connected, and also avoid damage to the rectification circuit caused due to harmonics generated by grid voltage transients or phase-control loads.



D.6.1 Reactors for AC 3PH 380V (-15%)-440V (+10%)

Inverter model	Input reactor	DC reactor	Output reactor
GD350-1R5G-4	ACL2-1R5-4	/	OCL2-1R5-4
GD350-2R2G-4	ACL2-2R2-4	/	OCL2-2R2-4
GD350-004G-4	ACL2-004-4	/	OCL2-004-4
GD350-5R5G-4	ACL2-5R5-4	/	OCL2-5R5-4
GD350-7R5G-4	ACL2-7R5-4	/	OCL2-7R5-4
GD350-011G-4	ACL2-011-4	/	OCL2-011-4
GD350-015G-4	ACL2-015-4	/	OCL2-015-4
GD350-018G-4	ACL2-018-4	/	OCL2-018-4
GD350-022G-4	ACL2-022-4	/	OCL2-022-4
GD350-030G-4	ACL2-037-4	/	OCL2-037-4
GD350-037G-4	ACL2-037-4	/	OCL2-037-4
GD350-045G-4	ACL2-045-4	/	OCL2-045-4
GD350-055G-4	ACL2-055-4	/	OCL2-055-4
GD350-075G-4	ACL2-075-4	/	OCL2-075-4
GD350-090G-4	ACL2-0110-4	/	OCL2-110-4
GD350-110G-4	ACL2-110-4	/	OCL2-110-4
GD350-132G-4	ACL2-160-4	DCL2-132-4	OCL2-200-4
GD350-160G-4	ACL2-160-4	DCL2-160-4	OCL2-200-4
GD350-185G-4	ACL2-200-4	DCL2-200-4	OCL2-200-4
GD350-200G-4	ACL2-200-4	DCL2-220-4	OCL2-200-4
GD350-220G-4	ACL2-280-4	DCL2-280-4	OCL2-280-4
GD350-250G-4	ACL2-280-4	DCL2-280-4	OCL2-280-4
GD350-280G-4	ACL2-280-4	DCL2-280-4	OCL2-280-4
GD350-315G-4	ACL2-350-4	DCL2-315-4	OCL2-350-4
GD350-350G-4	Standard	DCL2-400-4	OCL2-350-4
GD350-400G-4	Standard	DCL2-400-4	OCL2-400-4

Inverter model	Input reactor	DC reactor	Output reactor
GD350-450G-4	Standard	DCL2-500-4	OCL2-500-4
GD350-500G-4	Standard	DCL2-500-4	OCL2-500-4

- 1. The rated input voltage drop of input reactors is 2%±15%.
- The current adjustment coefficient on the input side of the inverter is higher than 90% after a DC reactor is configured.
- 3. The rated output voltage drop of output reactors is 1%±15%.
- The preceding table describes external accessories. You need to specify the ones you choose when purchasing accessories.

D.6.2 Reactors for AC 3PH 520V (-15%)-690V (+10%)

Inverter model	Input reactor	DC reactor	Output reactor
GD350-022G-6	ACL2-030G-6	DCL2-030G-6	OCL2-030G-6
GD350-030G-6	ACL2-030G-6	DCL2-030G-6	OCL2-030G-6
GD350-037G-6	ACL2-055G-6	DCL2-055G-6	OCL2-055G-6
GD350-045G-6	ACL2-055G-6	DCL2-055G-6	OCL2-055G-6
GD350-055G-6	ACL2-055G-6	DCL2-055G-6	OCL2-055G-6
GD350-075G-6	ACL2-110G-6	DCL2110G-6	OCL2-110G-6
GD350-090G-6	ACL2-110G-6	DCL2-110G-6	OCL2-110G-6
GD350-110G-6	ACL2-110G-6	DCL2-110G-6	OCL2-110G-6
GD350-132G-6	ACL2-185G-6	DCL2-185G-6	OCL2-185G-6
GD350-160G-6	ACL2-185G-6	DCL2-185G-6	OCL2-185G-6
GD350-185G-6	ACL2-185G-6	DCL2-185G-6	OCL2-185G-6
GD350-200G-6	ACL2-250G-6	DCL2-250G-6	OCL2-250G-6
GD350-220G-6	ACL2-250G-6	DCL2-250G-6	OCL2-250G-6
GD350-250G-6	ACL2-250G-6	DCL2-250G-6	OCL2-250G-6
GD350-280G-6	ACL2-350G-6	DCL2-350G-6	OCL2-350G-6
GD350-315G-6	ACL2-350G-6	DCL2-350G-6	OCL2-350G-6
GD350-350G-6	ACL2-350G-6	DCL2-350G-6	OCL2-350G-6
GD350-400G-6	Standard	DCL2-400G-6	OCL2-400G-6
GD350-450G-6	Standard	DCL2-560G-6	OCL2-560G-6
GD350-500G-6	Standard	DCL2-560G-6	OCL2-560G-6
GD350-560G-6	Standard	DCL2-560G-6	OCL2-560G-6
GD350-630G-6	Standard	DCL2-630G-6	OCL2-630G-6

Note:

- 1. The rated input voltage drop of input reactors is 2%±15%.
- The current adjustment coefficient on the input side of the inverter is higher than 90% after a DC reactor is configured.

- 3. The rated output voltage drop of output reactors is 1%±15%.
- The preceding table describes external accessories. You need to specify the ones you choose when purchasing accessories.

D.7 Filters


J10 is not connected in factory for inverters of 380V (≤ 110kW). Connect the J10 packaged with the manual if the requirements of level C3 need to be met:

J10 is connected in factory for inverters of 380V (≥ 132kW), all of which meet the requirements of level C3

Note:

Disconnect J10 in the following situations:

- The EMC filter is applicable to the neutral-grounded grid system. If it is used for the IT grid system (that is, non-neutral grounded grid system), disconnect J10.
- If leakage protection occurs during configuration of a residual-current circuit breaker, disconnect J10.




Note: Do not connect C3 filters in IT power systems.

Interference filters on the input side can reduce the interference of inverters (when used) on the surrounding devices.

Noise filters on the output side can decrease the radio noise caused by the cables between inverters and motors and the leakage current of conducting wires.

INVT provides some of the filters for users to choose.

D.7.1 Filter model description



Field identifier	Field description	
Α	FLT: Name of the inverter filter series	

Field identifier	Field description	
	Filter type	
В	P: Power input filter	
	L: Output filter	
	Voltage class	
С	04: AC 3PH 380V (-15%)-440V (+10%)	
	06: AC 3PH 520V (-15%)-690V (+10%)	
D	3-digit code indicating the rated current. For example, 015 indicates	
U	15 A.	
	Filter performance	
Е	L: General	
	H: High-performance	
	Filter application environment	
_	A: Environment Category I, C1 (EN 61800-3:2004)	
F	B: Environment Category I, C2 (EN 61800-3:2004)	
	C: Environment Category II, C3 (EN 61800-3:2004)	

D.7.2 Filters for AC 3PH 380V (-15%)-440V (+10%)

Inverter model	Input filter	Output filter	
GD350-1R5G-4	ELT D0 400CL D	FLT-L04006L-B	
GD350-2R2G-4	FLT-P04006L-B	FL1-L04006L-B	
GD350-004G-4	FLT-P04016L-B	FLT-L04016L-B	
GD350-5R5G-4	FLI-P04016L-B	FL1-L04016L-B	
GD350-7R5G-4	FLT-P04032L-B	FLT-L04032L-B	
GD350-011G-4	FL1-P04032L-B	FLI-LU4U32L-B	
GD350-015G-4	FLT D04045L D	FIT LOADAFL D	
GD350-018G-4	FLT-P04045L-B	FLT-L04045L-B	
GD350-022G-4	FLT DO ACCEL D	FIT LOADOFL D	
GD350-030G-4	FLT-P04065L-B	FLT-L04065L-B	
GD350-037G-4	FLT-P04100L-B	FLT-L04100L-B	
GD350-045G-4	FL1-P04100L-B		
GD350-055G-4	FLT-P04150L-B	FLT-L04150L-B	
GD350-075G-4	FLI-F04130L-B	FLI-L04130L-B	
GD350-090G-4			
GD350-110G-4	FLT-P04240L-B	FLT-L04240L-B	
GD350-132G-4			
GD350-160G-4			
GD350-185G-4	FLT-P04400L-B	FLT-L04400L-B	
GD350-200G-4			
GD350-220G-4	ELT D0.4600L B	FLT L 04600L B	
GD350-250G-4	FLT-P04600L-B	FLT-L04600L-B	

Inverter model	Input filter	Output filter
GD350-280G-4		
GD350-315G-4		
GD350-350G-4	FLT-P04800L-B	FLT-L04800L-B
GD350-400G-4		
GD350-450G-4	FI T D0440001 D	FIT L 0.44.000L B
GD350-500G-4	FLT-P041000L-B	FLT-L041000L-B

- 1. The input EMI meets the C2 requirements after an input filter is configured.
- The preceding table describes external accessories. You need to specify the ones you choose when purchasing accessories.

D.7.3 Filters for AC 3PH 520V (-15%)-690V (+10%)

Inverter model	Input filter	Output filter	
GD350-022G-6			
GD350-030G-6	FLT-P06050H-B	FLT-L06050H-B	
GD350-037G-6			
GD350-045G-6			
GD350-055G-6	FLT-P06100H-B	FLT-L06100H-B	
GD350-075G-6	FLI-P06100H-B	FL1-L06100H-B	
GD350-090G-6			
GD350-110G-6			
GD350-132G-6	FLT DOCCOOLL D	FLT-L06200H-B	
GD350-160G-6	FLT-P06200H-B		
GD350-185G-6			
GD350-200G-6	ELT DOGGOODL D		
GD350-220G-6		FLT-L06300H-B	
GD350-250G-6	FLT-P06300H-B	FLI-LU6300H-B	
GD350-280G-6			
GD350-315G-6	FLT-P06400H-B	FLT-L06400H-B	
GD350-350G-6	FLI-PU0400M-B	FLI-LU0400H-B	
GD350-400G-6			
GD350-450G-6	FLT-P061000H-B		
GD350-500G-6		FLT-P061000H-B	
GD350-560G-6			
GD350-630G-6			

Note:

1. The input EMI meets the C2 requirements after an input filter is configured.

The preceding table describes external accessories. You need to specify the ones you choose when purchasing accessories.

D.8 Brake system

D.8.1 Brake component selection

When an inverter driving a high-inertia load decelerates or needs to decelerate abruptly, the motor runs in the power generation state and transmits the load-carrying energy to the DC circuit of the inverter, causing the bus voltage of the inverter to rise. If the bus voltage exceeds a specific value, the inverter reports an overvoltage fault. To prevent this from happening, you need to configure brake components.

	The design, installation, commissioning, and operation of the device must be performed by trained and qualified professionals.					
	Follow all the "Warning" instructions during the operation. Otherwise, major physical injuries or property loss may be caused.					
A	♦ Only qualified electricians are allowed to perform the wiring. Otherwise,					
4	damage to the inverter or brake components may be caused.					
	♦ Read the brake resistor or unit instructions carefully before connecting them					
	to the inverter.					
	♦ Connect brake resistors only to the terminals PB and (+), and brake units					
	only to the terminals (+) and (-). Do not connect them to other terminals.					
	Otherwise, damage to the brake circuit and inverter and fire may be caused.					
	♦ Connect the brake components to the inverter according to the wiring					
<u> </u>	diagram. If the wiring is not properly performed, damage to the inverter or					
	other devices may be caused.					

D.8.1.1 Brake units for AC 3PH 380V (-15%)-440V (+10%)

Goodrive350 series inverters of 380 V, 37 kW or lower are equipped with built-in brake units, and those of 380 V, 45 kW or higher need to be configured with external brake units. Inverters of 45 kW to 110 kW can be configured with optional built-in brake units, and after a built-in brake unit is configured, the inverter model is added with a suffix "-B", for example, GD350-045G-4-B. Select brake resistors according to the specific requirements (such as the brake torque and brake usage requirements) on site.

Inverter model	Brake unit model	Resistance applicable for 100% brake	power of brake resistor (kW)	power of brake resistor (kW)	Dissipated power of brake resistor (kW) 80% brake usage	Min. allowable brake resistance
GD350-1R5G-4	Desilation benefits assist	326	0.23	1.1	1.8	170
GD350-2R2G-4	Built-in brake unit	222	0.33	1.7	2.6	130

Inverter model	Brake unit model		power of brake resistor (kW) 10% brake usage	power of brake resistor (kW) 50% brake usage	Dissipated power of brake resistor (kW) 80% brake usage	Min. allowable brake resistance (Ω)
GD350-004G-4		122	0.6	3	4.8	80
GD350-5R5G-4		89	0.75	4.1	6.6	60
GD350-7R5G-4		65	1.1	5.6	9	47
GD350-011G-4	-	44	1.7	8.3	13.2	31
GD350-015G-4	-	32	2	11	18	23
GD350-018G-4	-	27	3	14	22	19
GD350-022G-4	-	22	3	17	26	17
GD350-030G-4		17	5	23	36	17
GD350-037G-4		13	6	28	44	11.7
GD350-045G-4		10	7	34	54	
GD350-055G-4	DBU100H-110-4	8	8	41	66	6.4
GD350-075G-4		6.5	11	56	90	
GD350-090G-4	DBU100H-160-4	5.4	14	68	108	4.4
GD350-110G-4		4.5	17	83	132	
GD350-132G-4	DBU100H-220-4	3.7	20	99	158	3.2
GD350-160G-4		3.1	24	120	192	
GD350-185G-4	DBU100H-320-4	2.8	28	139	222	2.2
GD350-200G-4		2.5	30	150	240	
GD350-220G-4	DBU100H-400-4	2.2	33	165	264	1.8
GD350-250G-4	230100114004	2.0	38	188	300	1.0
GD350-280G-4		3.6×2	21×2	105×2	168×2	
GD350-315G-4	Two sets	3.2×2	24×2	118×2	189×2	2.2×2
GD350-355G-4	DBU100H-320-4	2.8×2	27×2	132×2	210×2	2.2.
GD350-400G-4		2.4×2	30×2	150×2	240×2	
GD350-450G-4	Two sets	2.2×2	34×2	168×2	270×2	1.8×2
GD350-500G-4	DBU100H-400-4	2.0×2	38×2	186×2	300×2	1.0×2

- 1. Select brake resistors according to the resistance and power data provided by our company.
- 2. The brake resistor may increase the brake torque of the inverter. The preceding table describes the resistance and power for 100% brake torque, 10% brake usage, 50% brake usage, and 80% brake usage. You can select the brake system based on the actual operation conditions.
- When using an external brake unit, set the brake voltage class of the brake unit properly by referring to the manual of the dynamic brake unit. If the voltage class is set incorrectly, the inverter may not run properly.



Do not use brake resistors whose resistance is lower than the specified minimum resistance. Inverters do not provide protection against overcurrent caused by resistors with low resistance.



In scenarios where brake is frequently implemented, that is, the brake usage is greater than 10%, you need to select a brake resistor with higher power as required by the operation conditions according to the preceding table.

D.8.1.2 Brake units for AC 3PH 520V (-15%)-690V (+10%)

External brake units need to be configured for Goodrive350 series inverters of 660 V. Select brake resistors according to the specific requirements (such as the brake torque and brake usage requirements) on site.

Inverter model	Brake unit model	Resistance applicable for 100% brake torque (Ω)	brake resistor (kW)	power of brake resistor (kW)	power of brake resistor (kW)	Min. allowable brake resistance
GD350-022G-6		55	4	17	27	
GD350-030G-6		40.3	5	23	36	
GD350-037G-6		32.7	6	28	44	
GD350-045G-6	DBU100H-110-6	26.9	7	34	54	10.0
GD350-055G-6	DBU100H-110-6	22.0	8	41	66	10.0
GD350-075G-6		16.1	11	56	90	
GD350-090G-6		13.4	14	68	108	
GD350-110G-6		11.0	17	83	132	
GD350-132G-6	DD1140011 400 0	9.2	20	99	158	0.0
GD350-160G-6	DBU100H-160-6	7.6	24	120	192	6.9
GD350-185G-6		6.5	28	139	222	
GD350-200G-6	DBU100H-220-6	6.1	30	150	240	5.0
GD350-220G-6		5.5	33	165	264	

Inverter model	Brake unit model	Resistance applicable for 100% brake torque (Ω)	power of brake resistor (kW)	power of brake resistor (kW)		Min. allowable brake resistance
GD350-250G-6		4.8	38	188	300	
GD350-280G-6	DD1140011 000 0	4.3	42	210	336	0.4
GD350-315G-6	DBU100H-320-6	3.8	47	236	378	3.4
GD350-355G-6		3.5	53	263	420	
GD350-400G-6	DBU100H-400-6	3.0	60	300	480	2.8
GD350-450G-6		5.5×2	34×2	168×2	270×2	
GD350-500G-6	Two sets	4.8×2	38×2	188×2	300×2	2.40
GD350-560G-6	DBU100H-320-6	4.3×2	42×2	210×2	336×2	3.4×2
GD350-630G-6		3.8×2	47×2	236×2	378×2	

- 1. Select brake resistors according to the resistance and power data provided by our company.
- The brake resistor may increase the brake torque of the inverter. The preceding table describes the resistance and power for 100% brake torque, 10% brake usage, 50% brake usage, and 80% brake usage. You can select the brake system based on the actual operation conditions.
- When using an external brake unit, set the brake voltage class of the brake unit properly by referring to the manual of the dynamic brake unit. If the voltage class is set incorrectly, the inverter may not run properly.



Do not use brake resistors whose resistance is lower than the specified minimum resistance. Inverters do not provide protection against overcurrent caused by resistors with low resistance.



In scenarios where brake is frequently implemented, that is, the brake usage is greater than 10%, you need to select a brake resistor with higher power as required by the operation conditions according to the preceding table.

D.8.2 Brake resistor cable selection

Brake resistor cables need to be shielded cables.

D.8.3 Brake resistor installation

All resistors need to be installed in places with good cooling conditions.




The materials near the brake resistor or brake unit must be non-flammable. The surface temperature of the resistor is high. Air flowing from the resistor is of hundreds of degrees Celsius. Prevent any materials from coming into contact with the resistor.

Installation of brake resistors



- Inverters of 380 V, 37 kW or lower need only external brake resistors.
- PB and (+) are the terminals for connecting brake resistors.



Installation of brake units




- All inverters of the 660 V series need external brake units.
- ♦ (+) and (-) are the terminals for connecting brake units.



The connection cables between the (+) and (-) terminals of an inverter and those of a brake unit must be shorter than 5 m, and the connection cables between the BR1 and BR2 terminals of a brake unit and the terminals of a brake resistor must be shorter than 10 m.


The following figure shows the connection of one inverter to a dynamic brake unit.



Appendix E STO function description

Reference standards: IEC 61508-1, IEC 61508-2, IEC 61508-3, IEC 61508-4, IEC 62061, ISO 13849-1, and IEC 61800-5-2

You can enable the safe torque off (STO) function to prevent unexpected startups when the main power supply of the drive is not switched off. The STO function switches off the drive output by turning off the drive signals to prevent unexpected startups of the motor (see the following figure). After the STO function is enabled, you can perform some-time operations (such as non-electrical cleaning in the lathe industry) and maintain the non-electrical components of the device without switching off the drive.



E.1 STO function logic table

The following table describes the input states and corresponding faults of the STO function.

STO input state	Corresponding fault				
H1 and H2 opened simultaneously	The STO function is triggered, and the drive stops running. Fault code:				
H1 and H2 closed simultaneously	40: Safe torque off (STO) The STOP function is not triggered, and the drive runs properly.				
One of H and H2 opened, and the other closed	The STL1, STL2, or STL3 fault occurs. Fault code: 41: Channel H1 exception (STL1) 42: Channel H2 exception (STL2) 43: Channel H1 and H2 exceptions (STL3)				

E.2 STO channel delay description

The following table describes the trigger and indication delay of the STO channels.

STO mode	STO trigger and indication delay ^{1, 2}
STO fault: STL1	Trigger delay < 10 ms
0.0.00	Indication delay < 280 ms
STO fault: STL2	Trigger delay < 10 ms
310 lault. 31L2	Indication delay < 280 ms
STO fault: STL3	Trigger delay < 10 ms
STO fault. STE3	Indication delay < 280 ms
STO fault: STO	Trigger delay < 10 ms
STO Tauli. STO	Indication delay < 100 ms

- STO function trigger delay: Time interval between trigger the STO function and switching off the drive output
- STO instruction delay: Time interval between trigger the STO function and STO output state indication

E.3 STO function installation checklist

Before installing the STO, check the items described in the following table to ensure that the STO function can be properly used.

	Item					
	Ensure that the drive can be run or stopped randomly during commissioning.					
	Stop the drive (if it is running), disconnect the input power supply, and isolate the drive					
	from the power cable through the switch.					
	Check the STO circuit connection according to the circuit diagram.					
П	Check whether the shielding layer of the STO input cable is connected to the +24 V					
	reference ground COM.					
	Connect the power supply.					
	Test the STO function as follows after the motor stops running:					
	If the drive is running, send a stop command to it and wait until the shaft of the					
	motor stops rotating.					
	Activate the STO circuit and send a start command to the drive. Ensure that the					
	motor does not start.					
	Deactivate the STO circuit.					
	Restart the drive, and check whether the motor is running properly.					
	Test the STO function as follows when the motor is running:					
	Start the drive. Ensure that the motor is running properly.					
	Activate the STO circuit.					
	The drive reports an STO fault (for details, see section 7.5 "Inverter faults and					
	corresponding solutions"). Ensure that the motor coasts to stop rotating.					
	Deactivate the STO circuit.					
	Restart the drive, and check whether the motor is running properly.					

Appendix F Acronyms and abbreviations

This chapter describes the acronyms and abbreviations of the terms or words that may be displayed

on the interfaces of the keypad.

Term/word	Acronym/ abbreviation	Term/word	Acronym/ abbreviation
Accumulated/ accumulation	Accum	Inverter	Inv
Address	Addr	Leakage	Lkge
Amplitude	Amp	Lower limit	LowLim
Bridge	Brdg	Low-frequency	LwFreq
Coefficicent	Coeff	Low-speed	LwSp
Combination	Comb	Master/slave	M/S
Command	Cmd	Operation/operate/operator	Oper
Communication	Comm	Output	Outp
Compensation	Comp	Parameter	Param
Component	Cmpt	Password	Pwd
Consumption	Consume	Position	Pos
Control	Ctrl	Power	Pwr
Current	Cur	Proportional	Prop
Detection/detect	Det	Protect/protection	Prot
Differential	Diff	Quantity	Qty
Digital	Digi	Reference	Ref
Display	Disp	Resistance	Resis
Dynamic	Dyn	Reverse	REV
Eelectromotive force	Emf	Saturation	Satur
Emergency	Emer	Short-circuit	S/C
Error	Err	Source	Src
Factor	Fac	Speed	Spd
Feedback	Fdbk	Spindle	Spdl
Filter/filtering	Filt	Switch	Swt
Forward	FWD	System	SYS
Frequency	Freq	Temperature	Temp
Frequency point	FreqPnt	Terminal	Trml
Friction	Frict	Threshold	Thr
High-speed	HiSp	Torque	Trq
Identification/identity	ID	Upper limit	UpLim
Inductance	Ind	Value	Val
Initial	Init	Version	Ver
Input	Inp	Vibration	Vib
Instance	Inst	Voltage	Volt
Integral	Intg	Voltage point	VoltPnt
Interval	Intvl		

Appendix G Further information

G.1 Product and service queries

Should you have any queries about the product, contact the local INVT office. Provide the model and serial number of the product you query about. You can visit www.invt.com.cn to find a list of INVT offices.

G.2 Feedback on INVT Inverter manuals

Your comments on our manuals are welcome. Visit www.invt.com.cn, directly contact online service personnel or choose Contact Us to obtain contact information.

G.3 Documents on the Internet

You can find manuals and other product documents in the PDF format on the Internet. Visit www.invt.com.cn and choose Service and Support > Data Download.



Service line:86-755-86312859 E-mail:overseas@invt.com.cn

Website:www.invt.com

The products are owned by Shenzhen INVT Electric Co., Ltd.

Two companies are commissioned to manufacture: (For product code, refer to the 2nd/3rd place of S/N on the name plate.)

Shenzhen INVT Electric Co., Ltd. (origin code: 01)
Address: INVT Guangming Technology Building, Songbai Road,
Matian, Guangming District, Shenzhen, China

INVT Power Electronics (Suzhou) Co., Ltd. (origin code: 06) Address: 1# Kunlun Mountain Road, Science&Technology Town, Gaoxin District, Suzhou, Jiangsu, China

■Motor & Electric Spindle

Industrial Automation: ■Frequency Inverter ■Servo & Motion Control

■HMI ■Intelligent Elevator Control System ■Traction Drive

Electric Power: ■Online Energy Management System **■**SVG ■Solar Inverter ■UPS



INVT Copyright.

Information may be subject to change without notice during product improving.

■PLC